

Servo Hoist Technical Manual



THIS MANUAL CONTAINS IMPORTANT INFORMATION REGARDING INSTALLATION, SAFETY, MAINTENANCE, AND OPERATION OF KNIGHT INDUSTRIES SERVO HOIST AND SHOULD BE AVAILABLE TO ALL PERSONNEL RESPONSIBLE FOR USING THE SERVO HOIST.

REV: 3_1_22

Warranty

Knight Industries Inc. warrants the Servo Hoist to the original user to be free of defects in material and workmanship for a period of one year from the date of purchase. Knight Industries will repair, with cost, any Servo Hoist found to be defective, including parts and labor charges, or at its option, will replace such Servo Hoist or refund the purchase price less a reasonable allowance for depreciation, in exchange for the Servo Hoist. Repairs or replacements are warranted for the remainder of the original warranty period.

If the Servo Hoist proves defective within its original one year warranty period, contact Knight Industries or originating distributor for a return goods authorization.

This warranty is void if servo hoist is disassembled beyond recommendations in this manual.

This warranty does not apply to Servo Hoists which Knight Industries has determined to have been used in a caustic or severe environment, misused, abused or improperly maintained by the user, or where the malfunction or defect can be attributed to the use of non-genuine Knight Industries parts. Knight makes no other warranty, and all implied warranties including any warranty of merchantability or fitness for a particular purpose are limited to the duration of the expressed warranty period as set forth above. Knight Industries liability is limited to the purchase price of the Servo Hoist and in no event shall Knight Industries be liable for any consequential, indirect, incidental, or special damages of any nature rising from the sale or use of the , whether based on contract, tort, or otherwise.

NOTE

Some states do not allow limitations on incidental or consequential damages or how long an implied warranty lasts. The above limitations may not apply in your state.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. It is our policy to promote safe delivery of all orders. This shipment has been thoroughly checked, packed and inspected before leaving our plant and receipt for it in good condition has been received from the carrier. Any loss or damage which occurs to this shipment while in route is not due to any action or conduct of the manufacturer.

A. VISIBLE LOSS OR DAMAGE

If any of the goods called for on the bill of lading or express receipt are damaged, or the quantity is short, do not accept them until the freight or express agent makes an appropriate notation on your freight bill or express receipt.

B. CONCEALED LOSS OR DAMAGE

When a shipment has been delivered to you in an apparent good condition, but upon opening the crate or container, loss or damage has taken place while in transit, notify the transportation company immediately.

C. DAMAGE CLAIMS

You must file claims for damage with the carrier. It is the responsibility of the transportation company to reimburse you for repair or replacement or goods damaged in shipment. Claims for loss or damage in shipment must not be deducted from the Knight Industries invoice, nor should payment of Knight Industries invoice be withheld awaiting adjustment of such claims as the carrier guarantees safe delivery. Products damaged in shipment must be returned to us for repair, services will be charged to your account and these charges will form the basis for claim against the carrier.

Every effort has been made to provide complete and accurate product information in this manual. However, due to product improvements and changes, discrepancies and omissions may be present.

It is the responsibility of the end user to exercise common sense and judgement when performing the tasks described in this manual. If any procedure seems inaccurate, incomplete or unsafe please put the equipment in a safe condition and contact Knight Industries service department for assistance.

Safety
Safety
Warning, Caution and Note1-1
General Safety Precautions1-2
Introduction
Principle of Operation
Model Number
Servo Hoist Sizing
Models and Specifications
Servo Hoist
Servo Rack and Pinion Tractor
Servo Hoist Twin Chain
Servo Hoist Twin Chain Dual Motor
Servo Hoist Articulating Arm Carriage Mounted
Servo Hoist Articulating Arm Floor Mounted
Servo Hoist Extension Arm
Servo Hoist Vertical Articulating Arm
Servo Hoist Vertical Arm
Servo Tractor with "Z" Control
Servo Tractor with "X,Y, Z" Control
Installation
Installation
Servo Hoist Trolley Installation
Safety Cable Installation
Operation
Operation 4-1
. Operation
Operation
Operation .4-1 Run-Stop .4-1 Shut Down .4-1
Operation
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1 Lift Mode .4-1 Float Mode .4-1 Limit Stops .4-2
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1 Lift Mode .4-1 Float Mode .4-1 Limit Stops .4-2 Setting Upper Limit Stop .4-2
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1 Lift Mode .4-1 Float Mode .4-1 Limit Stops .4-2 Setting Upper Limit Stop .4-2 Setting Lower Limit Stop .4-2
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1 Lift Mode .4-1 Float Mode .4-1 Limit Stops .4-2 Setting Upper Limit Stop .4-2 Clearing Limit Stops .4-2
Operation .4-1 Run-Stop .4-1 Shut Down .4-1 Start Up .4-1 No Mode .4-1 Lift Mode .4-1 Float Mode .4-1 Limit Stops .4-2 Setting Upper Limit Stop .4-2 Setting Lower Limit Stop .4-2
Operation.4-1Run-Stop.4-1Shut Down.4-1Start Up.4-1No Mode.4-1Lift Mode.4-1Lift Mode.4-1Float Mode.4-1Limit Stops.4-2Setting Upper Limit Stop.4-2Setting Lower Limit Stops.4-2Clearing Limit Stops.4-2Fault Mode.4-2
Operation.4-1Run-Stop.4-1Shut Down.4-1Start Up.4-1No Mode.4-1Lift Mode.4-1Lift Mode.4-1Limit Stops.4-2Setting Upper Limit Stop.4-2Setting Lower Limit Stops.4-2Clearing Limit Stops.4-2Fault Mode.4-2Preventive Maintenance
Operation.4-1Run-Stop.4-1Shut Down.4-1Start Up.4-1Start Up.4-1No Mode.4-1Lift Mode.4-1Float Mode.4-1Limit Stops.4-2Setting Upper Limit Stop.4-2Setting Lower Limit Stop.4-2Clearing Limit Stops.4-2Fault Mode.4-2Preventive Maintenance.4-2Preventive Maintenance.5-1
Operation.4-1Run-Stop.4-1Shut Down.4-1Start Up.4-1Start Up.4-1No Mode.4-1Lift Mode.4-1Float Mode.4-1Limit Stops.4-2Setting Upper Limit Stop.4-2Setting Lower Limit Stop.4-2Clearing Limit Stops.4-2Fault Mode.4-2Preventive Maintenance.4-2Preventive Maintenance.5-1Inspection Overview.5-1
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stops4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance4-2Preventive Maintenance5-1Inspection Overview5-1Inspection5-1
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stop4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance4-2Preventive Maintenance5-1Inspection Overview5-1Load Chain: Cleaning and Lubrication5-4
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stops4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance4-2Preventive Maintenance5-1Inspection Overview5-1Inspection5-1
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stop4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance5-1Inspection5-1Inspection5-1Load Chain: Cleaning and Lubrication5-4Load Chain: Replacement A5-5Load Chain: Replacement B5-9Chain Keeper:5-12
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stop4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance5-1Inspection5-1Inspection5-1Load Chain: Cleaning and Lubrication5-4Load Chain: Replacement A5-5Load Chain: Replacement B5-9
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1Start Up4-1No Mode4-1Lift Mode4-1Float Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stop4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance4-2Preventive Maintenance5-1Inspection Overview5-1Load Chain: Cleaning and Lubrication5-4Load Chain: Replacement A5-5Load Chain: Replacement B5-9Chain Keeper:5-12Coiled Cable: Replacement5-14
Operation4-1Run-Stop4-1Shut Down4-1Start Up4-1No Mode4-1Lift Mode4-1Lift Mode4-1Limit Stops4-2Setting Upper Limit Stop4-2Setting Lower Limit Stop4-2Clearing Limit Stops4-2Fault Mode4-2Preventive Maintenance5-1Inspection5-1Inspection5-1Load Chain: Cleaning and Lubrication5-4Load Chain: Replacement A5-5Load Chain: Replacement B5-9Chain Keeper:5-12

Bill of Materials
KSH250-2301w/ Inline Handle
KSH250-2301
KSH250-2301: Schematic
KSH250-230 Layout
KSHEA250-230 Layout
KSHAEA700-230 Layout
Software
Software
Connecting to a Servo Hoist
Serial Communications Settings8-1
Save Uploaded File
Reload New Drive with Existing Software
Change Max Load Limit
Modify Chain Payout
Balance the Analog Handle
Adjust the Fixture Weight
Enabling Float, Lift, Digital, or Analog Mode
Adjust the Speeds of a Digital Handle
Encoder Offset Setup Procedure
Troubleshooting Guide8-9
Variable Descriptions
iSTS Global Variable Array
fSTS Global Variable Array
TEST Global Variable Array
FHST Global Variable Array
F8L1 Global Variable Array
F8L2 Global Variable Array
F8L3 Global Variable Array9-11
Supporting Documentation
Allen-Bradley MP-Series Small Frame Brushless Servo Motor-
Installation Guide
System Specific Documentation10-2

Safety

This manual provides important information for all personnel involved in the installation, operation and maintenance of the Knight Industries servo hoist. Even if you feel that you are familiar with this or similar equipment, you should read and understand this manual before performing any of the tasks.

Knight Industries recognizes that most companies have a safety program in place at their facility. The Safety Section, Notes, Cautions and Warnings in this manual are intended to supplement and not supersede any existing plant or company safety guidelines or regulations.

Knight Industries cannot be aware of or provide for all the procedures by which the servo hoist operations or repairs may be conducted and the hazards which may result from each method. If operation or maintenance not specifically recommended by Knight Industries is conducted, it must be ensured that product or personnel safety is not endangered by these actions. If not sure of a operation or maintenance procedure or step, personnel should place the servo hoist in a safe condition and contact a supervisor and/or Knight Industries service department for technical support.

Modifications to upgrade, re-rate or otherwise alter this equipment shall be authorized only by the original equipment manufacturer.

If a below-the-hook lifting device or sling is used with the servo hoist, refer to ANSI/ASME B30.9, "Safety Standard for Slings" or ANSI/ASME B30.20, "Safety Standard for Below-the-Hook Lifting Devices".

Electrical equipment described in this manual are designed and built in compliance with ANSI/NFPA 70, "National Electrical Code". It is the responsibility of the system designer, system manufacturer, crane or rail manufacturer, installer and user to ensure that the installation and associated wiring of the servo hoist and components is in compliance with ANSI/NFPA 70, and all applicable Federal, State and Local Codes.

Hazardous voltages are present in the servo hoist and components. Only properly trained and component personnel should perform inspections or repairs on the servo hoist or accessories.

Prior to performing any maintenance (mechanical or electrical) on the servo hoist de-energize (disconnect) the main switch supplying power to the servo hoist. Lock out the power supply following standard plant procedures. Ensuring that the installation, inspection, testing maintenance and operation is compliance with ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, National Electric Code and ANSI/ASME B30 (if installed as part of an overhead crane system) is the responsibility of the owner/operator.

All personnel that will install, operate, inspect, test or maintain the hoist should read this manual and be familiar with all applicable portions of ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, "National Electric Code" and ANSI/ASME B30 (if installed as part of an overhead crane system).

If clarification of any information in this manual or additional information is required contact Knight Industries. Do not install, operate, inspect, test or maintain the hoist unless all information is understood.Ensuring that the installation, inspection, testing maintenance and operation is compliance with ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, National Electric Code and ANSI/ASME B30 (if installed as part of an overhead crane system) is the responsibility of the owner/operator.

All personnel that will install, operate, inspect, test or maintain the hoist should read this manual and be familiar with all applicable portions of ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, "National Electric Code" and ANSI/ASME B30 (if installed as part of an overhead crane system).

If clarification of any information in this manual or additional information is required contact Knight Industries. Do not install, operate, inspect, test or maintain the hoist unless all information is understood.

Warning, Caution and Note

Throughout this manual there are steps and procedures that if not performed correctly can result in personal injury or equipment damage. The following signal words are used to identify the level of potential hazard:

WARNING

Indicates a hazard which will cause severe injury, death or substantial equipment damage.



Indicates a hazard which can or will cause injury or equipment damage.

NOTE

Notifies personnel of installation, operation or maintenance information which is important but not hazard related.

General Safety Precautions

Hazards to avoid and are not necessarily limited to the following list:

- Do not operate the servo hoist before reading this technical manual.
- Allow only personnel trained in safety and operation of this servo hoist to operate the servo hoist.
- If the servo hoist is locked out or a "DO NOT OPERATE" sign is on the servo hoist or controls do not operate the servo hoist until the lock or sign is removed by designated personnel.
- Do not use the servo hoist if hook latch has been sprung or broken.
- Ensure the hook latches are engaged before using.
- Before each shift or prior to use inspect the servo hoist in accordance with the procedures defined in the maintenance section of this manual.
- Never place your hand or fingers inside the throat area of a hook.
- Never operate a servo hoist with twisted, kinked or damaged chain.
- Only operate a servo hoist when the chain is centered over the hook. Do not "side pull" or "yard".
- Do not force the hook into place by hammering.
- Ensure the load is properly seated in the saddle of the hook.
- Never run the chain over a sharp edge.
- Pay attention to the load all times when operating the servo hoist.
- Ensure no personnel are in the path of the load.
- Do not lift the load over personnel.
- Never use a servo hoist for lifting or lowering people.
- Do not allow anyone to stand on a suspended load.
- Do not swing a suspended load.
- Never leave a suspended load unattended.
- Never cut or weld a suspended load.
- Do not operate a servo hoist if the chain is jumping, jamming, overloading or binding or if there is excessive noise.
- Avoid collisions or bumping of the servo hoist.
- Do not operate servo hoist when damaged or malfunctioning.
- Do not remove load or handling device until tension is released from the chain.

Fail Safe Brake

A fail safe braking system engages and holds the unit in place in the event of a power outage or when the run/stop button is pushed. The virtual limits and paths remain in tact.

Movement Interrupt Cycle

If the Servo System is moving in Auto-Mode, and an obstruction or operator is within its path, the Servo System will stop once contact is made.

Overload Capacity Protection

Protects the equipment and prevents the operator from lifting or moving more weight than the system is rated for. If load parameters exceed the programmed capacity, the hoist will not lift any further until the load is removed.

Run/Stop Push Button

If an operator needs to shutdown the system immediately, the operator pushes the Run/Stop button. The system will not function until it is reset. To reset the system from the run/stop condition, the operator turns the button clockwise to release it from the down position. All virtual limits and programs remain intact.




Figure 2-1

Introduction


Servo Hoist Callouts

(Refer to Figure 2-1)

- 1. Gear Box Adapter
- 2. Gear Reducer
- 3. Chain Guide Mounting Plate
- 4. Servo Motor with Brake
- 5. Power Contractor (Underneath Servo Motor)
- 6. Motor Brake Cable
- 7. Motor Power Cable
- 8. Motor FB Cable
- 9. 24VDC Power Supply
- 10. 230 VAC Plug
- 11. Servo Drive
- 12. Terminals
- 13. Chain Bucket
- 14. Regen Board

Model Number

The servo hoist model number designates the Servo Hoist type and specifications. The letters indicate the Servo Hoist type, refer to table 2-1. The numbers preceding the servo hoist model letters reference the rated capacity. The next (3) three letters indicates the voltage and the last number indicates the phase.



Letters	Servo Hoist Type
KSH	Knight Servo Hoist Single Chain
KST	Knight Servo Tractor
KSHTC	Knight Servo Hoist Twin Chain
KSHTCDM	Knight Servo Hoist Twin Chain Dual Motor
KSHFA	Knight Servo Hoist Floor Mounted Articulating Arm
KSHCA	Knight Servo Hoist Overhead Carriage Articulating Arm
KSHEA	Knight Servo Hoist Extension Arm
KSHAEA	Knight Servo Hoist Articulating Extension Arm
KSHVA	Knight Servo Hoist Vertical Arm
KSHVAA	Knight Servo Hoist Vertical Articulating Arm
KSHXZ	Knight Servo Hoist and Tractor X and Z Movement
KSHXYZ	Knight Servo Hoist and Tractor X, Y, and, Z Movement

Servo Hoist Sizing

Servo Hoists are designed to float the weight, but can also be used as a hoist. The load should be 65 percent of the rated Servo Hoist capacity for optimal balance, refer to "Models and Specifications" page 2-2. Knight Industries recommends the total load weight be 75 percent or less than the Servo Hoist capacity for hoist applications.

Models and Specifications



Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
	Servo) Hoist	
KSH250-1151 Single Chain	250 [113]	98.43' fpm[30mpm]	115 / 1 Phase
KSH250-2301 Single Chain	250 [113]	196.85' fpm [60mpm]	230 / 1 Phase
KSH500-2301 Single Chain	500 [227]	98.43' fpm [30mpm]	230 / 1 Phase
KSH750-2301 Single Chain	750 [340]	123.03' fpm [37.5mpm]	230 / 1 Phase
KSH1000-2301 Single Chain	1000 [454]	82.02' fpm [25mpm]	230 / 1 Phase
KSH2000-2301 Reeved Unit	2000 [908]	41.01' fpm [12.5mpm]	230 / 1 Phase

Servo Hoist

Enables operator to precisely locate and/or float a load in the "Z" direction.



Servo Rack and Pinion Tractor				
Model Capacity Ibs Speed [kg] Max. Voltage / Pha				
KST4000	4000 [1814]	174.53' fpm [53.20mpm]	230 / 1 Phase	

Servo Rack and Pinion Tractor

Accurately locates a load in the X and Y direction.





Capacity lbs [kg]	Speed Max.	Voltage / Phase	
Servo Hoist Twin Chain			
250 [113]	196.85' fpm [60mpm]	230 / 1 Phase	
500lb, 750lb, and 1000lb arms are application dependent and considered a special order.			
	[kg] Servo Hois 250 [113] Ib, and 1000lb ar	[kg] Max. Servo Hoist Twin Chain 250 [113] 196.85' fpm [60mpm] lb, and 1000lb arms are application do	

Chain spreads 2ft [.6m] standard. Additional spreads determined per application.

Servo Hoist Twin Chain

Incorporates the benefits of a Servo System into a twin chain process. The twin chains help control/balance unwieldy or long parts.



Servo Hoist Twin Chain Dual Motor				
Capacity lbs [kg]	Speed Max.	Voltage / Phase		
500 [227]	196.85' fpm [60mpm]	230 / 1 Phase		
1000 [454]	98.43' fpm [30mpm]	230 / 1 Phase		
1500 [680]	123.03' fpm [37.5mpm]	230 / 1 Phase		
2000 [908]	82.02' fpm [25mpm]	230 / 1 Phase		
	Capacity Ibs 500 [227] 1000 [454] 1500 [680] 2000 [908]	Capacity Ibs [kg] Speed Max. 500 [227] 196.85' fpm [60mpm] 1000 [454] 98.43' fpm [30mpm] 1500 [680] 123.03' fpm [37.5mpm] 2000 [908] 82.02' fpm [25mpm]		

 Chain spreads 2ft [.6m] standard. Additional spreads determined per application.

Servo Hoist Twin Chain Dual Motor

Incorporates the benefits of a Servo System into a twin chain process. The twin chains control/balance unwieldy or long parts. The dual motor Servo Hoist is for heavier loads up to 1400lbs/635kg.





Servo Hoist Articulating Arm On An Overhead Carriage

Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
KSHCA500-2301	500 [227]	98.43' fpm [30mpm]	230 / 1 Phase
KSHCA1000-2301	1000 [454]	82.02' fpm [25mpm]	230 / 1 Phase

Servo Hoist Articulating Arm "Overhead Carriage"

Servo Hoist mounted on an Articulating Arm. Allows for overhead extended reach within a work cell



Servo Hoist Articulating Arm Floor Mounted			
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
KSHFA500-2301	500 [227]	98.43' fpm [30mpm]	230 / 1 Phase
KSHFA1000-2301	1000 [454]	82.02' fpm [25mpm]	230 / 1 Phase

Servo Hoist Articulating Arm "Floor Mounted"

Servo Hoist mounted on an Articulating Arm. Allows for overhead extended reach within a work cell



Servo Hoist Extension Arm				
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase	
KSHEA250-2301	250 [113]	196.85' fpm [60mpm]	230 / 1 Phase	
500lb, 750lb, and 1000lb arms are application dependent and considered a special order.				

Servo Hoist Extension Arm "Overhead Mounted"

Incorporates a Servo Hoist within a boom. Enables the operator to reach outside the area directly below the rail.



Servo Hoist Articulating Extension Arm				
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase	
KSHAEA250-2301	250 [113]	196.85' fpm [60mpm]	230 / 1 Phase	
KSHAEA500-2301	500 [227]	98.43' fpm [30mpm]	230 / 1 Phase	
KSHAEA750-2301	750 [340]	123.03' fpm [37.5mpm]	230 / 1 Phase	
KSHAEA1000-2301	1000 [454]	82.02' fpm [25mpm]	230 / 1 Phase	

Servo Hoist Articulating Extension Arm "Floor Mounted"

Articulating Extension Arm attached to a Servo Hoist. Allows for overhead extended non-linear reach within a work cell. May be mounted to a single bridge, rotating carriage or floor mounted pedestal.



Servo Hoist Vertical Arm				
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase	
KSHVA250-2301	250 [113]	196.85' fpm [60mpm]	230 / 1 Phase	
500lb, 750lb, and 1000lb arms are application dependent and considered a special order.				

Servo Hoist Vertical Arm "Overhead Mounted"

Servo Hoist mounted on a vertical aluminum mast creates a steady state condition. Eliminates the yarding of a cable or chain.



Servo Hoist Vertical Articulating Arm			
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
KSHVAA250-2301	250 [113]	196.85' fpm [60mpm]	230 / 1 Phase
500lb, 750lb, and 1000lb arms are application dependent and considered a special order.			

Servo Hoist Vertical Articulating Arm "Floor Mounted"

Servo Hoist mounted on a vertical aluminum mast. Creates a steady state condition, eliminating the yarding of a cable or chain. This hoist includes an articulating boom which enables the operator to reach underneath areas in a confined work cell.



Servo Tractor with "Z" Control			
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
KSHXZ1000	1000 [454]	174.53' fpm [53.20mpm]	230 / 1 Phase

Servo Tractor with "Z" Control

Combines X and Z movements in one handle.



Servo "X / Y" Tractor with "Z" Control			
Model	Capacity lbs [kg]	Speed Max.	Voltage / Phase
KSHXYZ1000	1000 [454]	174.53' fpm [53.20mpm]	230 / 1 Phase

Servo Tractor with "X, Y, and, Z" Control Combines X, Y and Z movements in one handle.



THIS PAGE IS INTENTIONALLY LEFT BLANK

Installation

Prior to installation visually inspect the servo hoist for signs of damage or missing parts.

Prior to installation, the chain must be lubed using a SAE 50 to 90 EP oil.

ACAUTION

Prior to placing this unit into service the owners and user are advised to examine specific local and/or other regulations, including ANSI and OSHA regulations that may apply to the use of this product.

WARNING

A falling load can cause injury or death. Before installing this servo hoist read the "Safety" section of this manual.

Follow all procedures in this section for installation and set-up of the servo hoist .

Retain all product information supplied with the servo hoist for future reference.

Ensure that the supporting structure is able to support the weight of the system and load. The structure should be able to support 300 percent of the combined weight of the servo hoist and load. Do not use a supporting structure that tilts the servo hoist to one side or the other.

For safe and proper installation into a rail system, refer to the installation manual provided by the rail system manufacturer.

When installation is complete and prior to placing the servo hoist into operation, inspect the servo hoist following the "Periodic Inspection" procedure on page 5-2 of the "Maintenance" section.

Power Supply to Servo Hoist:

Prior to installation visually inspect the Servo Hoist for signs of damage or missing parts.

Power Requirements: Standard 230V AC Single Phase / 60 hertz

1. The Servo System is operated by plug and cord power supply. Insert Servo Hoist plug into electrical receptacle.




Figure 3-1

Servo Hoist Trolley Installation:

Prior to installation visually inspect the trolley for signs of damage or missing parts.

 Slide trolley into trolley mounting plate on top of the servo hoist. Insert (2) two 1/2 x13x1/2 sockethead bolts and (2) two washers.



Figure 3-1



Trolley should be mounted offset for load distribution. (Refer to Figure 3-1 for trolley plate alignment)

2. Secure the (2) two sockethead bolts.

(Refer to Safety Cable Installation on page 3-2)

Safety Cable Installation:

1. Slide thimbles together as shown (Figure 3-2).



Figure 3-2

- 2. Slide two (2) cable clamps onto cable.
- 3. Loop end of cable around thimble and run end through cable clamps as shown (See Figure 3-3). The cable saddle (forged part) rests on the "live" (longer) end of the cable. The U-bolt rests on the "dead" (shorter) end of the cable.




Figure 3-3

- 4. Tighten nuts on clamps, alternating sides.
- 5. Follow the steps below for trolley or top hook.
- Insert cable through center hole on trolley and bracket (fig.3-4) and place two crosby clamps on the cable.
- Secure the two crosby clamps snug to the thimble repeating step 3.
- 6. Install cable so that the servo hoist has a drop of not more than 1 in. [2.54 cm].
- 7. Trim excess cable and tape ends of cable to prevent fraying.



Figure 3-4



Figure 3-5



Figure 3-6

Operation

All operators should read and understand the instructions in this manual. Follow all instructions and warnings in this manual for safe and trouble free operation.

NOTE

Due to the visual indicator (LED / Push Button Indicator) setup on the pendant control being configurable to customer specifications, the word "indicator" is used throughout these procedures to denote either a push button indicator or LED indicator.

Run-Stop

- 1. Press the RUN-STOP button, located on the pendant control handle.
 - Main power is removed and motion is disabled.
 - The RUN-STOP button will illuminate red.

Recovery:

- 1. Correct the situation that caused the run-stop.
- 2. Follow the Start Up procedure to restore power to the unit.

Shut Down

- 1. Press the RUN-STOP button, located on the pendant control handle.
- Disconnect the power supply to the unit (if required).

Start Up

- 1. Connect the power supply to the unit (if required).
- 2. Reset the RUN-STOP button.
 - The unit defaults to No Mode.
 - GREEN indicator will flash
- 3. Move the handle upward (use lift or float mode) until the upper limit switch is made. The GREEN indicator will illuminate solid (Unit will switch to Lift Mode).

No Mode

If the servo hoist is inactive for 15 minutes the unit will shift to an energy saving sleep mode; the brake will engage and remove the load from the motor. When the unit is in No Mode, the GREEN and BLUE indicators will flash alternately.

To reactivate the unit, move the pendant handle upward or downward or press the GREEN or BLUE push button.

Lift Mode

Press the GREEN button to shift the servo hoist to Lift Mode.

• The GREEN indicator will illuminate

In Line Pendant Handle

1. Slide the handle in the desired direction of travel (upward or downward). Travel speed is dependent on pressure applied to the handle by the operator.

Remote Mounted Pendant Handle

Press the UP or DOWN button to move the hoist in the desired direction. Travel speed is dependent on pressure applied to the button by the operator.

Float Mode

Press the BLUE button to shift the servo hoist to Float Mode.

• The BLUE indicator will illuminate.

Use the fixture or part to move up and down. Do not use the handle to move the part.

To shift the servo hoist out of Float Mode use the pendant handle (inline or remote mount) to move the hoist upward or downward or press the GREEN push button and the unit will shift to Lift Mode.

NOTE

Part must be picked up with the unit in Lift Mode and then shift the servo hoist to Float Mode.

NOTE

If the servo hoist is inactive for 5 minutes while in Float mode the unit will shift to Lift Mode.

NOTE

Pressing upward or downward on the pendant handle assembly will prevent the unit from changing to float mode.

Limit Stops

NOTE

During operation (normal or float mode) the hoist will ramp down in speed as the limit stops are approached.

Setting Upper Limit Stop

- 1. Move the handle to the desired location (Lift or Float mode).
- 2. Press and hold the GREEN push button until the GREEN and BLUE indicators begin to flash simultaneously (unit is in Program Mode).
- 3. Press the GREEN push button.
 - Upper limit is set.
 - GREEN and BLUE indicators will stop flashing.
 - GREEN indicator will remain illuminated.

Setting Lower Limit Stop

- 1. Move the handle to the desired location (Lift or Float mode).
- 2. Press and hold the GREEN push button until the GREEN and BLUE indicators begin to flash simultaneously (unit is in Program Mode).
- 3. Press the Blue Push Button.
 - The lower limit is set.
 - GREEN and BLUE indicators will stop flashing.
 - GREEN indicator will remain illuminated.

Clearing Limit Stops

- 1. Press and hold the GREEN push button.
 - The GREEN and BLUE indicators will begin to flash simultaneously.
 - When only the GREEN indicator is illuminated the limit stops are cleared from memory.

Fault Mode:

Red light will flash

1. Press the RUN-STOP button, located on the pendant control handle.

• Main power is removed and motion is disabled.

• The RUN-STOP button will illuminate red.

Recovery:

- 1. Correct the situation that caused the fault
- 2. Follow the Start Up procedure to restore power to the unit.

Preventive Maintenance

Inspection Overview

The inspection procedures and recommendations in this manual are based on ANSI/ASME B30.16. The following definitions and recommendations are from ANSI/ASME B30.16 and pertain to the recommended inspection procedures in this manual.

- <u>Qualified Person</u>- a person who, by possession of a recognized degree in an applicable field, or certificate of professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter at work.
- <u>Designated Person</u>- a person selected or assigned by the employer or the employer's representative as being competent to perform specific duties.
- <u>Normal Service</u>- service that involves operation with randomly distributed loads within the rated load limit, or uniform loads less than 65% of rated load for not more than 25% of the time for electric hoists.
- <u>Heavy Service</u>- service that involves operation within the rated load limit, which exceeds normal service.
- <u>Severe Service</u>- service that involves normal or heavy service with abnormal operating conditions.
- <u>Abnormal Operating Conditions</u>- environmental conditions that are unfavorable, harmful, or detrimental to the operation of a hoist, such as excessively high or low ambient temperatures, exposure to weather, corrosive fumes, dust laden or moisture laden atmospheres, and hazardous locations.

Inspection Record Requirements

Duty Rating

Inspection frequency should be determined by a qualified person and is based on factors such as severity of environment, percentage of capacity lifts, cycle time and shock loading. Each servo hoist should be rated individually and inspections performed in accordance with rating.

Frequent inspections can be performed by the operator or designated personal.

Periodic inspections must to be performed by designated personal.

Frequency of Documentation

Frequent Inspection (Non Documented):

- Normal duty cycle monthly.
- Heavy duty cycle- weekly.
- Severe duty cycle- daily.

Periodic Inspection (Documented):

- Normal duty cycle- annually.
- Heavy duty cycle- semi annually.
- Severe duty cycle- quarterly.

An inspection record which can be copied is located on the inside back cover of this manual.

Documentation should be made available to personnel for review.

Inspection

Frequent

If any of the conditions listed below are evident the servo hoist should be placed out of service and a detailed inspection and corrective action should be taken. Additionally, the operator should check the system continually during operation to ensure that no malfunctions are occurring.

Servo Hoist:

- Visually inspect the servo hoist, ensure that it is in good general working order. Repair or replace any broken or missing parts.
- Cycle the servo hoist and listen for any abnormal noises (grinding etc.). If any abnormal noises are evident a periodic inspection of the servo hoist must be performed.
- Inspect how the chain feeds through the servo hoist. If any binding is evident clean and lubricate the chain (see Chain Periodic Inspection). If the problem persists replace the chain.
- Cycle run stop.

continued from previous page

Load Chain

- Inspect each of the links for bending, cracks in weld area or shoulders, traverse nicks and gouges, weld splatter, corrosion pits, striation, general wear including bearing surfaces between chain links.
- The entire surface of the chain should have a light coating of lubricant and be free of dirt and grime. Clean and lubricate the chain as required refer to procedure on page 5-4.
- Inspect the chain for stretching. Measure the pitch across a five link section in several locations throughout the length of the chain (Refer to Figure 5-1). Additionally measure the wire diameter in several locations (Refer to Figure 5-1). Replace chain if the pitch is greater than the maximum value shown or if the wire diameter is less than the minimum value shown in Table 5-1.




Figure 5-1

	Normal in. (mm)	Discard in. (mm)
Pitch Dimension	2.38 (60.5)	2.43 (61.7)
Wire Diameter	0.16 (4.0)	0.13 (3.3)

Table 5-1

Load Shackle:

- Check shackle for signs of wear, refer to manufacturer's documentation for wear limits.
- Ensure load shackle is not cracked, nicked or gouged. Replace the shackle as necessary.
- Refer to manufacturers literature for additional maintenance requirements.
- Refer to manufactures specifications for wear.

Periodic Inspection (Documented)

Perform the items listed in the <u>Frequent Inspection</u> section in addition to the items listed below. All findings from this inspection should be recorded. An inspection record, which can be copied, is located on the inside back cover of this manual.

If any of the conditions listed below are evident the servo hoist should be placed out of service and corrective actions can be taken.

Supporting Structure:

• Check for distortion, wear and continued ability to support the load. Refer to manufacturers' instructions for overhead rail systems.

Rail Trolley (if applicable):

- Ensure wheels and side rollers run smoothly and are not excessively worn. Replace the wheels and side rollers as necessary.
- Check all fasteners ensure they are intact and properly tightened.
- Visually check the nylon at the bearing and along the face of the wheel for cracks.

Fasteners:


• Check all fasteners ensure they are not loose, missing or damaged .

Load Hook:

- Inspect for cracks, wear or damage.
- Inspect hook throat for spreading and proper safety latch engagement.
- Measure hook throat at wear points, greater than ten percent wear in any throat zone requires replacement. See manufacturer's instructions for wear zone information.
- Inspect hook eye or chain nest and sleeve for security.
- Inspect hook eye or chain nest and sleeve for free rotation without binding.

continued on following page

continued from previous page





Labels and Tags:

• Ensure that all labels are intact and legible. Replace as necessary. (Refer to Figure 5-2)

Servo Hoist Not In Regular Use:

- Idle for more than one month, but less than one year, perform the daily inspection on the servo hoist before placing it into service.
- Idle for more than one year perform the detailed inspection before placing the servo hoist into service.
- Stand-by servo hoist should have the daily inspection performed at regular intervals as conditions require.

WARNING

Failure to maintain clean and lubricated load chain will void the manufacture's warranty

ACAUTION

Load Chain: Cleaning and Lubrication

Lubricate load chain weekly, or more frequently, depending on severity of service. In a corrosive environment, lubricate more frequently than normal.

Lubricate each link of the chain and apply new lubricate over existing layer. (Refer to Figure 5-3)

Lubricate hook and safety latch pivot points.

Cleaning:

Clean the load chain with an acid free cleaning solution.

Lubrication:

Apply a light coat of SAE 50 to 90 EP oil or equivalent machine/gear oil. Ensure that oil is applied to the bearing surfaces of the load chain links. Wipe off excess oil from the load chain surfaces. Substitute a dry lubricant for use in dusty environments.



Figure 5-3

Chain Replacement A:

The servo hoist must be powered up and operational during this procedure. Use extreme caution when working around moving parts.

ACAUTION

Use only replacement load chain from Knight Industries. Replacing the load chain with chain that is the incorrect size, grade or construction can cause injury to personnel or damage equipment and voids all warranties.

Inspect the load sheave for wear when replacing the load chain, replace as necessary.



Figure 5-4

ACAUTION

Place Servo Hoist on workbench while performing chain replacement. Do not perform chain replacement while hoist is still in the air.

- 1. Lower the fixture onto a safe working surface to remove weight from hoist.
- 2. Depress Run/Stop button and remove power from Servo Hoist. Remove fixture from hoist.
- 3. Disconnect 9-Pin connector from bottom servo plate. (Refer to Figure 5-5)



Figure 5-5

4. Remove the (3) three bolts from the coiled cable clamps located on the bottom of the Servo Hoist.

NOTE

Keep coiled cable attached to handle and separate from chain.



Figure 5-6

- 5. Remove the chain retraining bolt from the control handle shackle. (Refer to Figure 5-6)
- 6. Remove the chain from the control handle shackle.
- 7. If needed, remove all chain components from the chain.

continues on next page

continued from previous page



Figure 5-7

- 8. Remove side cover(s) and trolley from the servo hoist. (Refer to Figure 5-7)
- 9. Remove the top cover panel by unfastening (5) five machine screws from the front and back cover panels and (2) BHCS 8mm button head screws from the top cover panel. (Refer to Figure 5-8)



Figure 5-8

10. Remove the chain bin retaining bolt. (Refer to Figure 5-9)



Figure 5-9

 Remove the outer gearbox bearing plate by unfastening (3) three 8mm sockethead screws.(Refer to Figure 5-10)



Figure 5-10

12. Unfasten the (2) bolts that secures chain guide to the gearbox. (Refer to Figure 5-11)

NOTE

If necessary, remove chain guide shims. (Refer to Figure 5-12)




Figure 5-11




Figure 5-12

continued from previous page

 Remove sprocket from gearbox. If necessary, lightly tap sprocket from backside of gearbox. (Refer to Figure 5-13)



Figure 5-13

 Remove remaining chain from chain guide by pulling chain through guide. (Refer to Figure 5-14)



Figure 5-14

15. At the end of the chain is a chain stop. Remove chain stop to allow chain to fully pass through chain guide. (Refer to Figure 5-15)



Figure 5-15

- Install chain stop, which was removed in step 15, on new chain and place chain stop end into bucket.
- 17. Lubricate the new chain as it is placed into the chain bucket. Refer to Load Chain Cleaning and Lubrication section on page 5-4.

 Insert new chain on bucket side of chain guide. Ensure that the chain welds on the chain links are on facing to the outside and top of the chain guide. (Refer to Figure 5-16)



Figure 5-16

NOTE

Use the second and third chain links as reference for chain link welds. First chain link can rotate, causing the weld on the link to fluctuate to either side of chain.

19. Rotate sprocket until chain feeds through to the other side of chain guide. Pull chain through so that approximately 2 ft. of chain is through the chain guide. (Refer to Figure 5-17)





20. Insert sprocket back through gearbox assembly.

NOTE

Before inserting the sprocket, ensure that keyway is not damaged on the sprocket shaft.

- 21. If necessary, replace the bearing to the outer sprocket shaft.
- 22. Install the chain guide by fastening the (2) bolts to the gearbox.

NOTE

If necessary, replace chain guide shims.

continues on next page

SERVO HOIST TECHNICAL MANUAL

continued from previous page

- 23. Install the outer gearbox bearing plate by fastening (3) three 8mm sockethead screws.
- 24. Install chain bin by fastening chain bin retaining bolt.
- 25. Install trolley to servo hoist trolley mount.
- 26. Install chain to control handle shackle.
- 27. Install coil cable to handle and bottom of Servo Hoist.
- 28. Restore power to Servo Hoist.
- 29. Once power has been restored, payout chain and re-attach handle and fixture assembly.

NOTE

A laptop is required to payout chain and re-set the upper limit for hoist. Refer to Software section for instructions.

- 29. Cycle the servo hoist through an up / down sequence to ensure that the new chain does not bind.
- 30. Reinstall the side cover(s).

Chain Replacement B:

ACAUTION

The servo hoist must be powered up and operational during this procedure. Use extreme caution when working around moving parts.

Use only replacement load chain from Knight Industries. Replacing the load chain with chain that is the incorrect size, grade or construction can cause injury to personnel or damage equipment and voids all warranties.

ACAUTION

Inspect the load sheave for wear when replacing the load chain, replace as necessary.



Figure 5-4B

Place Servo Hoist on workbench while performing chain replacement. Do not perform chain replacement while hoist is still in the air.

- 1. Lower the fixture onto a safe working surface to remove weight from hoist.
- 2. Depress Run/Stop button and remove power from Servo Hoist. Remove fixture from hoist.
- 3. Disconnect 9-Pin connector from bottom servo plate. (Refer to Figure 5-5B)



Figure 5-5B

4. Remove the (3) three bolts from the coiled cable clamps located on the bottom of the Servo Hoist.



Keep coiled cable attached to handle and separate from chain.



Figure 5-6B

- Remove the pin from the control handle shackle. (Refer to Figure 5-6B) Refer to page 5-12 for complete instructions for the chain keeper.
- 6. Remove the chain from the control handle shackle.
- 7. If needed, remove all chain components from the chain.

continues on next page

continued from previous page



Figure 5-7B

- 8. Remove side cover(s) and trolley from the servo hoist. (Refer to Figure 5-7B)
- 9. Remove the top cover panel by unfastening (5) five machine screws from the front and back cover panels and (2) BHCS 8mm button head screws from the top cover panel. (Refer to Figure 5-8B)



Figure 5-8B

10. Remove the chain bin retaining bolt. (Refer to Figure 5-9B and 5-10B)



Figure 5-9B



Figure 5-10B

 Remove the outer gearbox bearing plate by unfastening (6) six 8mm sockethead screws.(Refer to Figure 5-11B)



Figure 5-11B

12. Remove the outer chain guide plate. (Refer to Figure 5-12B)



Figure 5-12B

13. Remove keeper from chain guide and inner chain guide plate. (Refer to Figure 5-13B)



Figure 5-13B

14. Remove sprocket from inner chain guide plate. (Refer to Figure 5-14B)

AINTENANCE

M



Figure 5-14B

bucket.

15. At the end of the chain is a chain stop. Remove chain stop to allow chain to fully pass through chain guide. (Refer to Figure 5-15B)



16. Install chain stop, which was removed in step 15, on new chain and place chain stop end into

- 17. Lubricate the new chain as it is placed into the chain bucket. Refer to Load Chain Cleaning and Lubrication section on page 5-4.
- Insert new chain on bucket side of chain guide. Ensure that the chain welds on the chain links are on facing to the outside and top of the chain guide. (Refer to Figure 5-16)




Figure 5-16B

NOTE

Use the second and third chain links as reference for chain link welds. First chain link can rotate, causing the weld on the link to fluctuate to either side of chain.

- 19. Replace sprocket into inner chain guide plate. (Refer to Figure 5-14B)
- 20. Replace keeper into inner chain guide plate. (Refer to Figure 5-13B).
- 21. Replace the outer chain guide plate. (Refer to Figure 5-12B)
- 22. Install the outer gearbox bearing plate by fastening (6) six 8mm sockethead screws.



Orientate the (6) six fasterners into the outer gearbox bearing. (Refer to Figure 5-17B)



Figure 5-17B

- 23. Install chain bin by fastening chain bin retaining bolt.
- 24. Install trolley to servo hoist trolley mount.
- 25. Install chain to control handle shackle. (Refer to Chain Keeper Installment section)
- 26. Install coil cable to handle and bottom of Servo Hoist.
- 27. Restore power to Servo Hoist.
- 28. Once power has been restored, payout chain and re-attach handle and fixture assembly.

NOTE

A laptop is required to payout chain and re-set the upper limit for hoist. Refer to Software section for instructions.

- 29. Cycle the servo hoist through an up / down sequence to ensure that the new chain does not bind.
- 30. Reinstall the side cover(s).

Chain Keeper Installment:

1. Items needed (Refer to Figure 5-18)

Chain, Chain Keeper, Roll Pin, Pin, and Snap Ring.



Figure 5-18

2. Place the chain into the chain keeper. (Refer to Figure 5-19)




Figure 5-19

3. Insert roll pin thru chain keeper in front of chain link inside chain keeper. (Refer to Figure 5-20)



Figure 5-20

4. Place chain keeper assembly inside tube on top of handle or LMM unit. (Refer to Figure 5-21)



Figure 5-21

5. Align chain keeper assembly and tube thru holes. (Refer to Figure 5-22)




Figure 5-22

6. Insert pin thru tube and chain keeper assembly holes. (Refer to Figure 5-23)



Figure 5-23

7. Prepare snap-ring to be inserted into the thru hole on pin. (Refer to Figure 5-24)



Figure 5-24

8. Spread snap-ring to be inserted into the thru hole on pin and insert. (Refer to Figure 5-25)




Figure 5-25

9. Completed installation of snap-ring thru pin. (Refer to Figure 5-26)



Figure 5-26

Coiled Cable Replacement:

- 1. Remove power from Servo Hoist.
- 2. Remove cable guard from handle. (Refer to Figure 5-27).




Figure 5-27

- 3. Remove 9-pin connector from handle.
- 4. Remove the chain retaining bolt from the control handle shackle. (Depending on Servo purchased, refer to Figure 5-28A or 5-28B)



Figure 5-28A




Figure 5-28B

5. Remove 9-pin connector from bottom of the servo hoist. (Refer to Figure 5-29)





6. Remove (3) screws from the coiled cable clamping assembly from the bottom of the servo hoist. (Refer to Figure 5-30)



Figure 5-30

7. Remove coiled cable from chain and replace with new cable. (Refer to Figure 5-31)



Figure 5-31

- 8. Secure (3) screws from the coiled cable clamping assembly from the bottom of the servo hoist.
- 9. Connect the 9-pin connector to the bottom of the servo hoist. (Refer to Figure 5-29)

continued from previous page

 Seat the chain into the control handle shackle. Secure the retaining bolt through the control handle shackle. (Depending on Servo purchased, refer to Figure 5-32 or if chain keeper, refer to page 5-12)



Figure 5-32

- 11. Connect the 9-pin connector to the side of the handle.
- 12. Install cable guard to the handle. (Refer to Figure 5-18).
- 13. Restore power to Servo Hoist.

THIS PAGE IS INTENTIONALLY LEFT BLANK

Troubleshooting

Problem	Cause	Solution
	Power loss	Check circuit breaker, switches, and connections of all power lines. Check run stop, reset if necessary.
Hoist does not lift	Incorrect voltage	Check supply voltage and frequency of power supply to ensure it is correct for the servo hoist.
	Hoist overload Electrical fault	Reduce load to within the rated capacity of the servo.
		Secure power to the hoist; check all wiring and connections on the servo hoist.


Problem	Cause	Solution
	"Lower Limit Stop" set incorrectly	Clear limit stops. Refer to procedure on page 4-1.
Servo Hoist lifts but does	Open circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
not lower	Damaged pendant cord	Check each conductor in the pendant cable for continuity. Replace damaged cable as required.
	Switch malfunctioning	Check continuity in switch and electrical connections. Repair or replace as needed.

Problem	Cause	Solution
	too close to the over	Clear limit stops. Directions are located on the handle of the servo hoist. Refer to page 4-1 for further instructions.
	Open circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
Servo Hoist lowers but will		Check each conductor in the pendant cable for continuity. Replace damaged cable as required.
not lift	Switch malfunctioning	Check continuity in switch and electrical connections. Repair or replace as needed.
	Hoist overloaded	Reduce the weight of the load to within the rated capacity of the servo hoist.
	Low voltage in power supply	Determine the cause of low voltage and restore voltage back to with in +/_10% of required voltage supply.


Problem	Cause	Solution
Servo Hoist does not lift at		Reduce the weight of the load to within the rated capacity of the servo hoist.
proper speed		Determine the cause of low voltage and restore voltage back to with in +/_10% of required voltage supply.

Problem	Cause	Solution
		Check circuit for loose connections or broken conductors. Repair or replace as necessary.
Servo Hoist operates intermittently	Damaged pendant cord	Check each conductor in the pendant cable for continuity. Replace damaged cable as required.
	Damaged handle	Check each conductor in the pendant cable for continuity. Replace damaged conductors as required. Check connections and replace if necessary.

Problem	Cause	Solution
	Limit switch is defective	Repair or replace as necessary.
Actuation of limit switch does not stop hoist	Lever is bent, worn or does not move freely	Repair or replace as necessary.
	Missing ball stop	Replace.



SERVO HOIST TECHNICAL MANUAL




KSH250-2301






DRAWINGS ARE FOR REFERENCE ONLY AND SUBJECT TO CHANGE. CONTACT KNIGHT INDUSTRIES FOR CURRENT DRAWINGS.





DRAWINGS ARE FOR REFERENCE ONLY AND SUBJECT TO CHANGE. CONTACT KNIGHT INDUSTRIES FOR CURRENT DRAWINGS.






KSH250-230 Layout








KSHEA250-230 Layout

Q **OF MATERIAL** BILL

DRAWINGS ARE FOR REFERENCE ONLY AND SUBJECT TO CHANGE. CONTACT KNIGHT INDUSTRIES FOR CURRENT DRAWINGS





Software

Connecting to a Servo Hoist

Options to initiate a connection between a computer and the Ultra 5000 Drive:

1. Double click on the Ultraware software (SW) icon on the desktop. The software will automatically poll for drives that are connected to the serial port.

OR

2. Select Tools and then Rescan inside of the Ultraware (SW). (Figure 8-1).




Figure 8-1

3. Ultraware Program is attaching to the drive. (Figure 8-2).





Figure 8-2

4. Software is uploaded and listed under On-Line Drives. (Figure 8-3).



Serial Communications Settings

Options to initiate a connection between a computer and the Ultra 5000 Drive:

- 1. Connect a female-to-female 9-pin null modem serial cable from serial port on the laptop to the 9pin connector on the Servo Hoist handle. Some servo systems will need a female to male 9-pin null modem serial cable.
- 2. Select Tools and then Serial Port. (Figure 8-4)




Figure 8-4

3. Confirm the Communication Parameters (Figure 8-5).

- Serial Port should be the com port where the serial cable is connected.
- Baud Rate is always 38400.
- Format is always 8 Data Bits, No Parity.

PC Communications Setup				
Communication	n Parameters			
Serial Port:	COM 2	•		
Baud Rate:	38400	•		
Format:	8 Data Bits, No Parity 💌			
Ultra 5000 only supports 8 Data Bits, No Parity.				
OK Cancel Help				
Figure 8-5				

4. Click OK to accept the settings.

continued on following page

continued from previous page

Scan for correct nodes on the network.

1. Select **Tools** and then **Rescan Options**. (Figure 8-6)



Figure 8-6

- 2. Set node values in Rescan Option Window.
 - 1. Verify the Ultraware 5000 box is checked.
 - 2. Set "From Node-To Node" values.
 - 3. From Node: = 1
 - 4. To Node: = 10
 - 5. Knight Standard Hoist Systems are all Node 1.
 - 6. Tractor Systems may be Nodes 1-4.

NOTE

If experiencing problems connecting to the drive, set scan options from Nodes 0 to 100. This will verify the node address. (Figure 8-7)




Figure 8-7

SOFTWARE

Save Uploaded File

Uploading and saving the drive parameters from an online drive.

- 1. Verify that the system is online with the drive
- 2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Select the + next to Programs. This will expand to show one program Main.exe. (A red horizontal line will sweep from the top of the graphic to the bottom of the graphic when the program is running.)

4. Right click on Main.exe and select Stop from the menu to stop the program from running.

5. Once the program is stopped, click **File** and then **Save.** (Figure 8-8)

🕼 Ultraware - Workspace								
File	Edit	View	Insert	Program	Tools	Commands	Window	Help
N	ew							
0	pen							-
Sa	ave						Ctrl+S	
Sa	ave As							
C	lose							
igur	0 8-8							

Figure 8-8

1. A confirmation window will pop up. (Figure 8-9)

2. Click YES to upload information from the drive to the computer (process takes approximately 2 minutes).

3. A "Save As" dialog box will appear and prompt for a file name and folder location to save the .udb file. Select folder on hard drive and enter desired file name. Press "Save" button to save to hard drive.

4. The saved drive is now visible in the "Off-line" folder of the Workspace Window. (Figure 8-10)

continued from previous page

🔓 Ultraware - Workspace	
File Edit View Insert Program Tools Comm	iands Window Help
∐D⊯⊒⊜?⊯∣∐⊁®®×	
Workspace 🔀	
🖃 📳 On-Line Drives	
∰k V2_03_06	
⊡ 0ff-line: V2_03_06.udb	
⊡¶k V2_03_06	
	Ultraware
	Do you want to copy on-line data to offline before saving?
	Yes No Help
	🗖 Don't show this message again. (Default will be "No" in the future)

Figure 8-9

🔓 Ultraware - Workspace	
File Edit View Insert Program Tools Commands Window Help	
□ ☞ ■◎ ? 跑 ↓ ┗ € × ぬ ศ ∽ ∝ ル%)	3. 1% ∰ ! ⊕ © ø ! 1
Workspace On-Line Drives	Ultraware Image: Comparison of the com

Figure 8-10

Reload New Drive with Existing Software

Uploading and saving the drive parameters from an online drive.

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Select the + next to Programs. This will expand to show one program Main.exe. (A red horizontal line will sweep from the top of the graphic to the bottom of the graphic when the program is running.)

4. Right click on Main.exe and select Stop from the menu to stop the program from running.

5. Drag offline drive file to the online drive file. (Figure 8-11)




Figure 8-11

6. When prompt asks if you want to replace the drive, click "Yes".

7. Drive will be copied. (Process will take approximately 2 minutes).

8. When download is complete the program will not be running.

9. Expand Programs folder (located under Workspace On-Line Drives).

- 10. Highlight Main.exe
- 11. Start program by one of the following methods
 - a. Right click on Main.exe and select "Run."
 - b. Cycle power to the system and the program will restart upon power-up.
 - If the system has the small servo then you can press the run stop and wait 10-20 seconds for the servo to completely power down before turning it back on.
 - If the system has the large servo then you must unplug or completely disconnect the power and wait 10-20 seconds for the servo to completely power down before plugging back in.

Change Max Load Limit

If maximum load limit is reached, the hoist will no longer move in an upward direction. The system will however, allow the operator to set the load down. In order to reset the load limits:

1. Go to On-Line drive and double click on Global Variables.

2. Double click on the F8 file and scroll down to parameter F8:53 -Max Load (this value is the maximum weight that the hoist will pick up). (Figure 8-12)

Parameter	Value	Description
15	0	
16	0	
17	0	
18	0	
19	0	
20	0	
21	300	Max Load (lb) (Inc Fixture) UP STOP
22	-5	Min Load (Ib) (Exc Fixture) DOWN STOP
23	1	Lift Mode Timeout (min) (0 = no timeout)
24	40	Lift Speed Limit (in/sec)
25	0	
26	0	Remote Pendant Gain (ips/V)
27	0	Remote Pendant Deadband (V)
28	0	
29	0	
30	2	Handle Sense (lb)
31	1	Lift Force Deadband (lb)

Figure 8-12

NOTE

Physics and Force = Mass x Acceleration. If limits are set at 250lbs and operator attempts to pick up 240lbs, the 250lb threshold will be crossed when accelerating upward. Refer to load capacity ratings (listed on Servo Unit) when setting limits. For optimal, safe performance, DO NOT exceed rated capacity.

Modify Chain Payout

To prevent chain payout, a minimum load weight is programmed into the software. For example if the fixture weight is 40lbs and the minimum load weight is set to 10lbs, then the servo system will allow the hoist to lower until 10lbs of the fixture is placed on the floor. The remaining 30lbs will be supported by the hoist. This allows the operator to set down the fixture without paying out chain. If the minimum load weight is set to -50lbs, then the servo system will allow the hoist to lower until the entire weight of the 40lb fixture is placed on the floor. If the down command is maintained then the chain will payout onto the fixture until it reaches the lower limit.

To Modify Settings:

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Open Global Variable F8L1 and scroll to F8L1:22 (Parameter-Min Load) (Figure 8-13)

4. Change value to allow or stop chain payout.

P	Parameter	Value	Description
1	5	0	
1	6	0	
1	7	0	
1	8	0	
1	9	0	
2	20	0	
2	1	300	Max Load (lb) (Inc Fixture) UP STOP
2	2	-5	Min Load (lb) (Exc Fixture) DOWN STOP
2	23	1	Lift Mode Timeout (min) (0 = no timeout)
2	24	40	Lift Speed Limit (in/sec)
2	25	0	
2	26	0	Remote Pendant Gain (ips/V)
2	27	0	Remote Pendant Deadband (V)
2	28	0	
2	29	0	
3	30	2	Handle Sense (lb)
2	24	4	Lift Force Decelered (lb)

Figure 8-13

NOTE

Larger values stop chain payout; smaller values allow chain payout.

Balance the Analog Handle

The analog handle is controlled from a load cell that senses any additional force to the handle. A force-up creates a command up; a force-down creates a command down. If the static weight of the handle changes, the analog signal needs to be balanced.

To Verify Settings:

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Open Global Variable fSTS and scroll to fSTS: 3. This is the current command on the analog handle in pounds. Add this number to the number in F8L1:8. This is the Handle Weight, used to offset the lift load cell. (Figures 8-14)

NOTE

Move curser off value cell to update new value and save setting.

When looking at values online the update rate is fairly slow, so you should wait 10-15 seconds to make sure the values that you are looking at are correct.

An easy way to verify that you are working in a parameter table that is in the online drive is to see if the tab at the bottom of the window is green. Green means online and gray means offline.

4. Return to fSTS and look to make sure that fSTS:3 is close to zero. This variable is an actual filtered value that represents the pounds of force on the lift load cell. It should display 0 when no force is applied to the handle. (Figure 8-15)

continued on following page

continued from previous page

Ultraware - [F8L1 - Variable]			
File Edit View Insert Program Tools Comma	inds Window Hi	elp	
D 😂 🖬 🗇 😵 🎊 ໄໄຊ 🕹 🖬 📾 × #	ရကြက	1 % %	% ∭≝ ! ⊕ ©
irkspace 🛛 🗙	Parameter	Value	Description
Off-line: KSH Dev3.1.20.udb	Name	F8L1	
	Values	ALC: N	and the second s
E 10 k V3.1.20	0	0	
🕂 😂 Motion	1	0	
- 🗊 Motor	2	0	
"면" Tuning	3	0	
- B Encoders	4	0	
- 🗑 Digital Inputs	5	0	Top Limit (inches)
- Q Digital Outputs	6	70	Bottom Limit (inches)
Analog Inputs	7	0	
- Z Analog Outputs	8	1	Handle Weight (lb)
Monitor	9	1.5	Fixture Weight (lb)
	10	70	Default Bottom Limit (inches)
- Scilloscope	11	0	Encoder Offset (in)
- In Programs	12	150	Decel Rate At Limits (in/sec2
Archives	13	0	
Files	14	0	
🖃 🗐 Global Variables	15	0	
	16	0	
- fists	17	0	
TEST	18	0	
	19	0	
- FHST	20	0	
📙 F8L1	21	300	Max Load (lb) (Inc Fixture) (
- 🗄 F8L2	22	-5	Min Load (lb) (Exc Fixture)
- E F8L3	23	1	Lift Mode Timeout (min) (0 =
- A Faults	24	40	Lift Speed Limit (in/sec)
R. Service Info	25	0	
± 🗐 Main	26	0	Remote Pendant Gain (ips/V
	27	0	Remote Pendant Deadband (
	28	0	
	29	0	
	30	2	Handle Sense (lb)
	31	1	Lift Force Deadband (lb)
	32	0	
	Show Status		

Figure 8-14

Parameter	Value	Descripti
Name	ISTS	
Values		
0	0	Analog Input 2 (Lift LC) F
1	0	Lift LC Unbiased (lb)
2	0	Lift LC, Adjusted for Iner
3	0	Lift LC Adj, Zeroed, Filter
4	0	

Figure 8-15

Adjust the Fixture Weight

If a fixture is hanging without a load, review fSTS:17. This variable is the current part weight. This value should read approximately zero (0). (Figure 8-16)

13	0	Float LC Adj, Zeroed, Filtered
14	0	Total Weight, Adjusted for Acci
15	0	Total Weight, Adj, Filtered
16	0	Floating Weight (Float Mode Sn
17	0	Part Weight (lb) (Floating Wt - F
 0.40		

Figure 8-16

To Reset Variable fSTS: 17 (Part Weight) to Zero:

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Open Global Variable fSTS to fSTS:17. This is the current part weight on the float load cell in pounds. Add this number to the number in F8L1:9. This is the fixture weight, used to offset the float load cell.

4. After the change, return to fSTS:17 to make sure it is close to zero with no part on the fixture. This variable is an actual filtered value that represents the pounds of force on the float load cell.

NOTE

Fixture must be hanging without a load present to set correct fixture weight.

Enabling Float, Lift, Digital, or Analog Mode

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Open Global Variable F8L2. (Figure 8-17).

4. To enable the functionality, input (1) in the value columns.

5. To disable the functionality, input (0) in the value columns.

6. F8L2:20 Enable Lift Mode.

7. F8L2:40 Enable Float Mode.

8. F8L2:30 Enable Analog Handle.

9. F8L2:38 Enable Digital Handle.

NOTE

The above enable bits should only be set with the aid of a Knight Representative.

Parameter	Value	Description
20	0	Enable Lift Mode
21	300	Max Load (lb) (Inc Fixture) U
22	2	Up Stop Resume Bandwidth (
23	10	Down Stop Resume Bandwid
24	1	Up/Down Stop Resume Time
25	1	Lift Max Speed "Fudge Facto
26	0	
27	1	Enable Impulse Limiting (Lift M
28	12	Impulse Limit Max Speed Afte
29	0.1	Impulse Limit Time To Limit Ma
30	1	Enable Analog Handle
31	8	Handle Filter Bandwidth
32	0	
33	100	Lift Mode Prop Accel (in/sec2
34	150	Lift Mode Prop Decel (in/sec2
35	100	Lift Command Limit (lb)
36	0.9	Lift Force Cancellation Gain
37	0	
38	0	Enable Digital Handle
39	0	
40	0	Enable Float Mode

Figure 8-17

Adjust the Speeds of a Digital Handle

To Change Speed of the Handle:

1. Verify that your computer has an online connection with the drive.

2. Select the + next to the drive name under the On-Line Drives folder. This will expand and give more choices inside the drive.

3. Open Global Variable F8L1 and scroll down to F8L1:36 (high speed digital value in in/sec.) and F8L1:37 (low speed digital value in in/sec.) (Figure 8-18)

To Adjust the Rate of Acceleration and Deceleration of a Digital Handle:

1. Open Global Variable F8L1 and scroll down to F8L1:38 (digital acceleration value in in/sec2) and F8L1:39 (digital deceleration value in in/sec2). (Figure 8-18)




Figure 8-18

Encoder Offset Setup Procedure (Zero Position Adjustment)

This procedure is to be performed after the servo motor, gearbox or chain have been modified or replaced. It will "teach" the system the encoder position that equates to the zero or fully raised position of the hoist. Zero position is when the hoist is fully raised. The bottom limit is when the hoist is fully lowered. To setup the encoder offset the encoder position that equates to the hoist zero position must be determined. This is the encoder offset.

1. Connect to Servo Hoist by following the "Connecting to a Servo Hoist" procedure.

2. Record original values of encoder related variables from the On-Line drive.

- a. Variable F8L1:5 _____ "Top Limit Inches"
- b. Variable F8L1:6 _____ "Bottom Limit Inches"
- c. Variable F8L1:11 _____ "Encoder offset Inches"

3. The current position of the hoist is displayed in variable fSTS:30 "Real Word Position". This is the position that the hoist thinks that it is at. This may be incorrect due to the due to the replaced motor, gearbox or chain. It may be a positive or negative value.

a. Record current value of fSTS:30 _____ "Real Word Position".

4. Now that we know were the servo thinks that it is at, we can temporarily adjust the top limit to allow the hoist to move up to the physical top limit position (zero position).

- a. Adjust F8L1:5 "Top Limit Inches" a few inches less than fSTS:30 "Real Word Position"
- b. Use lift control to raise hoist a few inches.
- c. fSTS:30 "Real Word Position" will now display the new position.

d. Re-adjust F8L1:5 "Top Limit Inches" a few inches less than fSTS:30 until it allows you to completely raise the arm to home position. Raise hoist to the point that the coil cable is almost fully compressed, but not to the point that the hoist is forcing the cable into the hoist enclosure. This is the proper zero position. 5. Now that the hoist is at zero position we can determine the encoder position that equates to this zero position.

- a. Record current value of fSTS:29 "Encoder Position" _____.
- b. Copy value of fSTS:29 "Encoder Position" to F8L1:11 "Encoder Offset inches".
- c. Return values of variables F8L1:5 "Top Limit Inches" and F8L1:6 "Bottom Limit Inches" to the original values recorded in step 1.
- d. Verify that fSTS:30 "Real World Position" now displays a number close to zero.

6. Verify that encoder offset is correct by raising the host and checking that it stops automatically at the top limit before the coil cable is fully compressed.

7. Lower the hoist and verify that it stops automatically at the bottom limit before the hoist physically runs out of travel.

Troubleshooting Guide

Problem: Red light on the Run Stop button is flashing.

Action: Log onto the On-Line Ultraware Drive and open Global Variable fSTS:06. If the fault number is less than 100 then the fault is in the servo drive. Open the Fault screen to see the fault that is present. A yellow indicator (in the value column) will be on next to the fault description. (Figure 8-19)

rkspace 🛛 🗙	Parameter	Value	Un	ite.
Dn-Line Drives				R S
0ff-line: KSH Dev2_3_06_20070311_22	User Current Fault		amps	
⊡ n k ∨2_03_06	User Current Fault Enable User Velocity Fault	Disabled 0	counts	
+ 🗗 Motion	User Velocity Fault Enable	-	COUNTS	ASEC
- 🗊 Motor	Velocity Error Limit	5E+008	counts	loon
t⊡t Tuning	Velocity Error Time	1000	msec	,730C
	Following Error Limit	32000000		
- 🕤 Digital Inputs	Following Error Time	1000	msec	
	4 Motor Overtemp		Value	U
🋞 Analog Inputs				
			value	0
	5:IPM Fault		-X-	
- Programs	9:Bus Undervoltage		ŏ	
Archives	10.Bus Overvoltage		ð	
Files	11:llegal Hall State		ŏ	
	17 User Current		-ð-	
	18:Overspeed		ŏ	
	19:Following Error		Ŏ	
- FSTS	20: Motor Encoder State		Ő	
	21: Auxiliary Encoder State		Ŏ	
··· 🛕 Faults	22 Motor Filter		Ŏ	
- 🔐 Service Info	23: Thermal Protect Filter		- Õ	
🗄 🚍 Main	24 Velocity Error		- Q	
	26:User Velocity		0	
	29 Excessive Output Frequ	iency	8	
	34: Ground Short Circuit		Q	
	35:Soft-Starting Fault		- Ç	
	36 Power Module Overtern	perature	<u> </u>	
	37:AC Input Phase Loss		0	
	39 Self Sensing Startup En	or	8	
	58 Excessive CPU Load		Q	
	Fault Count	0		

Figure 8-19

If the fault number is greater than 99 then the fault is a software fault that can be looked up in table TBL8-1 on the following column:

Fault#	Description	Possible Solution
101	Run Stop input is not on to the drive.	Check input to determine why the drive is not getting the run stop input.
102	Failed to allocate memory for Global Variables.	Reduce the number of Global Variables in code.
103	Frame Failed.	Reduce the amount of code in the frame that is overloaded.
104	Velocity Following Error	Possible bad encoder cable.
105	Home Limit Switch Error	Home Limit switch has been made after the system has already been homed. Check to see why limit switch has moved
106	Axis Enable Failed	Axis enable did not enable after one second.
107	Float Load Cell not connected	The float load cell has been disconnected. Look at the physicalconnection to see why the input is not on.
108	Lift Load Cell not connected	The lift load cell has been disconnected. Look at the physicalconnection to see why the input is not on.
150	Heartbeat Fault	The heartbeat from the PLC has been lost.
152	Encoder Position Fault	The tractors absolute encoder does not match the motors encoder position.
201	Lift Load Cell Faulted	The lift load cell has seen more than the Lift Load Cell Command Limit, F8L2:35.
202	Test Parameter Fault	One of the Test Parameters is outside the top or bottom limits, or max speed limits.
203	Air Pressure Switch Not Ok	The air pressure is below that allowable limit to operate the system.

SOFTWARE

Problem: Not sure if an Input or Output is coming on?

Action: Log onto the On-Line Ultraware Drive and open the Digital Input or Digital Output screen. Verify if the specific Input or Output is ON (the lower half of the window has the current status of the Input or Output). The value column will be yellow if it is ON. (Figure 8-20)




Figure 8-20

Variable Descriptions

iSTS Global Variable Array

This complete array is reserved for internal use.

fSTS Global Variable Array

This Global Array is used as a status file to see what is going on inside the program. The values are updated from the drive over the serial communication. This means that they may not update very fast. The less parameters on the screen, the faster it will update. You can use the Windows restore down button in the upper right hand corner of the window and shrink the window to reduce the number of parameters showing. Also, if you click on the workspace the update rate will increase.

fSTS: 00 - Analog Input 2 (Lift LC) Raw

Variable Units: Volts

Description: This parameter displays the current reading of the lift load cell input in volts.

**fSTS: 01 - Lift LC Unbiased

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

fSTS: 02 - Lift LC, Adjusted for Inertial Accel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 03 - Lift Lift LC Adj, Zeroed, Filtered Variable Units: Pounds

Description: This parameter displays the current reading of the lift load cell input in pounds.

fSTS: 06 - Fault # (1-99 Drive, 100+ Software) Variable Units: Fault #

Description: This parameter displays the current drive fault if one exists. If the number is between 1 and 99 then it is a drive fault and can be looked at on the Ultraware fault screen or in the Ultra5000 manual. If the fault number is 100 or greater then it is a software servo fault and can be looked up in the back of this manual.

**fSTS: 07 - Al2 Source

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

fSTS: 08 - Operating Mode

Variable Units: Choice (1=Lift, 2=Float, 3=Test)

Description: This parameter displays the current mode of the hoist.

SERVO HOIST TECHNICAL MANUAL

fSTS: 10 - Analog Input 1 (Float LC) Raw Variable Units: Volts

Description: This parameter displays the current reading of the float load cell input in volts.

fSTS: 11 - Float LC Unbiased (Ib) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 12 - Float LC, Adjusted for Inertial Accel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 13 - Float LC Adj, Zeroed, Filtered Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 14 - Total Weight, Adjusted for Accel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 15 - Total Weight, Adj, Filtered Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 16 - Floating Weight (Float Mode Snapshot) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 17 - Part Weight (Ib) (Floating Wt - Fixture) Variable Units: Pounds

Description: This parameter displays the current reading of the float load cell input in pounds. This reading already has the fixture weight subtracted.

fSTS: 20 - Motion Timer (sec) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 21 - Main Loop Core Time (ms) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 22 - Main Loop Total Time (ms) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 23 - Main Loop Core Time, 100 scan avg (ms) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 24 - Main Loop Total Time, 100 scan avg (ms) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 25 - Logic Run Timer (days) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 26 - Total Distance Counter (inches) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 27 - Lift Mode Distance Counter (in) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 28 - Float Mode Distance Counter (in) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 29 - Encoder Position (in) Variable Units: Inches

Description: This parameter displays the actual encoder counts converted to inches.

fSTS: 30 - Real World Position (in) Variable Units: Inches

Description: This parameter displays the actual encoder counts converted to inches with the absolute encoder offset.

fSTS: 32 - Feedback Velocity (in/s) Variable Units: Inches per second

Description: This parameter displays the actual velocity of the servo hoist.

fSTS: 33 - Feedback Acceleration (in/s2) Variable Units: Inches per second2

Description: This parameter displays the actual rate of acceleration of the servo hoist.

fSTS: 35 - PGain (Vel Loop Tuning) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 36 - IGain (Vel Loop Tuning) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 37 - FGain (Vel Loop Tuning) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 38 - Kp (Pos Loop Tuning) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 39 - Kff (Pos Loop Tuning) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 40 - Stress Relief Mode Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 41 - Stress Relief Active Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 42 - Jog Vel Squared Filter Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 43 - Command Current (Amps) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

fSTS: 44 - Equivalent Force (lbs) (Up = negative) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

TEST Global Variable Array

This Global Array is used to configure and initiate the test mode auto cycle. The mode is used to cycle the hoist during the break-in period and for performance verification prior to shipping each system. This mode is for use by Knight representatives only and is disabled prior to shipping.

TEST: 00 - START TEST MODE

Variable Units: Boolean 1 = ON, 0 = OFF

Description: This parameter is used as a switch to turn on test mode. The controller will not respond to inputs and follows a set path based on the parameters set below.

TEST: 01 - Position 1 Variable Units: Inches

Description: This parameter sets the upper position limit for the controller while in test mode.

TEST: 02 - Position 2 Variable Units: Inches

Description: This parameter sets the lower position limit for the controller while in test mode.

TEST: 03 - Velocity Variable Units: Inches per second

Description: This parameter sets the velocity for test mode.

TEST: 04 - Accel Variable Units: Inches per second2

Description: This parameter sets the acceleration while in test mode.

TEST: 05 - Decel Variable Units: Inches per second2

Description: This parameter sets the deceleration while in test mode.

TEST: 06 - Delay Variable Units: Seconds

Description: This parameter sets the time delay between cycles in test mode.

TEST: 07 - Max Moves

Variable Units: Number of moves

Description: This parameter sets the number of test cycle moves. When the test cycle counter reaches this number, the test cycle will stop. If set to zero it will never stop on its own.

TEST: 10 - Move Count

Variable Units: Cycle Count

Description: This parameter displays the number of cycles completed by the hoist in test mode.

TEST: 13 - Est. Weight (lb) - Based On Mtr Current Variable Units: Pounds

Description: This parameter displays the estimated weight that the hoist is moving in test mode. This weight value is calculated from the motor current sampled during the motion.

TEST: 14 - Est. Efficiency - Based On Mtr Current Variable Units: Percent

Description: This parameter displays the estimated efficiency of the drive system. This is based on data collected during motion in test mode.

TEST: 15 - Motor Amp Avg 2nd Last Move Variable Units: Amp

variable Units: Amp

Description: Displays the average current draw of the servo motor during the 2nd to last motion in test mode.

TEST: 16 - Motor Amp Avg Last Move

Variable Units: Amp

Description: Displays the average current draw of the servo motor during the last motion in test mode.



Variables marked with a "**" should NOT be manipulated inside the F8 and N7 Global Variable Arrays, as it may have unintended consequences

FHST Global Variable Array

This variable array stores the history of system faults. It is used for system diagnostic and troubleshooting.

FHST: 00 - Fault History Index

Variable Units: Integer

Description: This variable displays the current index number of the revolving fault history array. If the fault history index is 1 then the number of the last fault is located in FHST:1 and the time of the last fault is located in FHST:2. If the fault history index is 10, then the number of the last fault is located in FHST:20 and the time of the last fault is located in FHST:21.

-- Location of last fault number = (Fault History Index x 2)

-- Location of last fault time = (Fault History Index x 2) + 1

FHST: 01, 03, 05 ... - Fault Number

Variable Units: Integer

Description: This variable displays the fault number for each fault number / fault time pair. If the number is between 1 and 99 then it is a drive fault and can be looked at on the Ultraware fault screen or in the Ultra5000 manual. If the fault number is 100 or greater then it is a software servo fault and can be looked up in the back of this manual. Note: Parameter fSTS:06 "Fault #" displays the current active fault.

FHST: 02, 04, 06 ... - Fault Time (Sec)

Variable Units: Seconds

Description: This variable displays the fault time for each fault number / fault time pair. The time is displayed in seconds from the global run timer.

NOTE

Variables marked with a "**" should NOT be manipulated without the aid of a Knight representative, as it may have unintended consequences.

F8L1 Global Variable Array

This variable array stores parameters that are most frequently adjusted by the end user. This list contains parameters used to fine tune the system performance. It also contains configuration parameters that must be adjusted after maintenance to the servo, motor or gearbox or after adjustment of the fixture or lift handle.

F8L1: 05 - Top Limit

Variable Units: Inches

Description: This sets the upper travel limit for the hoist. This may also be set through program mode on the handle (See instructional text on handle). This value should be set to a number greater than or equal to zero. The home position is set at zero. When setting the limits through program mode on the handle the limits must be 12 inches apart to prevent setting limits at the same point, which would prevent any movement.

Additional Reference: Section 4 "Limit Stop" instructions.

F8L1: 06 - Bottom Limit

Variable Units: Inches

Description: This sets the lower travel limit for the hoist. This may also be set through program mode on the handle (See instructional text on handle). This value should be set to a number greater than the Top Limit. The home position is set at zero. When setting the limits through program mode on the handle the limits must be 12 inches apart to prevent setting limits at the same point, which would prevent any movement.

Additional Reference: Section 4 "Limit Stop" instructions.

F8L1: 08 - Handle Weight

Variable Units: Pounds

Description: This configuration parameter is for the entry of the static weight of everything on the operator's side of the lift load cell. This must be adjusted if the lift handle is modified or replaced. Additional Reference: Section 8 "Balance the Analog Handle" procedure.

F8L1: 09 - Fixture Weight

Variable Units: Pounds

Description: This configuration parameter is for the entry of the static weight of the fixture, hook or shackle hanging below the float load cell. This must be adjusted if the fixture is modified or replaced.

Additional Reference: Section 8 "Adjust the Fixture Weight" procedure.

F8L1: 10 - Default Bottom Limit

Variable Units: Inches

Description: This sets the default value for the bottom position limit. This value is used when the operator programmed limits are reset by holding the green button for more than six seconds.

Additional Reference: Section 4 "Limit Stop" instructions.

F8L1: 11 -Encoder Offset

Variable Units: Inches

Description: This sets the offset that the hoist uses to compute the home position. It offsets the absolute encoders zero position so the hoists zero position becomes the position at the physical upper limit of travel. A zero indicates a non-absolute incremental motor and is for compatibility with legacy systems.

This parameter must be adjusted when the motor, gearbox or chain are replaced.

F8L1: 12 - Decel Rate At Limits

Variable Units: Inches per second2

Description: This sets the rate of deceleration at the top and bottom limits.

F8L1: 21 - Max Load (Ib) (Including Fixture) Variable Units: Pounds

Description: This sets the maximum load that the Servo Hoist will lift, including the weight of the fixture.

Note: Parameter "F8L2:21 - Max Load (lb)" also restricts the maximum load. F8L1:21 must be set to a value less than or equal to the value of F8L2:21.

Additional Reference: Section 8 "Change Max Load Limit" procedure.

F8L1: 22 - Min Load (Ib) (Excluding Fixture) Variable Units: Pounds

Description: This sets the minimum load that the Servo Hoist will release. This means that once it gets below this amount of weight the Servo Hoist will not pay out any more chain. This is typically set to a value that allows the hoist to lower most of the fixture weight on to the floor without paying out additional chain once the fixture is on the floor.

Additional Reference: Section 8 "Modify Chain Payout" procedure.

F8L1: 23 - Lift Mode Timeout (min) (0 = no timeout) Variable Units: Minutes

Description: This sets the length of time that the controller will stay in lift mode unattended. When idle for longer than the specified time the controller will

disable and revert to off mode. If this variable is set to zero, the hoist will never go into off mode.

F8L1: 24 - Lift Speed Limit

Variable Units: Inches per second

Description: This sets the maximum lift velocity for the Servo Hoist. The parameter is limited to the absolute maximum velocity of the system.

F8L1: 26 - Remote Pendant Gain Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L1: 27 - Remote Pendant Deadband Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L1: 30 - Handle Sense

Variable Units: Pounds

Description: This sets the amount of force that is required on the lift handle before it changes from off mode to lift mode or from float mode to lift mode.

Note: Applies to systems with in-line or fixture style handles only.

F8L1: 31 - Lift Force Deadband

Variable Units: Pounds

Description: This sets the amount of input force that is required on the lift handle to start motion.

Note: Applies to systems with in-line or fixture style handles only.

F8L1: 36 - Digital Lift High Speed Variable Units: Inches per second

Description: This sets the high speed for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

F8L1: 37 - Digital Lift Low Speed Variable Units: Inches per second

Description: This sets the low speed for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

F8L1: 38 - Digital Accel Variable Units: Inches per second2

Description: This sets the acceleration for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

F8L1: 39 - Digital Decel

Variable Units: Inches per second2

Description: This sets the deceleration when for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

F8L1: 41 - Float Top Limit Variable Units: Inches

Description: This sets the upper travel limit for the hoist when in float mode.

F8L1: 42 - Float Bottom Limit

Variable Units: Inches

Description: This sets the lower travel limit for the hoist when in float mode.

F8L1: 43 - Float Mode Timeout (min) (0 = no timeout)

Variable Units: Minutes

Description: This sets the length of time that the controller will stay in float mode unattended. When idle for longer than the specified time the controller will disable and revert to off mode. If this variable is set to zero, the hoist will never go into off mode.

F8L1: 44 - Float Speed Limit

Variable Units: Inches per second

Description: This sets the maximum velocity of the Servo Hoist in float mode.

F8L1: 45 - Float Force Deadband Variable Units: Pounds

Description: This sets the amount of input force that is required on the object hanging from the hoist to start motion in float mode.

** Parameters 71 - 75 are application specific **

F8L1: 71 - User Param 1 Variable Units: Application Specific

Description: Application Specific

F8L1: 72 - User Param 2 Variable Units: Application Specific

Description: Application Specific

F8L1: 73 - User Param 3 Variable Units: **Application Specific**

Description: **Application Specific**

F8L1: 74 - User Param 4 Variable Units: Application Specific

Description: Refer Application Specific

F8L1: 75 - User Param 5

Variable Units: Refer Application Specific

Description: Application Specific

F8L1: 78 - Down Slow

Variable Units: Choice (0=off, 1=dn, 2-up, 3=up/dn)

Description: The configures the mode of the slow down feature. This parameter works with the variables F8L1:79 to F8L1:84 to configure the slow down feature.

0 = Slow down feature is disabled.

1 = Hoist will slow the system when moving down only.

2 = Hoist will slow the system when moving up only.

3 = Hoist will slow the system when moving up and down.

F8L1: 79 - Down Slow Part Loaded Weight Variable Units: Pounds

Description: This sets the number of pounds that the hoist needs to see to indicate that a part loaded on the fixture. This is specific to the Down Slow feature.

F8L1: 80 - Down Slow Height Loaded Variable Units: Inches

Description: This sets the height that the hoist will start to run at a reduced speed when the part loaded is turned on. The home position with the hoist completely raised is zero and this parameter is the number of inches down from home position.

F8L1: 81 - Down Slow Speed Loaded

Variable Units: Inches per second

Description: This sets the slow speed that the hoist runs when the part loaded is turned on and it is below the down slow height loaded parameter.

F8L1: 82 - Down Slow Height Unloaded Variable Units: Inches

Description: This sets the height that the hoist will start to run at a reduced speed when the part loaded is turned off. The home position with the hoist completely raised is zero and this parameter is the number of inches down from home position.

F8L1: 83 - Down Slow Speed Unloaded Variable Units: Inches per second

Description: This sets the slow speed that the hoist runs when the part loaded is turned off and it is below the down slow height unloaded parameter.

F8L1: 84 - Down Slow Max Decel

Variable Units: Inches per second2

Description: This sets the deceleration when transitioning from the current speed to the down slow speed.

NOTE

Variables marked with a "**" should NOT be manipulated without the aid of a Knight representative, as it may have unintended consequences.

F8L2 Global Variable Array

This variable array stores advanced parameters that affect the performance of the hoist. These parameters should only be adjusted with the aid of a Knight representative.

F8L2: 00 - Nominal Capacity Variable Units: Pounds

Description: This displays the rated capacity of the hoist. It is purely text and will not change anything in the program.

**F8L2: 02 - Payout Mode

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

**F8L2: 05 - Gear Ratio

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 06 - Max Motor RPM Variable Units: RPM

Description: This configuration parameter sets the maximum motor rpm. The motor has a physical maximum of RPM of 5000.

F8L2: 07 - Lift LC Gain Variable Units: **Reserved for Internal Use Only

Description:**Reserved for Internal Use Only**

F8L2: 08 - Float LC Gain Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 09 - Lift Load Cell Bias Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 10 - Float Load Cell Bias Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

****F8L2: 11 - Reverse Motor Direction** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 12 - Absolute Encoder Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used as a switch in the code determining the encoder type which is either an absolute or incremental. If the system has an absolute encoder then the motor will remember its counts even after loosing power. If it is incremental it will power up with a new set of counts thus needing to be re-homed. To re-home with an incremental just raise the hoist until the ball stop triggers the limit switch up inside the hoist enclosure.

****F8L2: 13 - Max Velocity Following Error** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 14 - Chain Pitch Variable Units:Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 15 - Sprocket Size Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

****F8L2: 16 - Decel Rate on Fault** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 17 - Allow Down Full Speed Lift** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 18 - Allow Down Full Speed Float** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 20 - Enable Lift Mode Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to enable or disable lift mode.

F8L2: 21 - Max Load (Ib)(Including Fixture) Variable Units: Pounds

Description: This sets the maximum load that the Servo Hoist will lift, including the weight of the fixture.

Note: Parameter "F8L1:21 - Max Load (lb)" also restricts the maximum load. F8L1:21 must be set to a value less than or equal to the value of F8L2:21.

Additional Reference: Section 8 "Change Max Load Limit" procedure.

****F8L2: 22 - Up Stop Resume Bandwidth** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 23 - Down Stop Resume Bandwidth** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 24 - Up/Down Stop Resume Time** Variable Units: **Reserved for Internal Use Only** Description: **Reserved for Internal Use Only**

F8L2: 25 - Lift Max Speed Fudge Factor Variable Units: Factor

Description: This factor is multiplied by the lift max speed limit. A value of one is normal. Any value above one will increase the max speed and any value below one will reduce the max speed.

F8L2: 27 - Enable Impulse Limiting

Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to enable the impulse limiting code. When this code is enabled the hoist will sense an impulse in the load cell and slow the hoist to reduce the impact on the system. This prevents the sharp motion that would occur if a load is snagged while the lift is in motion. Instead of jerking the load off the ground, the hoist sense the impulse and slow to a controlled speed.

F8L2: 28 - Impulse Limit Max Speed after Impulse Variable Units: Inches per second

Description: This sets the speed that the hoist will slow to when impulse limiting is enabled and an impulse is detected.

F8L2: 29 - Impulse Limit Time to Limit Max Speed Variable Units: Seconds

Description: This sets the time that the slow speed will be active when impulse limiting is enabled and an impulse is detected.

F8L2: 30 - Enable Analog Handle

Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to enable the analog handle. The parameter is enabled for systems that have an inline or fixture handle.

**F8L2: 31 - Handle Filter Bandwidth

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 33 - Lift Mode Prop Accel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 34 - Lift Mode Prop Decel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 35 - Lift Command Limit Variable Units: Pounds

Description: This sets the maximum lift command that can be given to an analog handle without a fault. For example, if this parameter is set to 100lbs and a force of more than 100lbs is applied to the lift handle then the hoist will fault. A force of 100lbs would indicate the handle may be hung-up a fixed structure or damaged.

**F8L2: 36 - Lift Force Cancellation Gain

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 38 - Enable Digital Handle

Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to enable the digital handle. This parameter is enabled for systems that have a single speed or two speed pushbutton handle or a wireless transmitter pendant.

F8L2: 40 - Enable Float Mode

Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to enable or disable float mode.

F8L2: 41 - Float PB Dwell Time

Variable Units: Seconds

Description: This sets that amount of time that the blue button needs to be pressed before the hoist enters float mode.

F8L2: 45 - Float Max Speed Fudge Factor Variable Units: Factor

Description: This factor is multiplied by the float max speed limit. A value of one is normal. Any value above one will increase the max speed and any value below one will reduce the max speed.

F8L2: 53 - Float Mode Prop Accel Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

****F8L2: 54 - Float Mode Prop Decel** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 55 - Float Command Limit Variable Units: Pounds

Description: This sets the maximum float command that can be given to a load without a fault.

****F8L2: 60 - Float Prop Gain Fudge Factor** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 61 - Float Input Filter Fudge Factor** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 62 - Float Output Filter Fudge Factor** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

**F8L2: 63 - Float Force Filter Limiting Scale Factor

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 64 - Max Vel for Jerk Limitation** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 65 - Disable "Gear Unlock" code Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

**F8L2: 67 - Acmtr Enable

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 68 - Acmtr g's per Volt** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 70 - Disable Program Limits Variable Units: Boolean (1 = ON, 0 = OFF)

Description: This configuration parameter is used to disable the programming of the top and bottom limits from the green and blue pushbuttons. This feature may be disabled to prevent accidental programming of limits.

1 = Limit programming is disabled

0 = Limit programming is enabled

F8L2: 71 - Enable Stress Relief Logic Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 80 - Load Touch Bandwidth Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

F8L2: 81 - True Weight Filter Constant (2-pole) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

**F8L2: 85 - Active Damping Normal Filter Constant

Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 86 - Active Damping Gain (Sensitive) Variable Units: **Reserved for Internal Use Only Description: **Reserved for Internal Use Only**

****F8L2: 87 - High Freq Active Damping Gain** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 90 - Active Damping Min Gain - Lift** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 91 - Active Damping Min Gain - Float** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 92 - Active Damping Always On** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

F8L2: 93 - AD Ramp Down - Start Position (in) Variable Units: **Reserved for Internal Use Only

Description: **Reserved for Internal Use Only**

****F8L2: 94 - AD Ramp Down - Min Gain Position (in)** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

****F8L2: 95 - AD Ramp Down - Min Gain** Variable Units: **Reserved for Internal Use Only**

Description: **Reserved for Internal Use Only**

NOTE

Variables marked with a "**" should NOT be manipulated without the aid of a Knight representative, as it may have unintended consequences.

F8L3 Global Variable Array

This complete array is reserved for internal use.

THIS PAGE IS INTENTIONALLY LEFT BLANK

Allen-Bradley MP-Series Small Frame Brushless Servo Motor Installation Guide



Installation Instructions

MP-Series Small Frame Brushless Servo Motor

(Catalog Number MPL-A310, -A320, -A330, -A420, -A430, -A4520, -A4530, -A4540, -A4560, -A520, -A540, -A560, -A580, -B310, -B320, -B330, -B420, -B430, -B4520, -B4530, -B4540, -B4560, -B520, -B540, -B560, and -B580)

These *Installation Instructions* describe how to install the MP-Series motors with a frame size of 165mm or smaller. Use this document if you are responsible for installing these Allen-Bradley[®] MP-Series motor products. Please read all instructions before installing this motor.

For:	See Page
Receiving and Storage	2
Motor Catalog Number Identification	3
Before You Install the Motor	4
Using Shaft Seals	4
Using Couplings and Pulleys	5
Preventing Electrical Noise	6
Building and Installing Cables	7
Installing Your Motor	8
Changing Connector Orientation	9
Guidelines for Installation	11
Mounting Dimensions	13
Connector Data	15
Shaft Seal Kits	16
Cables and Connector Kits	17
Motor Load Force Ratings	18
Related Documentation	20

Receiving and Storage

The customer is responsible for inspecting the equipment before accepting the shipment from the freight company. Check the item(s) you receive against your purchase order. Notify the carrier of any shipping damage or missing items immediately.

You may store your motor in a clean and dry location within the following environmental conditions:

• storage temperature:	-30° to 70° C (-22° to 158° F)
• relative humidity:	5% to 95% non-condensing
• atmosphere:	non-corrosive

Environmental Ratings

The International Protection Code or IP Rating for environmental protection is:


• with a shaft seal: IP66 dust tight, heavy jet spray

The IP66 rating is roughly equivalent to a NEMA 35 (dust tight, drip tight).

Operational temperature range is:

• operating temperature: 0° to 40° C (32° to 104° F)





1 Not available on MPL-x5xx or larger (>165mm Frame Sizes)

3

Before You Install the Motor

- 1. Remove the motor carefully from its shipping container.
- 2. Visually inspect the motor for any damage.
- **3.** Examine the motor frame, front output shaft, and mounting pilot for any defects.
- 4. Notify the carrier of any shipping damage immediately.



Do not attempt to open and modify the motor beyond changing the connector orientation as described on page 9.

Only a qualified Allen-Bradley employee can service this type of motor.

Failure to observe these safety procedures could result in personal injury or damage to equipment.

Using Shaft Seals

An additional seal is required on the motor shaft near the motor front bearing, if the shaft is exposed to fluids or significant amounts of fine dust. This includes lubricating oil from a gearbox. An IP66 rating for the motor requires use of a shaft seal and environmentally sealed connectors/ cables. The additional seal is not recommended in applications where the motor shaft area is free of liquids or fine dust and a lower rating will suffice.

- Refer to *Environmental* Ratings on page 2 for a brief description of MP-Series motor IP rating.
- Refer to *Shaft Seal Kits* on page 16 to find the catalog numbers of seal kits available for your motor.
- Refer to *Motion Control Selection Guide* on page 20 to find environmentally sealed connectors and cables compatible with the MP-Series motors.

Using Couplings and Pulleys

Mechanical connections to the motor shaft, such as couplings and pulleys, require a torsionally rigid coupling or a reinforced timing belt. The high dynamic performance of servo motors can cause couplings, pulleys or belts to loosen or slip over time. A loose or slipping connection will cause system instability and may damage the motor shaft. All connections between the system and the servo motor shaft must be rigid to achieve acceptable response from the system. Periodically inspect connections to verify their rigidity.

When mounting couplings or pulleys to the motor shaft, ensure that the connections are properly aligned and that axial and radial loads are within the specifications of the motor. Refer to *Motor Load Force Ratings* on page 18 for guidelines to achieve 20,000 hours of motor bearing life.

ATTENTION



Damage may occur to the motor bearings and the feedback device if sharp impact to the shaft is applied during installation of couplings and pulleys. Damage to the feedback device may result by applying leverage from the motor mounting face to remove devices mounted on the motor shaft.

Do not strike the shaft, couplings, or pulleys with tools during installation or removal. Use a wheel puller applying pressure from the user end of the shaft to remove any friction fit or stuck device from the motor shaft.

Failure to observe these safety procedures could result in damage to the motor and its components.

Preventing Electrical Noise

ElectroMagnetic Interference (EMI), commonly called noise, may adversely impact motor performance by inducing stray signals. Effective techniques to counter EMI include filtering the AC power, shielding and separating signal carrying lines, and practicing good grounding techniques.

Effective AC power filtering can be achieved by using isolated AC power transformers or properly installed AC line filters.

To help avoid EMI:

- 1. Physically separate signal lines from motor cabling and power wiring. Do not route signal wires with motor and power wires, or over the vent openings of servo drives.
- 2. Ground all equipment using a single-point parallel ground system that employs ground bus bars or large straps. If necessary, use additional electrical noise reduction techniques to reduce EMI in noisy environments.

Refer to *System Design for Control of Electrical Noise Reference Manual* on page 20 for additional information on reducing the effects of EMI by improving the system level electromagnetic compatibility (EMC).

Building and Installing Cables

Knowledgeable cable routing and careful cable construction improves system electromagnetic compatibility (EMC).

To build and install cables, perform the following steps:

- 1. Keep wire lengths as short as physically possible.
- 2. Route signal cables (encoder, serial, analog) away from motor and power wiring.
- 3. Separate cables by 0.3 m (1 ft) minimum for every 9 m (30 ft) of parallel run.
- **4.** Ground both ends of the encoder cable shield and twist the signal wire pairs to prevent electromagnetic interference (EMI) from other equipment.



High voltage can be present on the shield of a power cable, if the shield is not grounded.



Ensure there is a connection to ground for any power cable shield.

Failure to observe these safety procedures could result in personal injury or damage to equipment.

Installing Your Motor

All motors include a mounting pilot for aligning the motor on a machine. Preferred fasteners are stainless steel. The installation must comply with all local regulations and use of equipment and installation practices that promote electromagnetic compatibility and safety.



Unmounted motors, disconnected mechanical couplings, loose shaft keys, and disconnected cables are dangerous if power is applied.

Disassembled equipment should be appropriately identified (tagged-out) and access to electrical power restricted (locked-out).

Before applying power to the motor, remove the shaft key and other mechanical couplings which could be thrown from the shaft.

Failure to observe these safety procedures could result in personal injury.

ATTENTION



Ensure that cables are installed and restrained to prevent uneven tension or flexing at the cable connectors.

Excessive and uneven lateral force at the cable connectors may result in the connector's environmental seal opening and closing as the cable flexes.

Failure to observe these safety procedures could result in damage to the motor and its components.

Changing Connector Orientation

The connector housing can be rotated to face down when the motor is installed in a vertical application, or rearward if connector access is restricted in a horizontal application. To rotate the connector housing:

- 1. Remove the three connector housing screws from the motor.
- **2.** Rotate connector housing 180 degrees. If binding of the wire bundles prevents rotation of the connector, you can gain access to the internal motor wiring by:
 - A. Remove the four screws from the rear cover of the motor.
 - **B.** Carefully reposition the wires around the perimeter of the motor feedback device located under the rear cover.
 - C. Ensure that wires are not close to any rotating parts.

ATTENTION



Do not loosen or remove the motor feedback device (encoder) mounting screws while repositioning the connector wires.

Encoder alignment is a critical adjustment that can only be performed in the factory. Misadjustment can render the motor inoperable or degrade motor performance, and voids the motor warranty.

Failure to observe this safety precaution could result in personal injury or damage to equipment.

3. Re-install the connector housing and torque the three screws to 0.8–1.0 Nm (7– 9 in.-lbs) after verifying that gaskets are properly positioned, and that no wires are pinched under the connector housing.



Exercise caution to prevent damaging the screw holes when reinserting the self-tapping screws holding the connector housing and rear cover.

Excessive force may strip the threads within the screw holes and prevent proper sealing of the motor. Ensure that the specified torque values are not exceeded.

Failure to observe these safety procedures could result in damage to the motor and its components.

4. Re-install the four rear cover screws and torque them to 0.8–1.0 Nm (7–9 in.-lbs) after ensuring that the rear cover O-ring is properly positioned onto the rear cover circular pilot surface.

Guidelines for Installation

Observe the following guidelines when installing the motor.



Damage may occur to the motor bearings and the feedback device if sharp impact to the shaft is applied during installation of couplings and pulleys. Do not strike the shaft, couplings, or pulleys with tools during installation or removal.

Failure to observe these safety procedures could result in damage to the motor and its components.

1. Allow sufficient clearances in the area of the motor for it to stay within its specified operating temperature range. Refer to *Receiving and Storage* on page 2 for the operating range. Do not enclose the motor unless forced air is blown across the motor for cooling. A fan blowing air across the motor will improve its performance. Keep other heat producing devices away from the motor.

To obtain the specified motor thermal rating, mount the motor on a surface with heat dissipation equivalent to a $12 \times 12 \times 0.5$ inch aluminum heatsink.

- 2. Refer to *Motor Load Force* Ratings on page 18 to determine the radial and axial shaft load limitations of your motor.
- 3. Place the motor with the connector housing pointing downward.
- 4. Properly mount and align the motor. Electronic zero (Index pulse or Stegmann ABS = 0) occurs when the shaft key or dimple is aligned with the connectors. Refer to *Mounting Dimensions* on page 13 for a visual reference of this alignment.

5. Attach all power, feedback, and brake cables after the motor is mounted and use a drip loop in the cable to keep liquids flowing away from the connectors.



Outer surfaces of motor can reach high temperatures, 125° C (275° F) during motor operation.

Take precautions to prevent accidental contact with hot surfaces. Consider motor surface temperature when selecting motor mating connections and cables.

Failure to observe these safety procedures could result in personal injury or damage to equipment.

Mounting Dimensions

Motors are designed to metric dimensions (mm), inch dimensions (in.) are conversions




Figure 1 References for Motor Dimensions

Motor	AD	* D	모	L ^{1, 2}	L-LB ³	Γ	LB ^{1, 2}	LD ¹	Σ	* 2	Ь	S ⁴	F	F 5	GE ⁶	End of Shaft
MPL-A or MPL-B MPL-B	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	Thread and Depth of Hole
310				164.7 (6.49)			124.7 (4.91)	70.7 (2.78)								
320	80.9 (3.19)	16.0 (0.629)	125.7 (4.95)	190.1 (7.49)	40.0 (1.58)	9.9 (0.39)	150.1 (5.91)	96.1 (3.78)	100.0 (3.937)	80.0 (3.15)	89.4 (3.52)	7.0 (0.28)	2.87 (0.113)	5.0 (0.20)	3.0 (0.12)	M5 x 0.8 x 12.5 (0.49)
330				215.5 (8.49)			175.5 (6.91)	121.5 (4.78)								
420	83.9	19.0	132.8	186.5 (7.35)	40.0	10.2	146.5 (5.77)	92.5 (3.64)	115.0	95.0	98.3	10.0	2.87	0.9	3.5	M6 x 1.0 x
430	(3.3)	(0.748)		211.9 (8.35)		(0.4)	171.9 (6.77)	117.9 (4.64)	(4.528)	(3.74)	(3.87)	(0.41)	(0.113)	(0.20)	(0.14)	16 (0.63)
4520				199.8 (7.87)			149.8 (5.90)	95.8 (3.77)								
4530	91.5	24.0	148.3	225.2 (8.87)	50.0	12.2	175.2 (6.90)	121.2 (4.77)	130.0	110.0	113.7	10.0	3.38	8.0	4.0	M8 x 1.25 x
4540	(3.6)			250.6 (9.87)	(1.97)	(0.48)	200.6 (7.90)	146.6 (5.77)	(5.118)	(4.331)		(0.41)	(0.133)	(0.31)	(0.158)	19 (0.75)
4560				301.5 (11.87)			251.5 (9.90)	197.4 (7.77)								
520				233.7 (9.20)			173.7 (6.84)	115.8 (4.56)								
540	106.2	28.0 (1.1)	178.1	284.5 (11.20)	60.0 (2.38)	13.97	224.5 (8.84)	166.9 (6.57)	165.0	130.0	143.5	12.0	3.38	8.0 (0.31)	4.1 (0.162)	M10 x 1.5-6H x 22 (0.87)
560	(4.18)		(7.01)	335.3 (13.20)		(0.55)	275.3 (10.84)	217.7 (8.56)	(6.496)	(5.118)	(5.65)	(0.48)	(0.133)			
580		32.0 (1.26)		406.1 (15.99)	80.0 (3.15)		326.1 (12.84)	268.5 (10.57)						10.0 (0.39)	5.1 (0.20)	M12 x 1.75-6H x 28 (1.10)
	with bral 10 throuç 20 throuç 20 throug with hich	Motors with brake, add this value to the dimension: MPL-x310 through -x330: add 34.5 mm (1.36 in.) to L, LB, and LD. MPL-x420 through -x4560: add 48.5 mm (1.91 in.) to L, LB, and LD. MPL-x520 through -x580 add 51.6 mm (2.03 in.) to L and LB, and 45.6 mr Motors with hich-resolution feedback add 3.3 mm (0.13 in.) to L and LB	i value to dd 34.5 mi add 48.5 n d 51.6 mn	the dimens m (1.36 in.) nm (1.91 ir n (2.03 in.)	sion:) to L, LB, a) to L, LB, to L and LE mm (0 13 ir	nd LD. and LD. 3, and 45.	nd LD. and LD. , and 45.6 mm (1.79 in.) to LD.	9 in.) to LE	Ċ	3 Tole 4 Tole 5 Tole 6 Tole	rance for t rance for t rance for t rance for t	this dimer this dimer this dimen this dimer	Tolerance for this dimension is ± 0.7 (± 0.028). Tolerance for this dimension is ± 0.36 (± 0.007) Tolerance for this dimension is ± 0.03 (± 0.001). Tolerance for this dimension is ± 0.1 (± 0.004).	7 (±0.028) 36 (±0.007 33 (-0.001) 1 (+0.004)		
* Refer to	Motion	Refer to Motion Control Selection Guide (referenced on par	ection Gu	ide (refere	nced on pa	ige 20) for	tolerance	s on these	ge 20) for tolerances on these measurements.	nents.						


Publication MP-IN001E-EN-P — August 2004

Connector Data

The tables below list the signal descriptions for the feedback, power, and brake connector pins.


Feed	back Connec	ctor		
			High Resolution	Encoder for:
	2000 Line	2 Pole	MPL-A3xx	MPL-A5xx, and
Pin	Encoder	Resolver	through -A45xx	all MPL-B (460V)
A	A+	S2	Sin+	Sin+
В	A-	S4	Sin-	Sin-
С	B+	S1	Cos+	Cos+
D	В-	S3	Cos-	Cos-
E	+	Reserved	Data+	Data+
F	-		Data-	Data-
G	Ground	R1	Reserved	Reserved
Η	ABS	R2		
J	Reserved	Reserved		
К	+5 VDC		+5 VDC	
L	Common		Common	
Μ	Reserved		Reserved	
Ν	-			+9 VDC
Р	_			Common
R	TS+	TS+	TS+	TS+
S	TS-	TS-	TS-	TS-
T	S1	Reserved	Reserved	Reserved
U	S2			
V	S3			

Powe	er Connector
Pin	Signal
А	Phase U
В	Phase V
С	Phase W
D	Ground




ITT Cannon TNM 16-4, 192993-0106

Brak	ce Connector
Pin	Signal
А	BR+
В	Reserved
С	BR-
D	Reserved



ITT Cannon TNM 10-4, 192993-0116



ITT Cannon TNM 16-19, 192993-0110

Shaft Seal Kits

Motor	Catalog Number ¹	Inside Diame		Outsid Diame	-	Widt	h
	5	mm	(in.)	mm	(in.)	mm	(in.)
MPL-A310 and -B310	MPL-SSN-A3B3	17	(0.669)	47	(1.850)	7	(0.276)
MPL-A320 and -B320							
MPL-A330 and -B330							
MPL-A420 and -B420	MPL-SSN-A4B4	20	(0.787)	52	(2.047)	7	(0.276)
MPL-A430 and -B430							
MPL-A4520 and -B4520	MPL-SSN-A5B5	25	(0.984)	62	(2.441)	7	(0.276)
MPL-A4530 and -B4530							
MPL-A4540 and -B4540							
MPL-A4560 and -B4560							
MPL-A520, B520, A540, A560 and B560	MPL-SSN-F165	30	(1.181)	72	(2.835)	8	(0.315)
MPL-A580 or B580	MPL-SSN-F165-32MM	35	(1.378)	72	(2.835)	8	(0.315)

Catalog numbers and dimensions for Nitrile shaft seals are shown below.

 1 Nitrile shaft seals require a lubricant to reduce wear. Lubricant is provided with kit.


Cables and Connector Kits


Factory manufactured feedback and power cables are available in standard cable lengths. They can provide environmental sealing and shield termination. Contact your nearest Allen-Bradley sales office or refer to your drive's installation manual for a complete listing of available cables.

If you choose to build your own cables, the following connector kits are available for MP-Series Small Frame motors. These solder-type connectors mate with the motor-mounted connectors and provide environmental sealing with shield termination.

Each connector kit includes the requisite number and size of solder-type contact pins, a connector housing, and a connector backshell. As an example, finished and exploded views of the Brake Connector Kit are shown below.

Catalog	Connector	Accepts Wire Gaug	je	Accepts Cable Diamet	ter Gauge
Number	Туре	mm ²	(AWG)	mm	(in.)
2090-MPPC-S	Power - Straight	2.5-4.0	(14-12)	7.9-12.4	(0.31-0.49)
2090-MPFC-S	Feedback - Straight	0.08-2.5	(28-14)		
2090-MPBC-S	Brake - Straight			4.3-7.4	(0.17-0.29)






Motor Load Force Ratings

Motors are capable of operating with a sustained shaft load. The radial and axial load force location is shown in the figure, and maximum values are in the tables.

Figure 2 Load Forces on Shaft



The following tables represent 20,000 hour L10 bearing fatigue life at various loads and speeds. This 20,000 hour life does not account for possible application-specific life reduction that may occur due to bearing grease contamination from external sources.

Radial Load Force Ratings

Motor	500	rpm	1000) rpm	2000) rpm	3000) rpm	350) rpm	400	0 rpm	500	0 rpm
Ινιοιοι	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)
MPL-A/B310	78	(171)	62	(136)	49	(108)	—	_	40	(89)	—	_	36	(79)
MPL-A/B320	87	(192)	69	(152)	55	(121)	_	_	45	(100)	—	_	40	(89)
MPL-A/B330	-	_	74	(163)	59	(129)	—	_	49	(107)	—	_	43	(95)
MPL-A/B420	-	_	78	(172)	62	(136)	—	_	51	(113)	—	_	45	(100)
MPL-A/B430	106	(234)	84	(186)	67	(148)	—	_	55	(122)	—	_	49	(109)
MPL-A/B4520	-	_	97	(213)	77	(169)	67	(147)	64	(140)	61	(134)	56	(124)
MPL-A/B4530	133	(292)	105	(232)	84	(184)	73	(161)	_		66	(146)	_	_
MPL-A/B4540	140	(309)	111	(245)	89	(195)	77	(170)	—	_	—	_	_	_
MPL-A/B4560	151	(332)	119	(263)	95	(209)	83	(183)	_	_	—	_	_	
MPL-A/B520	-	_	127	(280)	100	(222)	88	(194)	_		80	(176)	_	_
MPL-A/B540	-	_	143	(316)	114	(251)	99	(219)	—	_	90	(199)	_	
MPL-A/B560	-	_	153	(338)	121	(268)	106	(234)	—	_	—	_	_	
MPL-A/B580		_	153	(338)	121	(268)	106	(234)	—	_	-	_	—	

Motor	500	rpm	100	0 rpm	200	0 rpm	300	0 rpm	3500) rpm	4000	0 rpm	500) rpm
	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)	kg	(lb)
MPL-A/B310	30	(66)	23	(50)	16	(36)	_	_	13	(29)	-	_	11	(24)
MPL-A/B320	34	(74)	25	(56)	19	(41)	—	_	15	(32)	-	_	13	(28)
MPL-A/B330	-	—	27	(59)	20	(44)	_	_	16	(35)	-	—	13	(29)
MPL-A/B420	-	—	36	(80)	27	(59)	-	_	21	(47)	-	_	18	(39)
MPL-A/B430	52	(115)	39	(86)	29	(63)	—	—	22	(49)	—	—	19	(42)
MPL-A/B4520	-	_	31	(68)	23	(50)	19	(42)	18	(39)	17	(37)	15	(33)
MPL-A/B4530	45	(100)	34	(74)	25	(55)	21	(46)	-	_	19	(41)	—	_
MPL-A/B4540	49	(107)	36	(80)	27	(59)	22	(49)	-	_	-	_	—	_
MPL-A/B4560	53	(117)	40	(88)	30	(65)	24	(53)	-	_	-	—	—	—
MPL-A/B520	-	_	42	(94)	30	(68)	26	(58)	-	_	22	(50)	—	_
MPL-A/B540	_	_	48	(107)	35	(79)	30	(66)	_	_	26	(58)	_	_
MPL-A/B560	—	_	52	(115)	43	(95)	32	(71)	_	_	_	_	_	_
MPL-A/B580	_	_	52	(115)	43	(95)	32	(71)	_	_	_	_	_	_

Axial Load Force Ratings (Maximum Radial Load)

Axial Load Force Ratings (Zero Radial Load)

Motor	500	rpm	100	0 rpm	200	0 rpm	300	0 rpm	350) rpm	400	0 rpm	500) rpm
Ινιοιοι	kg	(lb)												
MPL-A/B310	49	(109)	36	(80)	27	(59)	—		21	(47)	_	_	18	(40)
MPL-A/B320	49	(109)	36	(80)	27	(59)	—		21	(47)	_	_	18	(40)
MPL-A/B330	-		36	(80)	27	(59)	—	_	21	(47)	_	_	18	(40)
MPL-A/B420	_		51	(112)	38	(83)	_		30	(65)	_	_	25	(55)
MPL-A/B430	69	(152)	51	(112)	38	(83)	_		30	(65)	_	_	25	(55)
MPL-A/B4520	-	_	51	(112)	38	(83)	31	(69)	30	(65)	28	(61)	25	(55)
MPL-A/B4530	69	(152)	51	(112)	38	(83)	31	(69)	-	_	28	(61)	—	_
MPL-A/B4540	69	(152)	51	(112)	38	(83)	31	(69)	—	_	_	_	—	_
MPL-A/B4560	69	(152)	51	(112)	38	(83)	31	(69)	-	_	_	_	—	_
MPL-A/B520	_		67	(149)	49	(109)	41	(92)	_	_	36	(81)	—	_
MPL-A/B540	-		67	(149)	49	(109)	41	(92)	—		36	(81)	_	_
MPL-A/B560	-	_	67	(149)	49	(109)	41	(92)	-	_	—	_	—	_
MPL-A/B580	-	_	67	(149)	49	(109)	41	(92)	_	_	—	_	—	—

Related Documentation

These publications provide additional information, and specifically about MP-Series motors and compatible drives.

To order printed copies, contact your Allen-Bradley Distributor or Rockwell Automation Sales Office. To view and download, go to Literature Library at http://www.rockwellautomation.com/literature.

For information about:	Read this document:	Publication Number
Installing large frame (≥215 mm) MP-Series low inertia motors	MP-Series Brushless Servo Motor Installation Manual	MP-IN002 <i>x</i> -EN-P
Installing MP-Series integrated gear motors	MP-Series Integrated Gear Motor Installation Manual	MP-IN003 <i>x</i> -EN-P
Connecting to an Ultra5000 [™] drive	Ultra5000 IPD Install Manual	2098-IN001 <i>x</i> -EN-P
Connecting to an Ultra3000 [™] drive	Ultra3000 DSD Install Manual	2098-IN003 <i>x</i> -EN-P
Connecting to an Kinetix™ 6000 drive	Kinetix 6000 Multi-Axis Servo Drive Installation Manual	2094-IN001x-EN-P
Connecting to an 1394 SERCOS™ drive	1394 SERCOS Interface™ Installation Manual	1394-IN002x-EN-P
A glossary of industrial automation terms and abbreviations	Allen-Bradley Industrial Automation Glossary	AG-7.1
How to minimize and control system-level noise.	<i>System Design for Control of Electrical Noise Reference Manual</i>	GMC-RM001x-EN-P
An overview of Allen-Bradley motion controls and systems, including information about MP-Series motors.	Motion Control Selection Guide	GMC-SG001 <i>x</i> -EN-P or GMC-SG002 <i>x</i> -EN-E

For more information refer to our web site: www.ab.com/motion

For Allen-Bradley Technical Support information refer to: www.ab.com/support or Tel: (1) 440.646.5800

Allen-Bradley is a registered trademark of Rockwell Automation, Inc. Kinetix, Ultra3000 and Ultra5000 are trademarks of Rockwell Automation, Inc.

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640 Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433 Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 1774 Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

Publication MP-IN001E-EN-P — August 2004

Supersedes MP-IN001D-EN-P — Aug 2001 and MP-RN001D-EN-P — Nov 2001

PN 0013-2068-001 Rev 01

Copyright © 2004 Rockwell Automation, Inc.. All rights reserved. Printed in the USA.

THIS PAGE IS INTENTIONALLY LEFT BLANK

THIS PAGE IS INTENTIONALLY LEFT BLANK



KNIGHT INDUSTRIES & ASSOCIATES INC 1140 Centre Road Auburn Hills, MI 48326 Phone 248-377-4950 Fax 248-377-2135 For additional copies\literature contact: sales@knight-ind.com For service related requests contact: services@knight-ind.com www.knight-ind.com