



# KNIGHT GLOBAL

## E-Tractor

### Operation, Installation, and Maintenance Manual



THIS MANUAL CONTAINS IMPORTANT INFORMATION REGARDING INSTALLATION, SAFETY, MAINTENANCE, AND OPERATION OF KNIGHT GLOBAL E-TRACTOR AND SHOULD BE AVAILABLE TO ALL PERSONNEL RESPONSIBLE FOR USING THE E-TRACTOR.

Rev: 010-202102

## Warranty

Knight warrants that its products and parts shall meet all applicable specifications, performance requirements, and be free from defects in material and workmanship for one year, (Servo Systems for two years), from the date of invoice, unless otherwise noted. One exclusion would include any purchased components not manufactured by Knight and their specific individual warranties. Paint defects, scratches and marring from shipping are also excluded.

This warranty shall not cover failure or defective operation caused by inadequate training provided by customer regarding the operation and / or maintenance of the tool, misuse, negligence, misadjustment, or alteration not approved by Knight. Knight's obligation is limited to the replacement or repair of Knight's products at a location designated by Knight. Buyer is responsible for all associated internal removal and reinstallation costs as well as freight charges to and from Knight Global. Knight's maximum liability shall not in any case exceed the contract price for the products claimed to be defective.

On a design & build job, the customer is the owner of the equipment once they authorize shipment. The equipment cannot be returned for reimbursement or credit.

Knight warranties servo hoists, servo balancers, and servo tractors to be free from defects in material or workmanship for a period of two years or 6000 hours use from date of shipment.

Knight distributors/agents are not authorized to circumvent any of the terms and conditions of this warranty unless approved in writing by Knight Management. Statements made by Knight distributors/agents do not constitute warranties.

Unauthorized changes to any of Knight's products voids our performance warranty and any potential liabilities. If changes are necessary, please contact Knight for authorization to continue.

Disclaimers: OTHER THAN AS SET FORTH HEREIN, NO OTHER EXPRESS WARRANTIES, AND NO IMPLIED WARRANTIES, ORAL AND WRITTEN, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE MADE BY KNIGHT WITH RESPECT TO ITS PRODUCTS AND ALL SUCH WARRANTIES ARE HEREBY SPECIFICALLY DISCLAIMED. KNIGHT SHALL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY INCIDENTAL, SPECIAL AND/OR CONSEQUENTIAL DAMAGES WHATSOEVER, WHETHER OR NOT FORESEEABLE, INCLUDING BUT NOT LIMITED TO DAMAGES FOR LOST PROFITS AND ALL SUCH INCIDENTAL, SPECIAL AND / OR CONSEQUENTIAL DAMAGES ARE HEREBY ALSO SPECIFICALLY DISCLAIMED.

### **A. VISIBLE LOSS OR DAMAGE**

If any of the goods called for on the bill of lading or express receipt are damaged, or the quantity is short, do not accept them until the freight or express agent makes an appropriate notation on your freight bill or express receipt.

### **B. CONCEALED LOSS OR DAMAGE**

When a shipment has been delivered to you in an apparent good condition, but upon opening the crate or container, loss or damage has taken place while in transit, notify the transportation company immediately.

### **C. DAMAGE CLAIMS**

You must file claims for damage with the carrier. It is the responsibility of the transportation company to reimburse you for repair or replacement of goods damaged in shipment. Claims for loss or damage in shipment must not be deducted from the Knight Global invoice, nor should payment of Knight Global invoice be withheld awaiting adjustment of such claims as the carrier guarantees safe delivery. Products damaged in shipment must be returned to us for repair, services will be charged to your account and these charges will form the basis for claim against the carrier.

Every effort has been made to provide complete and accurate product information in this manual. However, due to product improvements and changes, discrepancies and omissions may be present. It is the responsibility of the end user to exercise common sense and judgment when performing the tasks described in this manual. If any procedure seems inaccurate, incomplete or unsafe please put the equipment in a safe condition and contact Knight Global service department for assistance.



Safety	
Safety .....	1
Warning, Caution and Note .....	1
General Safety Precautions .....	1
Safety Devices .....	2
Run/Stop Push Button .....	2
Introduction	
Introduction .....	3
E-Tractor Callouts .....	3
Models and Specifications .....	4
Installation	
Installation .....	5
E-Tractor Installation .....	6
Drive Wheel Adjustment .....	7
Tow Bar to E-Tractor Drive Connection .....	8
Power Supply to E-Tractor .....	8
Unidrive M Connect .....	9
Connecting to a Knight E-Tractor .....	9
Accessing an Online Drive .....	17
Saving a Parameter File .....	19
Restoring a Parameter File .....	23
Adjusting Frequency References and Frequency Ramps .....	28
Operation	
Run/Stop .....	36
Shut Down .....	36
Start Up .....	36
Over Travel Limit Switches .....	36
Fault Mode .....	36
Maintenance	
Preventive Maintenance .....	37
Inspection Overview .....	37
Frequent Inspections .....	38
Periodic Inspections .....	38
Pendant Cable Replacement .....	39
Troubleshooting	
Troubleshooting Chart .....	40
Schematics	
M400KETD3K01 Drawing Package .....	41
Programming Parameters	
Program Parameters .....	42
Excerpts from Unidrive M400 User Guide: Issue 4	
Chapters 5, 6, and 13 .....	43
Excerpts from PowerFlex 520 series User Guide	
Chapters 2 and 3 .....	77



## Safety

This manual provides important information for all personnel involved in the installation, operation and maintenance of the Knight Global E-Tractor. Even if you feel that you are familiar with this or similar equipment, you should read and understand this manual before performing any of the tasks.

Knight Global recognizes that most companies have a safety program in place at their facility. The Safety Section, Notes, Cautions and Warnings in this manual are intended to supplement and not supersede any existing plant or company safety guidelines or regulations.

Knight Global cannot be aware of or provide for all the procedures by which the E-Tractor operations or repairs may be conducted and the hazards which may result from each method. If operation or maintenance not specifically recommended by Knight Global is conducted, it must be ensured that product or personnel safety is not endangered by these actions. If not sure of an operation or maintenance procedure or step, personnel should place the E-Tractor in a safe condition and contact a supervisor and/or Knight Global service department for technical support.

Modifications to upgrade, re-rate or otherwise alter this equipment shall be authorized only by the original equipment manufacturer.

If a below-the-hook lifting device or sling is used with the E-Tractor, refer to ANSI/ASME B30.9, "Safety Standard for Slings" or ANSI/ASME B30.20, "Safety Standard for Below-the-Hook Lifting Devices".

Electrical equipment described in this manual are designed and built-in compliance with ANSI/NFPA 70, "National Electrical Code". It is the responsibility of the system designer, system manufacturer, crane or rail manufacturer, installer and user to ensure that the installation and associated wiring of the E-Tractor and components is in compliance with ANSI/NFPA 70, and all applicable Federal, State and Local Codes.

Hazardous voltages are present in the E-Tractor and components. Only properly trained and component personnel should perform inspections or repairs on the E-Tractor or accessories.

Prior to performing any maintenance (mechanical or electrical) on the E-Tractor de-energize (disconnect) the main switch supplying power to the E-Tractor. Lock out the power supply following standard plant procedures. Ensuring that the installation, inspection, testing maintenance and operation is compliance with ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, National Electric Code and ANSI/ASME B30 (if installed as part of an overhead crane system) is the responsibility of the owner/operator. All personnel that will install, operate, inspect, test or maintain the tractor should read this manual and be familiar with all applicable portions of ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, "National Electric Code" and ANSI/ASME B30 (if installed as part of an overhead crane system).

If clarification of any information in this manual or additional information is required contact Knight Global. Do not install, operate, inspect, test or maintain the tractor unless all information is understood. Ensuring that the installation, inspection, testing maintenance and operation is compliance with ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, National Electric Code and ANSI/ASME B30 (if installed as part of an overhead crane system) is the responsibility of the owner/operator.

All personnel that will install, operate, inspect, test or maintain the tractor should read this manual and be familiar with all applicable portions of ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations ANSI/NFPA 70, "National Electric Code" and ANSI/ASME B30 (if installed as part of an overhead crane system).




If clarification of any information in this manual or additional information is required contact Knight Global. Do not install, operate, inspect, test or maintain the tractor unless all information is understood.



This manual provides important information for all personnel involved in the installation, operation and maintenance of the Knight Global Lift Assist system. All personnel must read this document before operating the equipment.

It is the responsibility of the end user to exercise common sense and judgment when performing the tasks described in this manual. If any procedure seems inaccurate, incomplete or unsafe please put the equipment in a safe condition and contact Knight Global service department for assistance.

Throughout this manual there are steps and procedures that if not performed correctly can result in personal injury or equipment damage. The following signal words are used to identify the level of potential hazard.

	<p><b>WARNING</b></p> <p>Indicates a hazard which will cause severe injury, death or substantial equipment damage.</p>
	<p><b>CAUTION</b></p> <p>Indicates a hazard which can or will cause injury or equipment damage.</p>
	<p><b>NOTE</b></p> <p>Notifies personnel of installation, operation or maintenance information which is important but not hazard related.</p>

## **General Safety Precautions**

Safe operating instructions are provided to make the operator aware of hazards to avoid and are not necessarily limited to the following list:

- Do not operate the E-Tractor before reading this technical manual.
- Allow only personnel trained in safety and operation of this E-Tractor to operate the E-Tractor.
- If the E-Tractor is locked out or a "DO NOT OPERATE" sign is on the E-Tractor or controls do not operate the E-Tractor until the lock or sign is removed by designated personnel.
- Before each shift or prior to use inspect the E-Tractor in accordance with the procedures defined in the maintenance section of this manual.
- Pay attention to the load all times when operating the E-Tractor.
- Ensure no personnel are in the path of the load.
- Do not move a load over personnel.
- Never use a E-Tractor for moving people or livestock.
- Do not allow anyone to stand under a suspended load.
- Avoid collisions or bumping of the E-Tractor.
- Do not operate E-Tractor when damaged or malfunctioning.

## **RUN/STOP Push Button**

If an operator needs to shut down the system immediately, the operator pushes the Run/Stop button. The system will not function until it is reset. To reset the system from the run/stop condition, the operator turns the button clockwise to release it from the down position. All over travel limits and parameters remain intact.



## Introduction




Figure 2

### E-Tractor Callout's (Refer to Figure 2)





- |   |  |
|---|--|
| 1. DRIVE, VFD, Unidrive M400, .5HP, 240V-4A<br>or DRIVE, VFD, PowerFlex 525, .5HP, 480VAC | 16. 1.5mm <sup>2</sup> , 4-COND, FLEX, ORG CABLE |
| 2. MOTOR, 1/2 HP, 1750RPM, 240V   | 17. 3/4NPT STEEL LOCK NUT                        |
| 3. GEARBOX  | 18. 3/4NPT CRDGRP (.312-.437)                    |
| 4. 24VDC RELAY  | 19. LOCKING PLUG (M) 15A 250V                    |
| 5. BASE FOR 700-HB RELAY  | 20. LOCKING CONN (F) 15A 250V                    |
| 6. POWER SUPPLY 24VDC 60W   | 21. STRAIN RELIEF FLEXCOR, 3/4"                  |
| 7. KEYPAD   | 22. ADAPTOR, RS485 COM, M200-400                 |
| 8. TERMINAL BLOCK   | 23. RELAY, 1NO-1NC, 24VDC COIL                   |
| 9. CENTER JUMPERS   | 26. END PLATE                                    |
| 10. END PLATE   | 27. TERMINAL BLOCK                               |
| 11. END ANCHOR  | 31. SWITCH, LIMIT, 1NO/1NC, M12                  |
| 12. TERMINAL GROUND   | 32. SWITCH, ROLLER, STEEL                        |
| 13. DIN RAIL STEEL  | 33. SWITCH, LIMIT, HEAD                          |
| 14. CABLE, 14G, 3C, SOOW, 600V, BLK   | 34. CORD SET, 4-PIN, MICRO, M/F                  |
| 15. RECEPT, PANEL, FEMALE, 8-PIN  | 35. RECEPTACLE, 4-PIN, MIC, FEMALE               |



## Models and Specifications

RAD4110 Rail Series

RAD7510 Rail Series



### EXAMPLE:

ORDER # : KET37122DC

1. SYSTEM CONFIGURATION  
VARIABLE SPEED TRACTOR = KET

2. LOAD CAPACITY  
3 = 3000 lbs [1360kg]

3. RAIL STYLE TRACTOR TO BE USED ON  
KNIGHT RAD4110 = 4  
KNIGHT RAD7510 = 7  
SPECIAL RAIL = S (SPECIFY)

4. MAXIMUM SPEED UNLOADED IN FPM  
090 FPM = 09  
120 FPM = 12  
180 FPM = 18  
SPECIAL FPM = S (SPECIFY)

5. PENDANT  
1 SPEED = 1  
2 SPEED = 2  
SPECIAL = S (SPECIFY)

6. OPTIONAL ACCESSORIES  
DC = DRIVE CLUTCH  
TL = TRAVEL LIMITS  
RH = RETURN TO HOME  
SA = SHOCK ABSORBER ASSEMBLY

MODEL #					
KET	X	X	XX	X	X


### Optional Accessories


Accessory	Part #	Description
Shock Absorber Assemblies	VFDTA1003	Used on applications where the tractor will frequently contact the end of the rail or mid rail stop.
Travel Limits	VFDTA1005	Used to limit tractor travel within a predetermined work area.
Return to Home	VFDTA1006	Allows the tractor to return to Home position automatically.
Electrical Disconnect Box	EBA1003	Steps down electrical feed from 480v to 230v.



## Installation

Prior to installation, visually inspect the E-Tractor for signs of damage.

	<p style="text-align: center;"><b>CAUTION</b></p> <p>Prior to placing this unit into service, the owners and user are advised to examine specific local and/or other regulations, including ANSI and OSHA regulations that may apply to the use of this product.</p>
---	--

	<p style="text-align: center;"><b>WARNING</b></p> <p>A moving load can cause injury or death. Before installing this E-Tractor read the “<b>Safety</b>” section of this manual.</p>
---	---

Follow all procedures in this section for installation and set-up of the E-Tractor.

Retain all product information supplied with the E-Tractor for future reference.

Ensure that the supporting structure is able to support the weight of the system and load. The structure should be able to support 300 percent of the combined weight of the E-Tractor and load. Do not use a supporting structure that tilts the E-Tractor to one side or the other.

For safe and proper installation into a rail system, refer to the installation manual provided by the rail system manufacturer.

When installation is complete and prior to placing the E-Tractor into operation, inspect the E-Tractor following the “Periodic Inspection” procedure on page 11 of the “Maintenance” section.







## E-Tractor Installation

Prior to installation visually inspect the tractor for signs of damage or missing parts.


1. Remove end cap on rail system or open inspection gate.

	<b>NOTE</b>
	Ensure that drive wheel engagement handle is in the up position. (Disengaged) (Refer to Figure 3).

2. Slide trolley into enclosed rail system. (Refer to Figure 5)

	<b>NOTE</b>
	Ensure that the (3) hole pattern is facing towards tow bar. (Refer to Figure 4).

3. Once E-tractor is fully inserted within the rail system, replace end cap or close inspection gate.

	<b>NOTE</b>
	Ensure that drive wheel engagement handle is in the down position. (Engaged). (Refer to Figure 5)




Figure 3



Figure 4




Figure 5

Drive Wheel Adjustment:

1. Ensure that the drive wheel is engaged and handle is in full down position. (Refer to Figure 6)
2. Check for contact between drive wheel and bottom of enclosed wheel. (Refer to Figure 7 and 8)
3. Adjust the hex nut located above spring on handle to increase or decrease contact pressure. (Refer to figure 9)



**Figure 6**



**Figure 7**



**Figure 8**




**Figure 9**



**Tow Bar to E-Tractor Drive Connection:**

1. Disengage Drive Wheel Handle which allows E-tractor to freewheel (If applicable).
2. Align the (3) hole pattern to mate with (3) hole pattern on tow bar. (Refer to Figure 10).
3. Secure supplied fasteners according to torque specifications.
4. See supplied drawings for further installations of tow bar hardware.




**Figure 10**

**Power Supply to E-Tractor:**

Power Requirements: Standard 240V AC Single Phase / 60 hertz

1. The E-Tractor System is operated by plug and cord power supply. Insert plug into electrical receptacle.



**Figure 11**



## Unidrive M Connect

### Connecting to a Knight E-Tractor

1. Getting started:

Hardware required

- PC – Laptop or Personal Computer with MS Windows OS
- Emerson USB/Serial adaptor – P/N CT Comm cable USB-RS485

Software required

- Emerson M Connect – Unidrive M Connect version V02.00.00 or greater.
  - Available at: <http://www.emersonindustrial.com/>





Figure 12




2. Open Unidrive M Connect software from the Start Button or Desktop Icon.



**Figure 13**


3. Configure communications port for the Emerson USB/Serial adaptor
  - ☐ Plug the Emerson USB/Serial adaptor into an available USB port on the PC
  - ☐ Open Emerson M Connect software.
  - ☐ Double-click on No project loaded icon under Project.



**Figure 14**



4. Configure communications port for the Emerson USB/Serial adaptor:
- ☐ Select RTU network in New Project dialog-box.
  - ☐ Click OK button
  - ☐ M Connect software will start scanning for drive on the network



**Figure 15**



5. During the scan for on-line drives on the network a dialog-box similar to the image in Figure 16 will be displayed.




Figure 16



6. If, no on-line drives are found on the network a dialog-box similar to the image in Figure 17 will be displayed.




Figure 17





7. If the no on-line drives are found on the network Discovery Setting or the Connection Address Editor must be set.

Set-up Discovery Settings:

- ☐ Select RTU Protocol
- ☐ Address Range is 1 to 5
- ☐ Check Discover COM Port
- ☐ Click Apply button




Figure 18

8. If the no on-line drives are found on the network Discovery Setting or the Connection Address Editor must be set.

Set-up Connection Address Editor:

- ☐ Select RTU Protocol
- ☐ Set Address to a 1
- ☐ Set COM Port to the available COM Port
- ☐ Click OK button




Figure 19



9. Unidrive M Connect will search for the drives in the set address range on the current COM/RTU connection.




Figure 20



10. Available drives on this network will be listed on left side under the Project window.




Figure 21



## Accessing an online drive(s) through Unidrive M Connect

1. Click the Online icon under listed under the Drive section of the Dashboard tab.
2. Online drive's information will load and be listed in the large window to the right of the Project window under the Dashboard tab




Figure 22



- Online drive's information and parameter settings will be accessible in the Dashboard tab listed in the large window to the right of the Project window.




Figure 23



## Saving a parameter file from a Knight E-Tractor

1. Connect to the Knight E-Tractor – for assistance see the Connecting to a Knight E-Tractor & Accessing an online drive(s) through Unidrive M Connect Sections.
2. Once connected to the on-line drive use the scroll bar on the right-hand side of the Dashboard tab to move down to the Parameters icon group




Figure 24

3. When the Parameters command group is in view click on the “Upload to a file” icon.




Figure 25





4. A file dialog box will appear to select the file that will be saved (uploaded) from the drive to the PC.




Figure 26



5. A file dialog box will appear to select the file that will be saved (uploaded) from the drive to the PC.

- Select the desired file that will be saved from the drive.
- Click the Open button.




Figure 27

6. A status dialog box will appear to indicate direction of the file transfer and percentage of file transferred.




Figure 28





7. A status dialog box will indicate that the operation is complete. Click the “Close” button.




Figure 29



## Restoring a parameter file to a Knight E-Tractor

1. Connect to the Knight E-Tractor – for assistance see the Connecting to a Knight E-Tractor & Accessing an online drive(s) through Unidrive M Connect Sections.
2. Once connected to the on-line drive use the scroll bar on the right-hand side of the Dashboard tab to move down to the Parameters icon group.




Figure 30



3. When the Parameters command group is in view click on the “Download to drive” icon.




Figure 31

4. A file dialog box will appear to select the file that will be restored (downloaded) to the drive from the PC.
  - Select the desired file to restore the drive.
  - Click the Open button.




Figure 32



5. A status dialog box will appear to indicate direction of the file transfer and percentage of file transferred.




Figure 33

6. A status dialog box will indicate that the operation is complete. Click the “Close” button.




Figure 34



7. Under the Drive Operations icon group click on the Save icon to save the restored parameters and drive setting to the drive.




Figure 35

8. The Save parameters in drive dialog-box will appear during this process in the drive.




Figure 36





9. Under the Drive command group click on the Reset icon to cycle the drive and prepare it for operation.




Figure 37

10. The Reset in progress dialog-box will appear during this process in the drive.




Figure 38



## Adjusting Frequency References and Frequency Ramps:

The following steps are used for adjusting Frequency References (Speed) & Frequency Ramps (Accel/Decel rates) in the Knight E- Tractor.

1. Connect and go On-line with the Knight E-Tractor using Unidrive M Connect Software.
2. From the Dashboard Window select the Parameter Listings Icon and use the pull-down option arrow to view the range of the Parameter Listing Menus. Please see the figure below.




Figure 39



3. Select - Menu 1: Frequency References (Speed). Please see the figure below.




Figure 40

4. The Menu 1: Frequency References Tab will be displayed as shown in the figure below.




Figure 41





5. Select Parameter 01.021 – Preset Reference 1. To adjust the slow speed value of the Knight E-Tractor. The adjustment can be made by using the Up/Down Arrows located on the right side of the dialog box or by typing the desired value in the dialog box. Please reference the figure shown below.




Figure 42



6. Select Parameter 01.022 – Preset Reference 2. To adjust the fast speed value of the Knight E-Tractor. The adjustment can be made by using the Up/Down Arrows located on the right side of the dialog box or by typing the desired value in the dialog box. Please reference the figure shown below.




Figure 43

(Note: If the Frequency Ramps (Accel/Decel rates) are not going to be adjusted please proceed to Step #10 – Saving the parameters in the drive.)



7. Select - Menu 2: Frequency Ramps (Accel/Decel rates). Please see Figure 45 below.




Figure 44



8. Select Parameter 02.011 – Acceleration Rate 1. To adjust the acceleration rate value of the Knight E-Tractor. The adjustment can be made by using the Up/Down Arrows located on the right side of the dialog box or by typing the desired value in the dialog box. Please reference the figure shown below. (Note: This parameter is in Seconds/Hertz units. So, the smaller the value the faster the rate of change.)




Figure 45



9. Select Parameter 02.021 – Deceleration Rate 1. To adjust the deceleration rate value of the Knight E-Tractor. The adjustment can be made by using the Up/Down Arrows located on the right side of the dialog box or by typing the desired value in the dialog box. Please reference the figure shown below. (Note: This parameter is in Seconds/Hertz units. So, the smaller the value the faster the rate of change.)




Figure 46



10. After these adjustments have been made and are acceptable. These parameter values must be saved in the drive. To save the parameters select the “Save parameters in drive” icon in one of two locations shown below.




Figure 47





## Operation

All operators should read and understand the instructions in this manual. Follow all instructions and warnings in this manual for safe and trouble-free operation.

### Run/Stop:

1. The E-Tractor System is operated by plug and cord power supply. Insert plug into electrical receptacle.
  - Drive unit input is inhibited and motion is disabled.
  - The RUN-STOP button will illuminate red.

Recovery:

1. Correct the situation that caused the run-stop.
2. Follow the Start Up procedure to restore power to the unit.


### Shut Down:

1. Press the RUN-STOP button, located on the pendant control handle.
2. Disconnect the power supply to the unit (if required).

### Start Up:

1. Connect the power supply to the unit (if required).
2. Reset the RUN-STOP button.
3. Push either Push Button (FWD/REV) to ensure that tractor is operational.

### Over Travel Limit Switches:

	<p><b>NOTE</b></p> <p>During operation the tractor will ramp down in speed and stop as the over travel limits are actuated.</p>
---	---


### Fault Mode:

*Red lift will flash*

1. Press the RUN-STOP button, located on the pendant control handle.
  - Main power is removed and motion is disabled.
  - The RUN-STOP button will illuminate red.

Recovery

1. Correct the situation that caused the fault.
2. Follow the Start Up procedure to restore power to the unit.
3. Consult drive display for fault code (Refer to Figure 35)  
 \*\*Refer to Emerson Unidrive Manual Excerpts or the accompanying CD for further information.



## Preventive Maintenance

### Inspection Overview:

The inspection procedures and recommendations in this manual are based on ANSI/ASME B30.16. The following definitions and recommendations are from ANSI/ASME B30.16 and pertain to the recommended inspection procedures in this manual.

- Qualified Person- a person who, by possession of a recognized degree in an applicable field, or certificate of professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter at work.
- Designated Person- a person selected or assigned by the employer or the employer's representative as being competent to perform specific duties.
- Normal Service- service that involves operation with randomly distributed loads within the rated load limit, or uniform loads less than 65% of rated load for not more than 25% of the time for electric tractors.
- Heavy Service- service that involves operation within the rated load limit, which exceeds normal service.
- Severe Service- service that involves normal or heavy service with abnormal operating conditions.
- Abnormal Operating Conditions- environmental conditions that are unfavorable, harmful, or detrimental to the operation of a tractor, such as excessively high or low ambient temperatures, exposure to weather, corrosive fumes, dust laden or moisture laden atmospheres, and hazardous locations.

### Inspection Overview:

#### Duty Rating

Inspection frequency should be determined by a qualified person and is based on factors such as severity of environment, percentage of capacity lifts, cycle time and shock loading. Each E-Tractor should be rated individually and inspections performed in accordance with rating.

Frequent inspections can be performed by the operator or designated personal.

Periodic inspections must to be performed by designated personal.

#### Frequency of Documentation

Frequent Inspection (Non-Documented):

- Normal duty cycle - monthly.
- Heavy duty cycle- weekly.
- Severe duty cycle- daily.

Periodic Inspection (Documented):

- Normal duty cycle- annually.
- Heavy duty cycle- semiannually.
- Severe duty cycle- quarterly.

Documentation should be made available to personnel for review.





## **Inspection**

### *Frequent Inspection (Non-Documented)*

If any of the conditions listed below are evident the E-Tractor should be placed out of service and a detailed inspection and corrective action should be taken. Additionally, the operator should check the system continually during operation to ensure that no malfunctions are occurring.

#### E-Tractor:

- Visually inspect the E-Tractor, ensure that it is in good general working order. Repair or replace any broken or missing parts.
- Cycle the E-Tractor and listen for any abnormal noises (grinding etc.). If any abnormal noises are evident a periodic inspection of the E-Tractor must be performed.
- Inspect how the drive wheel contacts the rail. If any binding is evident adjust drive wheel accordingly. (Refer to Page 10)
- Cycle run stop.

### *Periodic Inspection (Documented)*

Perform the items listed in the Frequent Inspection section in addition to the items listed below. All findings from this inspection should be recorded. An inspection record, which can be copied, is located on the inside back cover of this manual. If any of the conditions listed below are evident the E-Tractor should be placed out of service and corrective actions can be taken.

#### Supporting Structure:

- Check for distortion, wear and continued ability to support the load. Refer to manufacturers' instructions for overhead rail systems.

#### Rail Trolley (if applicable):

- Ensure wheels and side rollers run smoothly and are not excessively worn. Replace the wheels and side rollers as necessary.
- Check all fasteners ensure they are intact and properly tightened.
- Visually check the nylon at the bearing and along the face of the wheel for cracks.

#### Fasteners:

- Check all fasteners ensure they are not loose, missing or damaged.

#### E-Tractor Not In Regular Use:

- Idle for more than one month, but less than one year, perform the daily inspection on the E-Tractor before placing it into service.
- Idle for more than one year perform the detailed inspection before placing the E-Tractor into service.
- Stand-by E-Tractor should have the daily inspection performed at regular intervals as conditions require.

#### Wheel Wear:

- Check the rubber on the wheels. Rubber will wear with normal use. The wheels should be inspected periodically dependent upon application.
- Approximately 5/8" [1.6cm] of wear is allowable before the wheel needs to be replaced. Some cracking and material loss is allowable. Continued use past the recommended level will cause damage to the track or system operation.




**Pendant Cable Installation / Replacement:**

1. Remove power from E-tractor.
2. Remove Pendant Cable from top of E-tractor control box and control pendant. (Refer to Figure 49)
3. Install new Pendant Cable to top of E-Tractor control box and control pendant. (Refer to Figure 50)



**Figure 49**



**Figure 50**



## Troubleshooting Chart

Problem	Cause	Solution
E-Tractor does not move	Power loss	Check circuit breaker, switches, and connections of all power lines. Check run stop, reset if necessary.
	Incorrect voltage	Check supply voltage and frequency of power supply to ensure it is correct for the E-Tractor.
	Tractor overload / Bin	Reduce load to within the rated capacity of the tractor.
	Electrical fault	Secure power to the tractor; check all wiring and connections on the E-Tractor.
E-Tractor moves forward but does not move in reverse	"REV Limit Stop" set incorrectly	Check REV Limit Stop switch and ensure it is functioning properly.
	Open circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
	Damaged cord	Check each conductor in the pendant/switch cable for continuity. Replace damaged cable(s) as required.
	Switch malfunctioning	Check continuity in switch and electrical connections. Repair or replace as needed.
E-Tractor moves in reverse but does not move forward	"FWD Limit Stop" set incorrectly	Check FWD Limit Stop switch and ensure it is functioning properly.
	Open circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
	Damaged cord	Check each conductor in the pendant/switch cable for continuity. Replace damaged cable(s) as required.
	Switch malfunctioning	Check continuity in switch and electrical connections. Repair or replace as needed.
E-Tractor does not move at proper speed	Tractor Binding	Check for mechanical binds and interferences.
	Tractor Speed Changed	Check display for current speed.
E-Tractor operates intermittently	Open circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
	Damaged pendant cord	Check each conductor in the pendant cable for continuity. Replace damaged cable as required.
	Damaged handle	Check each conductor in the pendant cable for continuity. Replace damaged conductors as required. Check connections and replace if necessary.

*Refer to the appropriate technical manual for additional troubleshooting or contact the Knight Customer Service Department at (248) 377-4950, Extension 162.*



## **M400KETD3K DRAWING PACKAGE**



## Programming Parameters



## **Excerpts from Unidrive M400 User Guide: Issue 4**

(<http://www.emersonindustrial.com/en-EN/controltechniques/downloads/userguidesandsoftware/Pages/unidrivem.aspx>)

Chapter 5 Getting Started  
Chapter 6 Basic Parameters  
Chapter 13 Diagnostics

**\*\*Refer to the CD accompanying this manual for the Unidrive M400 User Guide: Issue 4 in its entirety.**



## 5 Getting started

This chapter introduces the user interfaces, menu structure and security levels of the drive.

### 5.1 Understanding the display


The keypad can only be mounted on the drive.

#### 5.1.1 CI-Keypad

The CI-Keypad display consists of up to four rows of text. The upper two rows show the drive status or the menu and parameter number currently being viewed. When in status mode, an area one character wide and four lines high on the right-hand side of the display, is reserved for displaying actions that are active on the drive. The possible active actions are given in Table 5-2.

When the drive is powered up, the lower two rows will show the status mode parameters defined by *Status Mode Parameter 1* (11.018) and *Status Mode Parameter 2* (11.019).

Figure 5-1 CI-Keypad



1. Escape button
2. Start button
3. Navigation keys (x4)
4. Stop / Reset button (red)
5. Status LED
6. Enter button

#### NOTE








The red stop button  is also used to reset the drive.

The parameter value is correctly displayed on the keypad display as shown in the below table.

Table 5-1 Keypad display formats

Display formats	Value
IP Address	127. 0. 0. 0
MAC Address	01ABCDEF2345
Time	12:34:56
Date	31-12-13 or 12-31-13
Version number	01.02.00.00
Character	ABCD
32 bit number with decimal point	21474836.47
16 bit binary number	0100001011100101





Table 5-2 Active action icon

Active action icon	Description
	Alarm active
	NV media card being accessed
	Drive security active
	User security unlocked
	Motor map 2 active
	User program running
	Keypad reference active


### 5.2 Keypad operation

#### 5.2.1 Control buttons

The keypad consists of:

- Navigation keys - Used to navigate the parameter structure and change parameter values.
- Enter / Mode button  Used to toggle between parameter edit and view mode.
- Escape / Exit button  Used to exit from parameter edit or view mode. In parameter edit mode, if parameter values are edited and the exit button pressed the parameter value will be restored to the value it had on entry to edit mode.
- Startbutton  Used to provide a 'Run' command if keypad mode is selected.
- Stop / Reset button  Used to reset the drive. In keypad mode can be used for 'Stop'.

**Figure 5-2 Display modes**



**NOTE**

The navigation buttons can only be used to move between menus if Pr **00.010** has been set to show 'All Menus'. Refer to section 5.8 *Parameter access level and security* on page 91.


**NOTE**

If the **Escape** button is held down for 1 second, the display returns to status mode.



## 5.2.2 Quick access mode

The quick access mode allows direct access to any parameter without scrolling through menus and parameters.



To enter the quick access mode, press and hold the  Enter button on the keypad while in 'parameter view mode'.



**Figure 5-3 Quick access mode**





## 5.2.3 Keypad shortcuts



In 'parameter view mode':

If the  up and down  keypad buttons are pressed together, then the keypad display will jump to the start of the parameter menu being viewed, i.e. Pr **05.005** being viewed, when the above buttons pressed together will jump to Pr **05.000**.


If the  left and  keypad buttons are pressed together, then the keypad display will jump to the last viewed parameter in Menu 0.

In 'parameter edit mode':

If the  up and down  keypad buttons are pressed together, then the parameter value of the parameter being edited will be set to 0.

If the  left and  keypad buttons are pressed together, the least significant digit (furthest right) will be selected on the keypad display for editing.

**Figure 5-4 Mode examples**



1. Parameter view mode: Read write or Read only
2. Status mode: Drive OK status

If the drive is ok and the parameters are not being edited or viewed, the upper row of the display will show one of the following:


- Inhibit, 'Ready' or 'Run'.

## 3. Status mode: tripstatus

When the drive is in trip condition, the upper row of the display will indicate that the drive has tripped and the lower row of the display will show the trip code. For further information regarding trip codes, refer to Table 13-2 *Trip indications* on page 209.

## 4. Status mode: Alarm status

During an 'alarm' condition the upper row of the display alternates between the drive status (Inhibit, Ready or Run, depending on what is displayed) and the alarm.



Do not change parameter values without careful consideration; incorrect values may cause damage or a safety hazard.

**WARNING**

## NOTE

When changing the values of parameters, make a note of the new values in case they need to be entered again.

## NOTE


For new parameter values to apply after the line power supply to the drive is interrupted, new values must be saved. Refer to section 5.6 *Saving parameters* on page 91.


## 5.3 Menu structure

The drive parameter structure consists of menus and parameters.

The drive initially powers up so that only Menu 0 can be viewed. The up and down arrow buttons are used to navigate between parameters and once Pr **00.010** has been set to 'All Menus', the left and right buttons are used to navigate between menus. For further information, refer to section 5.8 *Parameter access level and security* on page 91.


**Figure 5-5 Parameter navigation**





 \* Can only be used to move between menus if all menus have been enabled (Pr **00.010**). Refer to section 5.8 *Parameter access level and security* on page 91.

The menus and parameters roll over in both directions. i.e. if the last parameter is displayed, a further press will cause the display to rollover and show the first parameter. When changing between menus the drive remembers which parameter was last viewed in a particular menu and thus displays that parameter.

### 5.3.1 CI-Keypad set-up menu

To enter the keypad set-up menu, press and hold the  button on the keypad from status mode. All the keypad parameters are saved to the keypad non-volatile memory when exiting from the keypad set-up menu. To exit from the keypad set-up menu, press the

Escape  or  button. Below are the keypad set-up parameters.

**Table 5-3 CI-Keypad set-up parameters**

	Parameters	Range	Type
Keypad.00	Language	Classic English or English	RW
Keypad.01	Show Units	Off or On	RW
Keypad.02	Backlight Level	0 to 100 %	RW
Keypad.05	Show Raw Text Parameter Values	Off or On	RW
Keypad.06	Software Version	00.00.00.00 to 99.99.99.99	RO

#### NOTE

It is not possible to access the keypad parameters via any communications channel.

## 5.4 Advanced menus

The advanced menus consist of groups or parameters appropriate to a specific function or feature of the drive. Menus 0 to 22 can be viewed on the Keypad.

The option module menu (S.mm.ppp) is only displayed if the option module is installed. Where S signifies the option module slot number and the mm.ppp signifies the menu and parameter number of the option module's internal menus and parameter.

**Table 5-4 Advanced menu descriptions**

Menu	Description
0	Commonly used basic set up parameters for quick / easy programming
1	Frequency reference
2	Ramps
3	Frequency control
4	Torque and current control
5	Motor control
6	Sequencer and clock
7	Analog I/O
8	Digital I/O
9	Programmable logic, motorized pot, binary sum, timers and scope
10	Status and trips
11	Drive set-up and identification, serial communications
12	Threshold detectors and variable selectors
14	User PID controller
15	Option module slot 1 set-up menu
18	General option module application menu 1
20	General option module application menu 2
21	Second motor parameters
22	Menu 0 set-up
Slot 1	Slot 1 option menus*

\* Only displayed when the option module is installed.

### 5.4.1 Display messages

The following tables indicate the various possible mnemonics which can be displayed by the drive and their meaning.

**Table 5-5 Status indications**

Upper row string	Description	Drive output stage
Inhibit	The drive is inhibited and cannot be run. The SAFE TORQUE OFF signals are not applied to the SAFE TORQUE OFF terminals or Pr <b>06.015</b> is set to 0. The other conditions that can prevent the drive from enabling are shown as bits in <i>Enable Conditions</i> (06.010).	Disabled
Ready	The drive is ready to run. The drive enable is active, but the drive inverter is not active because the final drive run is not active.	Disabled
Stop	The drive is stopped / holding zero frequency.	Enabled
Run	The drive is active and running.	Enabled
Supply Loss	Supply loss condition has been detected	Enabled
Deceleration	The motor is being decelerated to zero frequency because the final drive run has been deactivated.	Enabled
dc Injection	The drive is applying dc injection braking.	Enabled
Trip	The drive has tripped and no longer controlling the motor. The trip code appears in the lower display.	Disabled
Under Voltage	The drive is in the under-voltage state either in low voltage or high voltage mode.	Disabled

### 5.4.2 Alarm indications

An alarm is an indication given on the display by alternating the alarm string with the drive status string on the display. Alarms strings are not displayed when a parameter is being edited.

**Table 5-6 Alarm indications**

Alarm string	Description
Brake Resistor	Brake resistor overload. <i>Braking Resistor Thermal Accumulator</i> (10.039) in the drive has reached 75.0 % of the value at which the drive will trip.
Motor Overload	<i>Motor Protection Accumulator</i> (04.019) in the drive has reached 75.0 % of the value at which the drive will trip and the load on the drive is >100 %.
Drive overload	Drive over temperature. <i>Percentage Of Drive Thermal Trip Level</i> (07.036) in the drive is greater than 90 %.
Auto Tune	The autotune procedure has been initialized and an autotune in progress.
Limit Switch	Limit switch active. Indicates that a limit switch is active and that is causing the motor to be stopped.
Option Slot 1	Option slot alarm.
Low AC	Low voltage mode. See <i>Low AC Alarm</i> (10.107).
Current Limit	Current limit active. See <i>Current Limit Active</i> (10.009).

## 5.5 Changing the operating mode

### Procedure

Use the following procedure only if a different operating mode is required:

1. Ensure the drive is not enabled, i.e. terminal 31 & 34 are open or Pr **06.015** is OFF (0)
2. Change the setting of Pr **00.079** as follows:

Pr <b>00.079</b> setting		Operating mode
00.079 ^ Open-loop	1	Open-loop
00.079 v RFC-A	2	RFC-A

The figures in the second column apply when serial communications are used.

### NOTE

When the operating mode is changed, a parameter save is carried out.


3. Either:

Press the red  reset button

Carry out a drive reset through serial communications by setting Pr **10.038** to 100 (ensure that Pr **mm.000** returns to 0)

## 5.6 Saving parameters


When changing a parameter in Menu 0, the new value is saved when

pressing the Enter button  to return to parameter view mode from parameter edit mode.

If parameters have been changed in the advanced menus, then the change will not be saved automatically. A save function must be carried out.

### Procedure

1. Select 'Save parameters\*' in Pr **mm.000** (alternatively enter a value of 1000\* in Pr **mm.000**)
2. Either:


- Press the red  reset button
- Carry out a drive reset through serial communications by setting Pr **10.038** to 100

\* If the drive is in the under-voltage state (i.e. when the AI-Backup adaptor terminals are being supplied from a +24 Vdc supply) a value of 1001 must be entered into Pr **mm.000** to perform a save function.

## 5.7 Restoring parameter defaults

Restoring parameter defaults by this method saves the default values in the drives memory. *User security status* (00.010) and *User security code* (00.025) are not affected by this procedure).

### Procedure

1. Ensure the drive is not enabled, i.e. terminal 31 & 34 is open or Pr **06.015** is OFF (0)
2. Select 'Reset 50 Hz Defs' or 'Reset 60 Hz Defs' in Pr **mm.000**. (alternatively, enter 1233 (50 Hz settings) or 1244 (60 Hz settings) in Pr **mm.000**).
3. Either:
  - Press the red  reset button
  - Carry out a drive reset through serial communications by setting Pr **10.038** to 100

## 5.8 Parameter access level and security

The parameter access level determines whether the user has access to Menu 0 only or to all the advanced menus (Menus 1 to 22) in addition to Menu 0.

The User Security determines whether the access to the user is read only or read write.

Both the User Security and Parameter Access Level can operate independently of each other as shown in Table 5-7.

**Table 5-7 Parameter access level and security**

User security status (11.044)	Access level	User security	Menu 0 status	Advanced menu status
0	Menu 0	Open	RW	Not visible
		Closed	RO	Not visible
1	All Menus	Open	RW	RW
		Closed	RO	RO
2	Read-only Menu 0	Open	RO	Not visible
		Closed	RO	Not visible
3	Read-only	Open	RO	RO
		Closed	RO	RO
4	Status only	Open	Not visible	Not visible
		Closed	Not visible	Not visible
5	No access	Open	Not visible	Not visible
		Closed	Not visible	Not visible

The default settings of the drive are Parameter Access Level Menu 0 and user Security Open i.e. read / write access to Menu 0 with the advanced menus not visible.

### 5.8.1 User Security Level / Access Level

The drive provides a number of different levels of security that can be set by the user via *User Security Status* (11.044); these are shown in the table below.

User Security Status (Pr 11.044)	Description
Menu 0 (0)	All writable parameters are available to be edited but only parameters in Menu 0 are visible
All menus (1)	All parameters are visible and all writable parameters are available to be edited
Read-only Menu 0 (2)	Access is limited to Menu 0 parameters only. All parameters are read-only
Read-only (3)	All parameters are read-only however all menus and parameters are visible
Status only (4)	The keypad remains in status mode and no parameters can be viewed or edited
No access (5)	The keypad remains in status mode and no parameters can be viewed or edited. Drive parameters cannot be accessed via a comms/ fieldbus interface in the drive or any option module



### 5.8.2 Changing the User Security Level/Access Level

The security level is determined by the setting of Pr **00.010** or Pr **11.044**. The Security Level can be changed through the keypad even if the User Security Code has been set.



### 5.8.3 User Security Code

The User Security Code, when set, prevents write access to any of the parameters in any menu.

#### Setting User Security Code


Enter a value between 1 and 9999 in Pr **00.025** and press the  button; the security code has now been set to this value. In order to activate the security, the Security level must be set to desired level in Pr **00.010**. When the drive is reset, the security code will have been activated and the drive returns to Menu 0 and the  symbol is displayed in the right-hand corner of the keypad display. The value of Pr **00.025** will return to 0 in order to hide the security code.

#### Unlocking User Security Code

Select a parameter that need to be edited and press the  button, the display will now show 'security code'. Use the arrow buttons to set the security code and press the  button. With the correct security code entered, the display will revert to the parameter selected in edit mode.

If an incorrect security code is entered, the following message 'incorrect security code' is displayed, and the display will revert to parameter view mode.

#### Disabling User Security

Unlock the previously set security code as detailed above. Set Pr **00.025** to 0 and press the  button. The User Security has now been disabled, and will not have to be unlocked each time the drive is powered up to allow read / write access to the parameters.

## 5.9 Displaying parameters with non-default values only

By selecting 'Show non-default' in Pr **mm.000** (Alternatively, enter 12000 in Pr **mm.000**), the only parameters that will be visible to the user will be those containing a non-default value. This function does not require a drive reset to become active. In order to deactivate this function, return to Pr **mm.000** and select 'No action' (alternatively enter a value of 0). Please note that this function can be affected by the access level enabled, refer to section 5.8 *Parameter access level and security* on page 91 for further information regarding access level.

## 5.10 Displaying destination parameters only

By selecting 'Destinations' in Pr **mm.000** (Alternatively enter 12001 in Pr **mm.000**), the only parameters that will be visible to the user will be destination parameters. This function does not require a drive reset to become active. In order to deactivate this function, return to Pr **mm.000** and select 'No action' (alternatively enter a value of 0).

Please note that this function can be affected by the access level enabled, refer to section 5.8 *Parameter access level and security* on page 91 for further information regarding access level.

## 5.11 Communications

Installing an AI-485 adaptor provides the drive with a 2 wire 485 serial communications interface. This enables the drive set-up, operation and monitoring to be carried out with a PC or controller as required.

### 5.11.1 485 Serial communications

Communication is via the RJ45 connector or screw terminals (parallel connection). The drive only supports Modbus RTU protocol.

The communications port applies a  $\frac{1}{4}$  unit load to the communications network.

#### USB to EIA485 Communications

An external USB hardware interface such as a PC cannot be used directly with the 2-wire EIA485 interface of the drive. Therefore, a suitable converter is required.

A suitable USB to EIA485 isolated converter is available from Control Techniques as follows:

- CT USB Comms cable (CT Part No. 4500-0096)

When using one of the above converters or any other suitable converter with the drive, it is recommended that no terminating resistors be connected on the network. It may be necessary to 'link out' the terminating resistor within the converter depending on which type is used. The information on how to link out the terminating resistor will normally be contained in the user information supplied with the converter.

#### Serial communications set-up parameters

The following parameters need to be set according to the system requirements.

Serial communications set-up parameters		
<i>Serial Mode</i> (11.024)	8 2 NP (0), 8 1 NP (1), 8 1 EP (2), 8 1 OP (3), 8 2 NP M (4), 8 1 NP M (5), 8 1 EP M (6), 8 1 OP M (7), 7 1 EP (8), 7 1 OP (9), 7 1 EP M (10), 7 1 OP M (11)	The drive only supports the Modbus RTU protocol and is always a slave. This parameter defines the supported data formats used by the 485 comms port (if installed) on the drive. This parameter can be changed via the drive keypad, via a option module or via the comms interface itself.
<i>Serial Baud Rate</i> (11.025)	300 (0), 600 (1), 1200 (2), 2400 (3), 4800 (4), 9600 (5), 19200 (6), 38400 (7), 57600 (8), 76800 (9), 115200 (10)	This parameter can be changed via the drive keypad, via a option module or via the comms interface itself. If it is changed via the comms interface, the response to the command uses the original baud rate. The master should wait at least 20 ms before sending a new message using the new baud rate.
<i>Serial Address</i> (11.023)	1 to 247	This parameter defines the serial address and an address between 1 and 247 is permitted.

Safety information	Product information	Mechanical installation	Electrical installation	Getting started	<b>Basic parameters</b>	Running the motor	Optimization	NV Media Card Operation	Onboard PLC	Advanced parameters	Technical data	Diagnostics	UL listing information
--------------------	---------------------	-------------------------	-------------------------	-----------------	-------------------------	-------------------	--------------	-------------------------	-------------	---------------------	----------------	-------------	------------------------

## 6 Basic parameters

Menu 0 is used to bring together various commonly used parameters for basic easy set up of the drive. All the parameters in Menu 0 appear in other menus in the drive (denoted by {...}). Menus 22 can be used to configure the parameters in Menu 0.

### 6.1 Menu 0: Basic parameters

Parameter		Range (圖)		Default (O)		Type					
		OL	RFC-A	OL	RFC-A						
00.001	Minimum Reference Clamp	±VM_NEGATIVE_REF_CLAMP1 Hz		0.00 Hz		RW	Num				US
00.002	Maximum Reference Clamp	±VM_POSITIVE_REF_CLAMP Hz		50 Hz default: 50.00 Hz 60 Hz default: 60.00 Hz		RW	Num				US
00.003	Acceleration Rate 1	±VM_ACCEL_RATE s		5.0 s		RW	Num				US
00.004	Deceleration Rate 1	±VM_ACCEL_RATE s		10.0 s		RW	Num				US
00.005	Drive Configuration	AV (0), AI (1), AV Preset (2), AI Preset (3), Preset (4), Keypad (5), Keypad Ref (6), Electronic Pot (7), Torque Control (8), Pid Control (9)		AV (0)		RW	Txt			PT	US
00.006	Motor Rated Current	±VM_RATED_CURRENT A		Maximum Heavy-Duty Rating (11.032) A		RW	Num		RA		US
00.007	Motor Rated Speed	0.0 to 80000.0 rpm		50 Hz default: 1500.0 rpm 60 Hz default: 1800.0 rpm	50 Hz default: 1450.0 rpm 60 Hz default: 1750.0 rpm	RW	Num				US
00.008	Motor Rated Voltage	±VM_AC_VOLTAGE_SET V		110 V drive: 230 V 200 V drive: 230 V 400 V drive 50 Hz: 400 V 400 V drive 60 Hz: 460 V 575 V drive: 575 V 690 V drive: 690 V		RW	Num		RA		US
00.009	Motor Rated Power Factor	0.00 to 1.00		0.85		RW	Num		RA		US
00.010	User Security Status	Menu 0 (0), All Menus (1), Read only Menu 0 (2), Read only (3), Status Only (4), No Access (5)		Menu 0 (0)		RW	Txt	ND	NC	PT	
00.012	Input Logic Polarity	Negative Logic (0) or Positive Logic (1)		Positive Logic (1)		RW	Txt				US
00.015	Jog Reference	0.00 to 300.00 Hz		1.50 Hz		RW	Num				US
00.016	Analog Input 1 Mode	4-20 mA Stop (-6), 20-4 mA Stop (-5), 4-20 mA Low (-4), 20-4 mA Low (-3), 4-20 mA Hold (-2), 20-4 mA Hold (-1), 0-20 mA (0), 20-0 mA (1), 4-20 mA Trp (2), 20-4 mA Trp (3), 4-20 mA (4), 20-4 mA (5), Voltage (6)		Voltage (6)		RW	Txt				US
00.017	Bipolar Reference Enable	Off (0) or On (1)		Off (0)		RW	Bit				US
00.018	Preset Reference 1	±VM_SPEED_FREQ_REF Hz		0.00 Hz		RW	Num				US
00.025	User Security Code	0 to 9999		0		RW	Num	ND	NC	PT	US
00.027	Power-up Keypad Control Mode Reference	Reset (0), Last (1), Preset (2)		Reset (0)		RW	Txt				US
00.028	Ramp Mode Select	Fast (0), Standard (1), Std boost (2), Fast boost (3)		Standard (1)		RW	Txt				US
00.029	Ramp Enable		Off (0) or On (1)		On (1)	RW	Bit				US
00.030	Parameter Cloning	None (0), Read (1), Program (2), Auto (3), Boot (4)		None (0)		RW	Txt		NC		US
00.031	Stop Mode	Coast (0), Ramp (1), Ramp dc I (2), dc I (3), Timed dc I (4), Disable (5), No Ramp (6)		Ramp (1)		RW	Txt				US
00.032	Dynamic V to F Select / Flux Optimization Select	0 to 1		0		RW	Num				US
00.033	Catch A Spinning Motor	Disable (0), Enable (1), Fwd Only (2), Rev Only (3)		Disable (0)		RW	Txt				US
00.034	Digital Input 5 Select	Input (0), Therm Short Cct (1), Thermistor (2), Therm No Trip (3)		Input (0)		RW	Txt				US
00.035	Digital Output 1 Control	0 to 21		0		RW					US
00.036	Analog Output 1 Control	0 to 15		0		RW					US
00.037	Maximum Switching Frequency	0.667 (0), 1 (1), 2 (2), 3 (3), 4 (4), 6 (5), 8 (6), 12 (7), 16 (8) kHz	2 (2), 3 (3), 4 (4), 6 (5), 8 (6), 12 (7), 16 (8)	3 (3) kHz		RW	Txt				US

Safety information	Product information	Mechanical installation	Electrical installation	Getting started	Basic parameters	Running the motor	Optimization	NV Media Card Operation	Onboard PLC	Advanced parameters	Technical data	Diagnostics	UL listing information
--------------------	---------------------	-------------------------	-------------------------	-----------------	------------------	-------------------	--------------	-------------------------	-------------	---------------------	----------------	-------------	------------------------


Parameter		Range (R)		Default (O)		Type					
		OL	RFC-A	OL	RFC-A						
00.038	Auto-tune	0 to 2	0 to 3	0		RW	Num		NC		US
00.039	Motor Rated Frequency	0.00 to VM_SPEED_FREQ_REF_UNIPOLAR Hz		50Hz: 50.00 Hz 60Hz: 60.00 Hz		RW	Num		RA		US
00.040	Number of Motor Poles*	Automatic (0) to 32 (16) Poles		Automatic (0) Poles		RW	Txt				US
00.041	Control Mode	Ur S (0), Ur (1), Fixed (2), Ur Auto (3), Ur I (4), Square (5)		Ur I (4)		RW	Txt				US
00.042	Low Frequency Voltage Boost	0.0 to 25.0 %		3.0 %		RW	Num				US
00.043	Serial Baud Rate	300 (0), 600 (1), 1200 (2), 2400 (3), 4800 (4), 9600 (5), 19200 (6), 38400 (7), 57600 (8), 76800 (9), 115200 (10)		19200 (6)		RW	Txt				US
00.044	Serial Address	1 to 247		1		RW	Num				US
00.045	Reset Serial Communications	Off (0) or On (1)		Off (0)		RW	Bit	ND	NC		
00.046	Brake Release Current Threshold	0 to 200 %		50 %		RW	Num				US
00.047	Brake Apply Current Threshold	0 to 200 %		10 %		RW	Num				US
00.048	BC Brake Release Frequency	0.00 to 20.00 Hz		1.00 Hz		RW	Num				US
00.049	BC Brake Apply Frequency	0.00 to 20.00 Hz		2.00 Hz		RW	Num				US
00.050	BC Brake Delay	0.0 to 25.0 s		1.0 s		RW	Num				US
00.051	BC Post-brake Release Delay	0.0 to 25.0 s		1.0 s		RW	Num				US
00.053	BC Initial Direction	Ref (0), Forward (1), Reverse (2)		Ref (0)		RW	Txt				US
00.054	BC Brake Apply Through Zero Threshold	0.00 to 25.00 Hz		0.00 Hz		RW	Num				US
00.055	BC Enable	Disable (0), Relay (1), Digital IO (2), User (3)		Disable (0)		RW	Txt				US
00.059	OUP Enable	Stop (0) or Run (1)		Run (1)		RW	Txt				US
00.065	Frequency Controller Proportional Gain Kp1		0.000 to 200.000 s/rad		0.100 s/rad	RW	Num				US
00.066	Frequency Controller Integral Gain Ki1		0.00 to 655.35 s <sup>2</sup> /rad		0.10 s <sup>2</sup> /rad	RW	Num				US
00.067	Sensorless Mode Filter		4 (0), 5 (1), 6 (2), 8 (3), 12 (4), 20 (5) ms		4 (0) ms	RW	Txt				US
00.069	Spin Start Boost	0.0 to 10.0		1.0		RW	Num				US
00.076	Action on Trip Detection	00000 to 11111		00000		RW	Bin				US
00.077	Maximum Heavy-Duty Current Rating	0.00 to 9999.99 A				RO	Num	ND	NC	PT	
00.078	Software Version	00.00.00.00 to 99.99.99.99				RO	Num	ND	NC	PT	
00.079	User Drive Mode	Open loop (1), RFC A (2)		Open-loop (1)		RW	Txt	ND	NC	PT	US
00.080	User Security Status	Menu 0 (0), All Menus (1), Read only Menu 0 (2), Read only (3), Status Only (4), No Access (5)		Menu 0 (0)		RW	Txt	ND		PT	

\* If this parameter is read via serial communications, it will show pole pairs.


RW	Read / Write	RO	Read only	Num	Number parameter	Bit	Bit parameter	Txt	Text string	Bin	Binary parameter	FI	Filtered
ND	No default value	NC	Not copied	PT	Protected parameter	RA	Rating dependent	US	User save	PS	Power-down save	DE	Destination

Safety information	Product information	Mechanical installation	Electrical installation	Getting started	<b>Basic parameters</b>	Running the motor	Optimization	NV Media Card Operation	Onboard PLC	Advanced parameters	Technical data	Diagnostics	UL listing information
--------------------	---------------------	-------------------------	-------------------------	-----------------	-------------------------	-------------------	--------------	-------------------------	-------------	---------------------	----------------	-------------	------------------------

Figure 6-1 Menu 0 logic diagram







## 6.2 Parameter descriptions

### 6.2.1 Pr mm.000

Pr **mm.000** is available in all menus, commonly used functions are provided as text strings in Pr **mm.000** shown in Table 6-1. The functions in Table 6-1 can also be selected by entering the appropriate numeric values (as shown in Table 6-2) in Pr **mm.000**. For example, enter 7001 in Pr **mm.000** to store drive parameters on an NV media card.

**Table 6-1 Commonly used functions in xx.000**

Value	Equivalent value	String	Action
0	0	No Action	No action
1000	1	Save Parameters	Save drive parameters to non-volatile memory
6001	2	Load file 1	Load the data from file 1 on a non-volatile media card into the drive provided it is a parameter file
4001	3	Save to file 1	Store the drive parameters in file 1 on a non-volatile media card
6002	4	Load file 2	Load the data from file 2 on a non-volatile media card into the drive provided it is a parameter file
4002	5	Save to file 2	Store the drive parameters in file 2 on a non-volatile media card
6003	6	Load file 3	Load the data from file 3 on a non-volatile media card into the drive provided it is a parameter file
4003	7	Save to file 3	Store the drive parameters in file 3 on a non-volatile media card
12000	8	Show non-default	Only display parameters that are different from their default value
12001	9	Destinations	Only display parameters that are used to set-up destinations
1233	10	Reset 50 Hz defs	Load 50 Hz defaults
1244	11	Reset 60 Hz defs	Load 60 Hz defaults
1070	12	Reset modules	Reset all option modules

**Table 6-2 Functions in Pr mm.000**

Value	Action
1000	Save parameters when <i>Under Voltage Active</i> (Pr <b>10.016</b> ) is not active.
1001	Save parameter under all conditions
1070	Reset option module
1233	Load standard (50 Hz) defaults
1234	Load standard (50 Hz) defaults to all menus except option module menu 15
1244	Load US (60 Hz) defaults
1245	Load US (60 Hz) defaults to all menus except option module menu 15
1299	Reset {Stored HF} trip.
2001*	Create a boot file on a non-volatile media card based on the present drive parameters including all Menu 20 parameters
4yyy*	NV media card: Transfer the drive parameters to parameter file yyy
5yyy*	NV media card: Transfer the onboard user program to onboard user program file yyy
6yyy*	NV media card: Load the drive parameters from parameter file yyy or the onboard user program from onboard user program file yyy
7yyy*	NV media card: Erase file yyy
8yyy*	NV Media card: Compare the data in the drive with file yyy
9555*	NV media card: Clear the warning suppression flag
9666*	NV media card: Clear the warning suppression flag
9777*	NV media card: Clear the read-only flag
9888*	NV media card: Set the read-only flag
12000**	Only display parameters that are different from their default value. This action does not require a drive reset.
12001**	Only display parameters that are used to set-up destinations (i.e. DE format bit is 1). This action does not require a drive reset.
40yyy	Backup all drive data (parameter differences from defaults, an onboard user program and miscellaneous option data), including the drive name; the store will occur to the </fs/MCDF/driveyyy/> folder; if it does not exist, it will be created. Since the name is stored, this is a backup, rather than a clone. The command code will be cleared when all drive and option data have been saved.
60yyy	Load all drive data (parameter differences from defaults, an onboard user program and miscellaneous option data); the load will come from the </fs/MCDF/driveyyy/> folder. The command code will not be cleared until the drive and all option data have been loaded.

\* See Chapter 9 *NV Media Card Operation* on page 114 for more information on these functions.

\*\* These functions do not require a drive reset to become active.

All other functions require a drive reset to initiate the function. Equivalent values and strings are also provided in the table above.

## 13 Diagnostics

The keypad display on the drive gives various information about the status of the drive. The keypad display provides information on the following categories:

- Trip indications
- Alarm indications
- Status indications




Users must not attempt to repair a drive if it is faulty, nor carry out fault diagnosis other than through the use of the diagnostic features described in this chapter.

**WARNING** If a drive is faulty, it must be returned to an authorized Control Techniques distributor for repair.

### 13.1 Status modes (Keypad and LED status)

Figure 13-1 Keypad status modes



- 1 Drive OK status
- 2 Trip status
- 3 Alarm status

### 13.2 Trip indications

The output of the drive is disabled under any trip condition so that the drive stops controlling the motor. If the motor is running when the trip occurs it will coast to a stop.

During a trip condition, where a CI-Keypad is being used, the upper row of the display indicates that a trip has occurred and the lower row of the keypad display will show the trip string. Some trips have a sub-trip number to provide additional information about the trip. If a trip has a sub-trip number, the sub-trip number is flashed alternately with the trip string unless there is space on the second row for both the trip string and the sub-trip number in which case both the trip string and sub-trip information is displayed separated by a decimal point.

If a display is not being used, the drive LED Status indicator will flash with 0.5 s duty cycle if the drive has tripped. Refer to Figure 13-2 Key to sub-trip number.

Trips are listed alphabetically in Table 13-3 *Serial communications look up table* on page 225 based on the trip indication shown on the drive display. Alternatively, the drive status can be read in Pr **10.001** 'Drive OK' using communication protocols. The most recent trip can be read in Pr **10.020** providing a trip number. It must be noted that the hardware trips (HF01 to HF19) do not have trip numbers. The trip number must be checked in Table 13-3 to identify the specific trip.

#### Example

1. Trip code 2 is read from Pr **10.020** via serial communications.
2. Checking Table 13-2 shows Trip 2 is an Over Volts trip.



3. Look up Over Volts in Table 13-2.
4. Perform checks detailed under *Diagnosis*.

### 13.3 Identifying a trip / trip source

Some trips only contain a trip string whereas some other trips have a trip string along with a sub-trip number which provides the user with additional information about the trip.

A trip can be generated from a control system or from a power system. The sub-trip number associated with the trips listed in Table 13-1 is in the form xxyzz and used to identify the source of the trip.

Table 13-1 Trips associated with xxyzz sub-trip number


Over Volts	Phase Loss
OI ac	Power Comms
OI Brake	OI Snubber
PSU	OHt Rectifier
OHt Inverter	Temp Feedback
OHt Power	Power Data
OHt dc bus	Soft Start

The digits xx are 00 for a trip generated by the control system. For a drive, if the trip is related to the power system then xx will have a value of 01, when displayed the leading zeros are suppressed.

For a control system trip (xx is zero), the y digit where relevant is defined for each trip. If not relevant, the y digit will have a value of zero.

The zz digits give the reason for the trip and are defined in each trip description.

Figure 13-2 Key to sub-trip number



## 13.4 Trips, Sub-trip numbers

Table 13-2 Trip indications

Trip	Diagnosis				
<b>An Input 1 Loss</b>	<b>Analog input 1 current loss</b>				
28	<p>The <i>An Input 1 Loss</i> trip indicates that a current loss was detected in current mode on Analog input 1 (Terminal 2). In 4-20 mA and 20-4 mA modes loss of input is detected if the current falls below 3 mA.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check control wiring is correct</li> <li>Check control wiring is undamaged</li> <li>Check the <i>Analog Input 1 Mode</i> (07.007)</li> <li>Current signal is present and greater than 3 mA</li> </ul>				
<b>An Input 1 OI</b>	<b>Analog input 1 over-current</b>				
189	Current input on analog input 1 exceeds 24mA.				
<b>An Input 2 Loss</b>	<b>Analog input 2 current loss</b>				
29	<p>The <i>An Input 2 Loss</i> trip indicates that a current loss was detected in current mode on Analog input 2 (Terminal 5). In 4-20 mA and 20-4 mA modes loss of input is detected if the current falls below 3 mA.</p> <p><b>Recommend actions:</b></p> <ul style="list-style-type: none"> <li>Check control wiring is correct</li> <li>Check control wiring is undamaged</li> <li>Check the <i>Analog Input 2 Mode</i> (07.011)</li> <li>Current signal is present and greater than 3 mA</li> </ul>				
<b>An Input 2 OI</b>	<b>Analog input 2 over-current</b>				
190	Current input on analog input 2 exceeds 24 mA.				
<b>Autotune</b>	<b>Measured inertia has exceeded the parameter range</b>				
13	<p>The drive has tripped during a rotating autotune or mechanical load measurement test. The cause of the trip can be identified from the associated sub-trip number.</p> <table border="1"> <thead> <tr> <th>Sub-trip</th><th>Reason</th></tr> </thead> <tbody> <tr> <td>1</td><td>Measured inertia has exceeded the parameter range during a mechanical load measurement</td></tr> </tbody> </table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check motor cable wiring is correct</li> </ul>	Sub-trip	Reason	1	Measured inertia has exceeded the parameter range during a mechanical load measurement
Sub-trip	Reason				
1	Measured inertia has exceeded the parameter range during a mechanical load measurement				
<b>Autotune Stopped</b>	<b>Autotune test stopped before completion</b>				
18	<p>The drive was prevented from completing an autotune test, because either the drive enable or the drive run were removed.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check the drive enable signal (Terminal 31 &amp; 34) were active during the autotune</li> </ul>				
<b>Brake R Too Hot</b>	<b>Braking resistor overload timed out (I<sup>2</sup>t)</b>				
19	<p>The <i>Brake R Too Hot</i> trip indicates that braking resistor overload has timed out. The value in <i>Braking Resistor Thermal Accumulator</i> (10.039) is calculated using <i>Braking Resistor Rated Power</i> (10.030), <i>Braking Resistor Thermal Time Constant</i> (10.031) and <i>Braking Resistor Resistance</i> (10.061). The <i>Brake R too Hot</i> trip is initiated when the <i>Braking Resistor Thermal Accumulator</i> (10.039) reaches 100 %.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Ensure the values entered in Pr <b>10.030</b>, Pr <b>10.031</b> and Pr <b>10.061</b> are correct</li> <li>If an external thermal protection device is being used and the braking resistor software overload protection is not required, set Pr <b>10.030</b>, Pr <b>10.031</b> or Pr <b>10.061</b> to 0 to disable the trip.</li> </ul>				
<b>Card Access</b>	<b>NV Media Card Write fail</b>				
185	<p>The <i>Card Access</i> trip indicates that the drive was unable to access the NV Media Card. If the trip occurs during the data transfer to the card then the file being written may be corrupted. If the trip occurs when the data being transferred to the drive then the data transfer may be incomplete. If a parameter file is transferred to the drive and this trip occurs during the transfer, the parameters are not saved to non-volatile memory, and so the original parameters can be restored by powering the drive down and up again.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check NV Media Card is installed / located correctly</li> <li>Replace the NV Media Card</li> </ul>				
<b>Card Boot</b>	<b>The Menu 0 parameter modification cannot be saved to the NV Media Card</b>				
177	<p>Menu 0 changes are automatically saved on exiting edit mode.</p> <p>The <i>Card Boot</i> trip will occur if a write to a Menu 0 parameter has been initiated via the keypad by exiting edit mode and Pr <b>11.042</b> is set for auto or boot mode, but the necessary boot file has not been created on the NV Media Card to take the new parameter value. This occurs when Pr <b>11.042</b> is changed to Auto (3) or Boot (4) mode, but the drive is not subsequently reset.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Ensure that Pr <b>11.042</b> is correctly set, and then reset the drive to create the necessary file on the NV Media Card</li> <li>Re-attempt the parameter write to the Menu 0 parameter</li> </ul>				

Card Busy	NV Media Card cannot be accessed as it is being accessed by an option module	
178	<p>The <i>Card Busy</i> trip indicates that an attempt has been made to access a file on NV Media Card, but the NV Media Card is already being accessed by an Option Module. No data is transferred.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Wait for the option module to finish accessing the NV Media Card and re-attempt the required function</li></ul>	
Card Compare	NV Media Card file/data is different to the one in the drive	
188	<p>A compare has been carried out between a file on the NV Media Card, a <i>Card Compare</i> trip is initiated if the parameters on the NV Media Card are different to the drive.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Set Pr <b>mm.000</b> to 0 and reset the trip</li><li>Check to ensure the correct data block on the NV Media Card has been used for the compare</li></ul>	
Card Data Exists	NV Media Card data location already contains data	
179	<p>The <i>Card Data Exists</i> trip indicates that an attempt has been made to store data on a NV Media Card in a data block which already contains data.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Erase the data in data location</li><li>Write data to an alternative data location</li></ul>	
Card Drive Mode	NV Media Card parameter set not compatible with current drive mode	
187	<p>The <i>Card Drive Mode</i> trip is produced during a compare if the drive mode in the data block on the NV Media Card is different from the current drive mode. This trip is also produced if an attempt is made to transfer parameters from a NV Media Card to the drive if the operating mode in the data block is outside the allowed range of operating modes.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Ensure the destination drive supports the drive operating mode in the parameter file.</li><li>Clear the value in Pr <b>mm.000</b> and reset the drive</li><li>Ensure destination drive operating mode is the same as the source parameter file</li></ul>	
Card Error	NV Media Card data structure error	
182	<p>The <i>Card Error</i> trip indicates that an attempt has been made to access the NV Media Card but an error has been detected in the data structure on the card. Resetting the trip will cause the drive to erase and create the correct folder structure. The cause of the trip can be identified by the sub-trip.</p>	
	Sub-trip	Reason
	1	The required folder and file structure is not present
	2	The HEADER.DAT file is corrupted
	3	Two or more files in the <MCDF> folder have the same file identification number
<p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Erase all the data block and re-attempt the process</li><li>Ensure the card is located correctly</li><li>Replace the NV Media Card</li></ul>		
Card Full	NV Media Card full	
184	<p>The <i>Card Full</i> trip indicates that an attempt has been made to create a data block on a NV Media Card, but there is not enough space left on the card.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Delete a data block or the entire NV Media Card to create space</li><li>Use a different NV Media Card</li></ul>	
Card No Data	NV Media Card data not found	
183	<p>The <i>Card No Data</i> trip indicates that an attempt has been made to access non-existent file or block on the NV Media Card.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Ensure data block number is correct</li></ul>	
Card Option	NV Media Card trip; option modules installed are different between source drive and destination drive	
180	<p>The <i>Card Option</i> trip indicates that parameter data or default difference data is being transferred from the NV Media Card to the drive, but the option module category is different between the source and destination drives. This trip does not stop the data transfer, but is a warning that the data for the option module that is different will be set to the default values and not the values from the card. This trip also applies if a compare is attempted between the data block and the drive.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Ensure the correct option module is installed.</li><li>Press the red reset button to acknowledge that the parameters for the option module installed will be at their default values</li><li>This trip can be suppressed by setting Pr <b>mm.000</b> to 9666 and resetting the drive.</li></ul>	

Card Product	NV Media Card data blocks are not compatible with the drive derivative							
175	<p>The <i>Card Product</i> trip is initiated either at power-up or when the card is accessed, If <i>Drive Derivative</i> (11.028) is different between the source and target drives. This trip can be reset and data can be transferred in either direction between the drive and the card.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Use a different NV Media Card</li><li>• This trip can be suppressed by setting Pr <b>mm.000</b> to 9666 and resetting the drive</li></ul>							
Card Rating	NV Media Card Trip; The voltage and / or current rating of the source and destination drives are different							
186	<p>The <i>Card Rating</i> trip indicates that parameter data is being transferred from the NV Media Card to the drive, but the current and / or voltage ratings are different between source and destination drives. This trip also applies if a compare (using Pr <b>mm.000</b> set to 8yyy) is attempted between the data block on a NV Media Card and the drive. The Card Rating trip does not stop the data transfer but is a warning that rating specific parameters with the RA attribute may not be transferred to the destination drive.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Reset the drive to clear the trip</li><li>• Ensure that the drive rating dependent parameters have transferred correctly</li></ul>							
Card Read Only	NV Media Card has the Read Only bit set							
181	<p>The <i>Card Read Only</i> trip indicates that an attempt has been made to modify a read-only NV Media Card or a read-only data block. A NV Media Card is read-only if the read-only flag has been set.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Clear the read only flag by setting Pr <b>mm.000</b> to 9777 and reset the drive. This will clear the read-only flag for all data blocks in the NV Media Card</li></ul>							
Card Slot	NV Media Card trip; Option module file transfer has failed							
174	<p>The Card Slot trip is initiated, if the transfer of an option module file to or from a module failed because the option module does not respond correctly. If this happens this trip is produced with the sub-trip number indicating the option module slot number.</p>							
Control Word	Trip initiated from the <i>Control Word</i> (06.042)							
35	<p>The <i>Control Word</i> trip is initiated by setting bit 12 on the control word in Pr <b>06.042</b> when the control word is enabled (Pr <b>06.043</b> = On).</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Check the value of Pr <b>06.042</b>.</li><li>• Disable the control word in <i>Control Word Enable</i> (Pr <b>06.043</b>) Bit 12 of the control word set to a one causes the drive to trip on Control Word When the control word is enabled, the trip can only be cleared by setting bit 12 to zero</li></ul>							
Current Offset	Current feedback offset error							
225	<p>The <i>Current Offset</i> trip indicates that the current offset is too large to be trimmed.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Ensure that there is no possibility of current flowing in the output phases of the drive when the drive is not enabled</li><li>• Hardware fault – Contact the supplier of the drive</li></ul>							
Data Changing	Drive parameters are being changed							
97	<p>A user action or a file system write is active that is changing the drive parameters and the drive has been commanded to enable, i.e. <i>Drive Active</i> (10.002) = 1.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Ensure the drive is not enabled when defaults are loading</li></ul>							
Derivative ID	Derivative file error							
246	<p>Derivative file error with sub-trips:</p> <table><tr><th>Sub-trip</th><th>Reason</th></tr><tr><td>1</td><td>Derivative file different</td></tr><tr><td>2</td><td>Derivative file missing</td></tr></table>		Sub-trip	Reason	1	Derivative file different	2	Derivative file missing
Sub-trip	Reason							
1	Derivative file different							
2	Derivative file missing							

Derivative Image	Derivative product image error		
248	The <i>Derivative Image</i> trip indicates that an error has been detected in the derivative product image. The reason for the trip can be identified by the sub-trip number.		
	Sub-trip	Reason	Comments
	1	Divide by zero	
	2	Undefined trip	
	3	Attempted fast parameter access set-up with non-existent parameter	
	4	Attempted access to non-existent parameter	
	5	Attempted write to read-only parameter	
	6	Attempted and over-range write	
	7	Attempted read from write-only parameter	
	30	The image has failed because either its CRC is incorrect, or there are less than 6 bytes in the image or the image header version is less than 5	Occurs when the drive powers-up or the image is programmed. The image tasks will not run
	31	The image requires more RAM for heap and stack than can be provided by the drive.	As 30
	32	The image requires an OS function call that is higher than the maximum allowed.	As 30
	33	The ID code within the image is not valid	As 30
	34	The derivative image has been changed for an image with a different derivative number	As 30
	40	The timed task has not completed in time and has been suspended	
	41	Undefined function called, i.e. a function in the host system vector table that has not been assigned	As 40
	51	Core menu customization table CRC check failed	As 30
	52	Customizable menu table CRC check failed	As 30
	53	Customizable menu table changed	Occurs when the drive powers-up or the image is programmed and the table has changed. Defaults are loaded for the derivative menu and the trip will keep occurring until drive parameters are saved.
	61	The option module installed in slot 1 is not allowed with the derivative image	As 30
	80	Image is not compatible with the control board	Initiated from within the image code
	81	Image is not compatible with the control board serial number	As 80
Recommended actions:			
<ul style="list-style-type: none"> <li>Contact the supplier of the drive</li> </ul>			
Destination	Two or more parameters are writing to the same destination parameter		
199	The <i>Destination</i> trip indicates that destination output parameters of two or more logic functions (Menus 7, 8, 9, 12 or 14) within the drive are writing to the same parameter. <b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Set Pr <b>mm.000</b> to 'Destinations' or 12001 and check all visible parameters in all menus for parameter write conflicts</li> </ul>		
Drive config	Drive configuration		
232	The hardware ID does not match the user software ID.		



EEPROM Fail	Default parameters have been loaded																			
31	The <i>EEPROM Fail</i> trip indicates that default parameters have been loaded. The exact cause/reason of the trip can be identified from the sub-trip number.																			
	Sub-trip	Reason	1	The most significant digit of the internal parameter database version number has changed	2	The CRC's applied to the parameter data stored in internal non-volatile memory indicate that a valid set of parameters cannot be loaded	3	The drive mode restored from internal non-volatile memory is outside the allowed range for the product or the derivative image does not allow the previous drive mode	4	The drive derivative image has changed	5	The power stage hardware has changed	6	The internal I/O hardware has changed	7	Reserved	8	The control board hardware has changed	9	The checksum on the non-parameter area of the EEPROM has failed
	Sub-trip	Reason																		
	1	The most significant digit of the internal parameter database version number has changed																		
	2	The CRC's applied to the parameter data stored in internal non-volatile memory indicate that a valid set of parameters cannot be loaded																		
	3	The drive mode restored from internal non-volatile memory is outside the allowed range for the product or the derivative image does not allow the previous drive mode																		
	4	The drive derivative image has changed																		
	5	The power stage hardware has changed																		
	6	The internal I/O hardware has changed																		
	7	Reserved																		
8	The control board hardware has changed																			
9	The checksum on the non-parameter area of the EEPROM has failed																			
<b>Recommended actions:</b>																				
<ul style="list-style-type: none"><li>• Default the drive and perform a reset</li><li>• Allow sufficient time to perform a save before the supply to the drive is removed</li><li>• If the trip persists - return drive to supplier</li></ul>																				
External Trip	An External trip is initiated																			
6	An <i>External Trip</i> trip has occurred. The cause of the trip can be identified from the sub trip number displayed after the trip string. See table below. An external trip can also be initiated by writing a value of 6 in Pr <b>10.038</b> .																			
	Sub-trip	Reason	1	<i>External Trip</i> (10.032) = 1																
	Sub-trip	Reason																		
1	<i>External Trip</i> (10.032) = 1																			
<b>Recommended actions:</b>																				
<ul style="list-style-type: none"><li>• Check the value of Pr <b>10.032</b>.</li><li>• Select 'Destinations' (or enter 12001) in Pr <b>mm.000</b> and check for a parameter controlling Pr <b>10.032</b>.</li><li>• Ensure Pr <b>10.032</b> or Pr <b>10.038</b> (= 6) is not being controlled by serialcomms</li></ul>																				
Fan Fail	Fan fail																			
173	Recommended actions:																			
	<ul style="list-style-type: none"><li>• Check that the fan is installed and connected correctly.</li><li>• Check that the fan is not obstructed.</li><li>• Contact the supplier of the drive to replace the fan.</li></ul>																			
File changed	File changed																			
247	Recommended action:																			
	<ul style="list-style-type: none"><li>• Power cycle the drive.</li></ul>																			
FW incompatible	Firmware incompatibility																			
237	The <i>FW incompatible</i> trip indicates that the user firmware is incompatible with the power firmware.																			
	<b>Recommended actions:</b>																			
	<ul style="list-style-type: none"><li>• Re-program the drive with the latest version of the drive firmware for Unidrive M400.</li></ul>																			
HF01	Data processing error: CPU hardware fault																			
	The <i>HF01</i> trip indicates that a CPU address error has occurred. This trip indicates that the control PCB on the drive has failed.																			
	<b>Recommended actions:</b>																			
	<ul style="list-style-type: none"><li>• Hardware fault – Contact the supplier of the drive</li></ul>																			
HF02	Data processing error: CPU memory management fault																			
	The <i>HF02</i> trip indicates that a DMAC address error has occurred. This trip indicates that the control PCB on the drive has failed.																			
	<b>Recommended actions:</b>																			
	<ul style="list-style-type: none"><li>• Hardware fault – Contact the supplier of the drive</li></ul>																			
HF03	Data processing error: CPU has detected a bus fault																			
	The <i>HF03</i> trip indicates that a bus fault has occurred. This trip indicates that the control PCB on the drive has failed.																			
	<b>Recommended actions:</b>																			
	<ul style="list-style-type: none"><li>• Hardware fault – Contact the supplier of the drive</li></ul>																			
HF04	Data processing error: CPU has detected a usage fault																			
	The <i>HF04</i> trip indicates that a usage fault has occurred. This trip indicates that the control PCB on the drive has failed.																			
	<b>Recommended actions:</b>																			
	<ul style="list-style-type: none"><li>• Hardware fault – Contact the supplier of the drive</li></ul>																			

Safety information	Product information	Mechanical installation	Electrical installation	Getting started	Basic parameters	Running the motor	Optimization	NV Media Card Operation	Onboard PLC	Advanced parameters	Technical data	Diagnostics	UL listing information									
HF05		Reserved																				
HF06		Reserved																				
HF07		Data processing error: Watchdog failure																				
		The HF07 trip indicates that a watchdog failure has occurred. This trip indicates that the control PCB on the drive has failed.																				
		Recommended actions:																				
		• Hardware fault – Contact the supplier of the drive																				
HF08		Data processing error: CPU Interrupt crash																				
		The HF08 trip indicates that a CPU interrupt crash has occurred. This trip indicates that the control PCB on the drive has failed. The crash level is indicated by the sub-trip number.																				
		Recommended actions:																				
		• Hardware fault – Contact the supplier of the drive																				
HF09		Data processing error: Free store overflow																				
		The HF09 trip indicates that a free store overflow has occurred. This trip indicates that the control PCB on the drive has failed.																				
		Recommended actions:																				
		• Hardware fault – Contact the supplier of the drive																				
HF10		Reserved																				
HF11		Data processing error: Non-volatile memory comms error																				
		The HF11 trip indicates that a non-volatile memory comms error has occurred.																				
		<table><tr><th>Sub-trip</th><th>Reason</th><th>Recommended action</th></tr><tr><td>1</td><td>Non-volatile memory comms error.</td><td>Hardware fault – contact the supplier of the drive.</td></tr><tr><td>2</td><td>EEPROM size is incompatible with the user firmware.</td><td>Re-program drive with compatible user firmware.</td></tr></table>												Sub-trip	Reason	Recommended action	1	Non-volatile memory comms error.	Hardware fault – contact the supplier of the drive.	2	EEPROM size is incompatible with the user firmware.	Re-program drive with compatible user firmware.
Sub-trip	Reason	Recommended action																				
1	Non-volatile memory comms error.	Hardware fault – contact the supplier of the drive.																				
2	EEPROM size is incompatible with the user firmware.	Re-program drive with compatible user firmware.																				
HF12		Data processing error: Main program stack overflow																				
		The HF12 trip indicates that the main program stack over flow has occurred. The stack can be identified by the sub-trip number. This trip indicates that the control PCB on the drive has failed.																				
		<table><tr><th>Sub-trip</th><th>Stack</th></tr><tr><td>1</td><td>Freewheeling tasks</td></tr><tr><td>2</td><td>Reserved</td></tr><tr><td>3</td><td>Main system interrupts</td></tr></table>												Sub-trip	Stack	1	Freewheeling tasks	2	Reserved	3	Main system interrupts	
Sub-trip	Stack																					
1	Freewheeling tasks																					
2	Reserved																					
3	Main system interrupts																					
		Recommended actions:																				
		• Hardware fault - Contact the supplier of the drive																				
HF13		Reserved																				
HF14		Reserved																				
HF15		Reserved																				
HF16		Data processing error: RTOS error																				
		The HF16 trip indicates that a RTOS error has occurred. This trip indicates that the control PCB on the drive has failed.																				
		Recommended actions:																				
		• Hardware fault – Contact the supplier of the drive																				
HF17		Reserved																				

HF18	Data processing error: Internal flash memory has failed																		
	The HF18 trip indicates that the internal flash memory has failed when writing option module parameter data. The reason for the trip can be identified by the sub-trip number.																		
	<table><tr><th>Sub-trip</th><th>Reason</th></tr><tr><td>1</td><td>Option module initialization timed out</td></tr><tr><td>2</td><td>Programming error while writing menu in flash</td></tr><tr><td>3</td><td>Erase flash block containing setup menus failed</td></tr><tr><td>4</td><td>Erase flash block containing application menus failed</td></tr><tr><td>5</td><td>Incorrect setup menu CRC contained in flash</td></tr><tr><td>6</td><td>Incorrect application menu CRC contained in flash</td></tr></table>	Sub-trip	Reason	1	Option module initialization timed out	2	Programming error while writing menu in flash	3	Erase flash block containing setup menus failed	4	Erase flash block containing application menus failed	5	Incorrect setup menu CRC contained in flash	6	Incorrect application menu CRC contained in flash				
Sub-trip	Reason																		
1	Option module initialization timed out																		
2	Programming error while writing menu in flash																		
3	Erase flash block containing setup menus failed																		
4	Erase flash block containing application menus failed																		
5	Incorrect setup menu CRC contained in flash																		
6	Incorrect application menu CRC contained in flash																		
	Recommended actions:																		
	<ul style="list-style-type: none"><li>Hardware fault - Contact the supplier of the drive</li></ul>																		
HF19	Data processing error: CRC check on the firmware has failed																		
	HF19 trip indicates that the CRC check on the drive firmware has failed.																		
	Recommended actions:																		
	<ul style="list-style-type: none"><li>Re-program the drive</li><li>Hardware fault - Contact the supplier of the drive</li></ul>																		
Hot Rect/Brake	Hot rectifier/brake																		
250	Over-temperature detected on input rectifier or braking IGBT.																		
I cal. range	Current calibration range																		
231	Current calibration range error.																		
I/O Overload	Digital output overload																		
26	<p>The <i>I/O Overload</i> trip indicates that the total current drawn from 24 V user supply or from the digital output has exceeded the limit. A trip is initiated if the following condition is met:</p> <ul style="list-style-type: none"><li>Maximum output current from one digital output is 100 mA.</li></ul> <p>Recommended actions:</p> <ul style="list-style-type: none"><li>Check total loads on digital outputs</li><li>Check control wiring is correct</li><li>Check output wiring is undamaged</li></ul>																		
Keypad Mode	Keypad has been removed when the drive is receiving the reference from the keypad																		
34	<p>The <i>Keypad Mode</i> trip indicates that the drive is in keypad mode [<i>Reference Selector</i> (01.014) = 4 or 6] and the keypad has been removed or disconnected from the drive.</p> <p>Recommended actions:</p> <ul style="list-style-type: none"><li>Re-install keypad and reset</li><li>Change <i>Reference Selector</i> (01.014) to select the reference from another source</li></ul>																		
LF Power Comms	Communication has been lost / errors detected between power, control and rectifier modules																		
90	<p>This trip is initiated if there is no communications between power, control or the rectifier module or if excessive communication errors have been detected. The reason for the trip can be identified by the sub-trip number.</p> <table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th></tr><tr><td>Control system</td><td>00</td><td>0</td><td>01: No communications between the control system and the power system.</td></tr><tr><td>Control system</td><td>00</td><td>0</td><td>02: Excessive communication errors between the control system and power system.</td></tr><tr><td>Control system</td><td>01</td><td>1</td><td>00: Excessive communications errors detected by the rectifier module.</td></tr></table> <p>Recommended actions:</p> <ul style="list-style-type: none"><li>Hardware fault - contact the supplier of the drive.</li></ul>			Source	xx	y	zz	Control system	00	0	01: No communications between the control system and the power system.	Control system	00	0	02: Excessive communication errors between the control system and power system.	Control system	01	1	00: Excessive communications errors detected by the rectifier module.
Source	xx	y	zz																
Control system	00	0	01: No communications between the control system and the power system.																
Control system	00	0	02: Excessive communication errors between the control system and power system.																
Control system	01	1	00: Excessive communications errors detected by the rectifier module.																
Motor Too Hot	Output current overload timed out (I²t)																		
20	<p>The <i>Motor Too Hot</i> trip indicates a motor thermal overload based on the output current (Pr <b>05.007</b>) and motor thermal time constant (Pr <b>04.015</b>). Pr <b>04.019</b> displays the motor temperature as a percentage of the maximum value. The drive will trip on <i>Motor Too Hot</i> when Pr <b>04.019</b> gets to 100 %.</p> <p>Recommended actions:</p> <ul style="list-style-type: none"><li>Ensure the load is not jammed / sticking</li><li>Check the load on the motor has not changed</li><li>Tune the motor rated speed parameter (Pr <b>5.008</b>) (RFC-A mode only)</li><li>Ensure the motor rated current is not zero</li></ul>																		

No power board	No power board										
236	<p>No communication between the power and control boards.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Check connection between power and control board.</li></ul>										
OHt Brake	Braking IGBT over-temperature										
101	<p>The <i>OHt Brake</i> over-temperature trip indicates that braking IGBT over-temperature has been detected based on software thermal model.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Check braking resistor value is greater than or equal to the minimum resistance value</li></ul>										
OHt Control	Control stage over temperature										
219	<p>This trip indicates that a control stage over-temperature has been detected if Cooling Fan control (06.045) = 0.</p> <p>Recommended actions:</p> <ul style="list-style-type: none"><li>• Increase ventilation by setting Cooling Fan control (06.045) &gt; 0</li></ul>										
OHt dc bus	DC bus over temperature										
27	<p>The <i>OHt dc bus</i> trip indicates a DC bus component over temperature based on a software thermal model. The drive includes a thermal protection system to protect the DC bus components within the drive. This includes the effects of the output current and DC bus ripple. The estimated temperature is displayed as a percentage of the trip level in Pr <b>07.035</b>. If this parameter reaches 100 % then an <i>OHt dc bus</i> trip is initiated. The drive will attempt to stop the motor before tripping. If the motor does not stop in 10 seconds the drive trips immediately.</p> <table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th><th>Description</th></tr><tr><td>Control system</td><td>00</td><td>2</td><td>00</td><td>DC bus thermal model gives trip with sub-trip 0</td></tr></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Check the AC supply voltage balance and levels</li><li>• Check DC bus ripple level</li><li>• Reduce duty cycle</li><li>• Reduce motor load</li><li>• Check the output current stability. If unstable;<ul style="list-style-type: none"><li>Check the motor map settings with motor nameplate (Pr <b>05.006</b>, Pr <b>05.007</b>, Pr <b>05.008</b>, Pr <b>05.009</b>, Pr <b>05.010</b>, Pr <b>05.011</b>) – (All Modes)</li><li>Disable slip compensation (Pr <b>05.027</b> = 0) – (Open loop)</li><li>Disable dynamic V to F operation (Pr <b>05.013</b> = 0) - (Open loop)</li><li>Select fixed boost (Pr <b>05.014</b> = Fixed) – (Open loop)</li><li>Select high stability space vector modulation (Pr <b>05.019</b> = 1) – (Open loop)</li><li>Disconnect the load and complete a rotating auto-tune (Pr <b>05.012</b>)</li><li>Reduce frequency loop gains (Pr <b>03.010</b>, Pr <b>03.011</b>, Pr <b>03.012</b>) – (RFC-A)</li></ul></li></ul>	Source	xx	y	zz	Description	Control system	00	2	00	DC bus thermal model gives trip with sub-trip 0
Source	xx	y	zz	Description							
Control system	00	2	00	DC bus thermal model gives trip with sub-trip 0							
OHt Inverter	Inverter over temperature based on thermal model										
21	<p>This trip indicates that an IGBT junction over-temperature has been detected based on a software thermal model.</p> <table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th><th>Description</th></tr><tr><td>Control system</td><td>00</td><td>1</td><td>00</td><td>Inverter thermal model gives {OHt Inverter} trip with sub-trip 0</td></tr></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Reduce the selected drive switching frequency</li><li>• Ensure <i>Auto-switching Frequency Change Disable</i> (05.035) is set to OFF</li><li>• Reduce duty cycle</li><li>• Increase acceleration / deceleration rates</li><li>• Reduce motor load</li><li>• Check DC bus ripple</li><li>• Ensure all three input phases are present and balanced</li></ul>	Source	xx	y	zz	Description	Control system	00	1	00	Inverter thermal model gives {OHt Inverter} trip with sub-trip 0
Source	xx	y	zz	Description							
Control system	00	1	00	Inverter thermal model gives {OHt Inverter} trip with sub-trip 0							

Oht Power		Power stage over temperature													
22		This trip indicates that a power stage over-temperature has been detected. From the sub-trip 'xxyz', the Thermistor location is identified by 'zz'.													
		<table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th><th>Description</th></tr><tr><td>Power system</td><td>01</td><td>0</td><td>zz</td><td>Thermistor location in the drive defined by zz</td></tr></table>				Source	xx	y	zz	Description	Power system	01	0	zz	Thermistor location in the drive defined by zz
		Source	xx	y	zz	Description									
		Power system	01	0	zz	Thermistor location in the drive defined by zz									
<b>Recommended actions:</b>															
<ul style="list-style-type: none"><li>• Check enclosure / drive fans are still functioning correctly</li><li>• Force the heatsink fans to run at maximum speed</li><li>• Check enclosure ventilation paths</li><li>• Check enclosure door filters</li><li>• Increase ventilation</li><li>• Reduce the drive switching frequency</li><li>• Reduce duty cycle</li><li>• Increase acceleration / deceleration rates</li><li>• Reduce motor load</li><li>• Check the derating tables and confirm the drive is correctly sized for the application.</li><li>• Use a drive with larger current / power rating</li></ul>															
Oht Rectifier		Rectifier over temperature													
102		The <i>Oht Rectifier</i> trip indicates that a rectifier over-temperature has been detected. The thermistor location can be identified from the sub-trip number.													
		<table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th><th>Description</th></tr><tr><td>Power system</td><td>Power module number</td><td>Rectifier number</td><td>zz</td><td>Thermistor location defined by zz</td></tr></table>				Source	xx	y	zz	Description	Power system	Power module number	Rectifier number	zz	Thermistor location defined by zz
		Source	xx	y	zz	Description									
		Power system	Power module number	Rectifier number	zz	Thermistor location defined by zz									
<b>Recommend actions:</b>															
<ul style="list-style-type: none"><li>• Check the motor and motor cable insulation with an insulation tester</li><li>• Fit an output line reactor or sinusoidal filter</li><li>• Force the heatsink fans to run at maximum speed by setting Pr <b>06.045</b> = 1</li><li>• Check enclosure / drive fans are still functioning correctly</li><li>• Check enclosure ventilation paths</li><li>• Check enclosure door filters</li><li>• Increase ventilation</li><li>• Increase acceleration / deceleration rates</li><li>• Reduce duty cycle</li><li>• Reduce motor load</li></ul>															
OI ac		Instantaneous output over current detected													
3		The instantaneous drive output current has exceeded VM_DRIVE_CURRENT_MAX.													
		<table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th><th>Description</th></tr><tr><td>Control system</td><td>00</td><td>0</td><td>00</td><td>Instantaneous over-current trip when the measured a.c. current exceeds VM_DRIVE_CURRENT[MAX].</td></tr></table>				Source	xx	y	zz	Description	Control system	00	0	00	Instantaneous over-current trip when the measured a.c. current exceeds VM_DRIVE_CURRENT[MAX].
		Source	xx	y	zz	Description									
		Control system	00	0	00	Instantaneous over-current trip when the measured a.c. current exceeds VM_DRIVE_CURRENT[MAX].									
<b>Recommended actions/checks:</b>															
<ul style="list-style-type: none"><li>• Increase acceleration/deceleration rate</li><li>• If seen during auto-tune reduce the voltage boost</li><li>• Check for short circuit on the output cabling</li><li>• Check integrity of the motor insulation using an insulation tester</li><li>• Is the motor cable length within limits for the frame size?</li><li>• Reduce the values in the frequency loop gain parameters - (Pr <b>03.010</b>, <b>03.011</b>, <b>03.012</b>) or (Pr <b>03.013</b>, <b>03.014</b>, <b>03.015</b>)</li><li>• Reduce the values in the current loop gain parameters</li></ul>															

OI Snubber	Snubber over-current detected			
92	This trip indicates that an over-current condition has been detected in the rectifier snubbing circuit, The exact cause of the trip can be identified by the sub-trip number.			
	Source	xx	y	zz
	Power system	01	1	00: Rectifier snubber over-current trip detected.
<b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Ensure the internal EMC filter is installed.</li> <li>Ensure the motor cable length does not exceed the maximum for selected switching frequency.</li> <li>Check for supply voltage imbalance.</li> <li>Check for supply disturbance such as notching from a DC drive.</li> <li>Check the motor and motor cable insulation with a Megger.</li> <li>Fit an output line reactor or sinusoidal filter</li> </ul>				
OI.Brake	Braking IGBT over current detected: short circuit protection for the braking IGBT activated			
4	The <i>OI.Brake</i> trip indicates that over current has been detected in braking IGBT or braking IGBT protection has been activated.			
	Source	xx	y	zz
	Power system	01	0	00 Braking IGBT instantaneous over-current trip
<b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Check brake resistor wiring</li> <li>Check braking resistor value is greater than or equal to the minimum resistance value</li> <li>Check braking resistor insulation</li> </ul>				
OI.dc	Power module over current detected from IGBT on state voltage monitoring			
109	The <i>OI.dc</i> trip indicates that the short circuit protection for the drive output stage has been activated.			
	<b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Disconnect the motor cable at the drive end and check the motor and cable insulation with an insulation tester</li> <li>Replace the drive</li> </ul>			
Option Disable	Option module does not acknowledge during drive mode changeover			
215	The <i>Option Disable</i> trip indicates that the option module did not acknowledge notifying the drive that communications with the drive has been stopped during the drive mode changeover with in the allocated time.			
	<b>Recommended trip:</b> <ul style="list-style-type: none"> <li>Reset the trip</li> <li>If the trip persists replace the option module</li> </ul>			
Out Phase Loss	Output phase loss detected			
98	The <i>Out Phase Loss</i> trip indicates that a phase loss has been detected at the drive output. If <i>Output Phase Loss Detection Enable</i> (06.059) = 1 then output phase loss is detected as follows:			
	<ol style="list-style-type: none"> <li>When the drive is enabled short pulses are applied to make sure each output phase is connected.</li> <li>During running the output current is monitored and the output phase loss condition is detected if the current contains more than TBD % negative phase sequence current for TBDs.</li> </ol>			
	<b>Recommended action:</b> <ul style="list-style-type: none"> <li>Check motor and drive connections</li> <li>To disable the trip set <i>Output Phase Loss Detection Enable</i> (06.059) = 0</li> </ul>			
Output phase s/c	Output phase short-circuit			
228	Over-current detected on drive output when enabled. Possible motor ground fault.			
	<b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Check for short circuit on the output cabling</li> <li>Check integrity of the motor insulation using an insulation tester</li> <li>Is the motor cable length within limits for the frame size?</li> </ul>			
Over Speed	Motor frequency has exceeded the over frequency threshold			
7	In open loop mode, if the <i>Post-ramp Reference</i> (02.001) exceeds the threshold set in the <i>Over Frequency Threshold</i> (03.008) in either direction an Over Speed trip is produced. In RFC-A mode, if the estimated frequency (03.002) exceeds the Over Frequency Threshold in Pr <b>03.008</b> in either direction an Over Speed trip is produced. If Pr <b>03.008</b> is set to 0.0 the threshold is then equal to 1.2 x the value set in Pr <b>01.006</b> .			
	<b>Recommended actions:</b> <ul style="list-style-type: none"> <li>Reduce the <i>Frequency Controller Proportional Gain</i> (03.010) to reduce the speed overshoot (RFC-A mode only)</li> </ul>			

Over Volts		DC bus voltage has exceeded the peak level or maximum continuous level for 15 seconds																
2	The <i>Over Volts</i> trip indicates that the DC bus voltage has exceeded the VM_DC_VOLTAGE[MAX] or VM_DC_VOLTAGE_SET[MAX] for 15 s. The trip threshold varies depending on voltage rating of the drive as shown below.																	
	<table><tr><th>Voltage rating</th><th>VM_DC_VOLTAGE[MAX]</th><th>VM_DC_VOLTAGE_SET[MAX]</th></tr><tr><td>100</td><td>415</td><td>410</td></tr><tr><td>200</td><td>415</td><td>410</td></tr><tr><td>400</td><td>830</td><td>815</td></tr></table>			Voltage rating	VM_DC_VOLTAGE[MAX]	VM_DC_VOLTAGE_SET[MAX]	100	415	410	200	415	410	400	830	815			
	Voltage rating	VM_DC_VOLTAGE[MAX]	VM_DC_VOLTAGE_SET[MAX]															
	100	415	410															
	200	415	410															
	400	830	815															
Sub-trip Identification																		
<table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th></tr><tr><td>Control system</td><td>00</td><td>0</td><td>01: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].</td></tr><tr><td>Control system</td><td>00</td><td>0</td><td>02: Time delayed trip indicating that the DC bus voltage is above VM_DC_VOLTAGE_SET[MAX].</td></tr><tr><td>Power system</td><td>01</td><td>0</td><td>00: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].</td></tr></table>			Source	xx	y	zz	Control system	00	0	01: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].	Control system	00	0	02: Time delayed trip indicating that the DC bus voltage is above VM_DC_VOLTAGE_SET[MAX].	Power system	01	0	00: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].
Source	xx	y	zz															
Control system	00	0	01: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].															
Control system	00	0	02: Time delayed trip indicating that the DC bus voltage is above VM_DC_VOLTAGE_SET[MAX].															
Power system	01	0	00: Instantaneous trip when the DC bus voltage exceeds VM_DC_VOLTAGE[MAX].															
Recommended actions:																		
<ul style="list-style-type: none"><li>• Increase deceleration ramp (Pr <b>00.004</b>)</li><li>• Decrease the braking resistor value (staying above the minimum value)</li><li>• Check nominal AC supply level</li><li>• Check for supply disturbances which could cause the DC bus to rise</li><li>• Check motor insulation using a insulation tester</li></ul>																		
Phase Loss		Supply phase loss																
32	The <i>Phase Loss</i> trip indicates that the drive has detected an input phase loss or large supply imbalance. The drive will attempt to stop the motor before this trip is initiated. If the motor cannot be stopped in 10 seconds the trip occurs immediately. The <i>Phase Loss</i> trip works by monitoring the ripple voltage on the DC bus of the drive, if the DC bus ripple exceeds the threshold, the drive will trip on Phase Loss. Potential causes of the DC bus ripple are input phase loss, Large supply impedance and severe output current instability.																	
	<table><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th></tr><tr><td>Control system</td><td>00</td><td>0</td><td>00: Phase loss detected based on control system feedback. The drive attempts to stop the drive before tripping unless bit 2 of <i>Action On Trip Detection</i> (10.037) is set to one.</td></tr></table>			Source	xx	y	zz	Control system	00	0	00: Phase loss detected based on control system feedback. The drive attempts to stop the drive before tripping unless bit 2 of <i>Action On Trip Detection</i> (10.037) is set to one.							
	Source	xx	y	zz														
	Control system	00	0	00: Phase loss detected based on control system feedback. The drive attempts to stop the drive before tripping unless bit 2 of <i>Action On Trip Detection</i> (10.037) is set to one.														
Input phase loss detection can be disabled when the drive is required to operate from the DC supply or from a single phase supply in <i>Input Phase Loss Detection Mode</i> (06.047).																		
Recommended actions:																		
<ul style="list-style-type: none"><li>• Check the AC supply voltage balance and level at full load</li><li>• Check the DC bus ripple level with an isolated oscilloscope</li><li>• Check the output current stability</li><li>• Reduce the duty cycle</li><li>• Reduce the motor load</li><li>• Disable the phase loss detection, set Pr <b>06.047</b> to 2.</li></ul>																		
Power Board HF		Power board HF																
235	Power processor hardware fault.																	
	Recommended action:																	
<ul style="list-style-type: none"><li>• Hardware fault - Contact the supplier of the drive</li></ul>																		
Power Comms		Communication has been lost / errors detected between power control																
93	The <i>Power Comms</i> trip is initiated if there is no communications between power control. The reason for the trip can be identified by the sub-trip number.																	
	<table><tr><th>Sub-trip</th><th>Reason</th></tr><tr><td>1</td><td>PLL operating range out of lock</td></tr><tr><td>2</td><td>Power board lost communications with user board</td></tr><tr><td>3</td><td>User board lost communication with power board</td></tr><tr><td>4</td><td>Communication CRC error</td></tr></table>			Sub-trip	Reason	1	PLL operating range out of lock	2	Power board lost communications with user board	3	User board lost communication with power board	4	Communication CRC error					
	Sub-trip	Reason																
	1	PLL operating range out of lock																
	2	Power board lost communications with user board																
	3	User board lost communication with power board																
4	Communication CRC error																	
Recommended actions:																		
<ul style="list-style-type: none"><li>• Hardware fault – Contact the supplier of the drive</li></ul>																		



Power Data		Power system configuration data error			
220	The <i>Power Data</i> trip indicates that there is an error in the configuration data stored in the power system.				
	Source	xx	y	zz	Description
	Control system	00	0	01	No data was obtained from the power board.
	Control system	00	0	02	There is no data table in node 1.
	Control system	00	0	03	The power system data table is bigger than the space available in the control pod to store it.
	Control system	00	0	04	The size of the table given in the table is incorrect.
	Control system	00	0	05	Table CRC error.
	Control system	00	0	06	The version number of the generator software that produced the table is too low.
	Control system	0	0	07	The power data table failed to be stored in the power board.
	Power system	01	0	00	The power data table used internally by the power module has an error.
	Power system	01	0	01	The power data table that is uploaded to the control system on power up has an error.
	Power system	01	0	02	The power data table used internally by the power module does not match the hardware identification of the power module.
Recommended actions:					
• Hardware fault – Contact the supplier of the drive					
Power Down Save		Power down save error			
37	The <i>Power Down Save</i> trip indicates that an error has been detected in the power down save parameters saved in non-volatile memory.				
	Recommended actions:				
• Perform a 1001 save in Pr <b>mm.000</b> to ensure that the trip doesn't occur the next time the drive is powered up.					
PSU		Internal power supply fault			
5	The <i>PSU</i> trip indicates that one or more internal power supply rails are outside limits or overloaded.				
	Source	xx	y	zz	Description
	Control system	00	0	00	Internal power supply overload.
	Power system	01	1		
Recommended actions:					
• Remove the option module and perform a reset					
• There is a hardware fault within the drive – return the drive to the supplier					
Reserved		Reserved trips			
14-17 11 09 01 94 - 95 103 - 108 191 - 198 168 - 173 238 - 245 23, 39, 99, 176, 205 - 214 223 - 224	These trip numbers are reserved trip numbers for future use. These trips should not be used by the user application programs.				
	Trip Number		Description		
	01		Reserved resettable trip		
	94 - 95		Reserved resettable trip		
	103 - 108		Reserved resettable trip		
	191 – 198		Reserved resettable trip		
	168 - 173		Reserved resettable trip		
	238 - 245		Reserved non-resettable trip		

Resistance	Measured resistance has exceeded the parameter range																	
33	<p>The <i>Resistance</i> trip indicates that the measured stator resistance during an auto-tune test has exceeded the maximum possible value of <i>Stator Resistance</i> (05.017).</p> <p>The stationary auto-tune is initiated using the auto-tune function (Pr <b>05.012</b>) or in open loop vector mode (Pr <b>05.014</b>) on the first run command after power up in mode 4 (Ur_I) or on every run command in modes 0 (Ur_S) or 3 (Ur_Auto). This trip can occur if the motor is very small in comparison to the rating of the drive.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Check the motor cable / connections</li><li>• Check the integrity of the motor stator winding using a insulation tester</li><li>• Check the motor phase to phase resistance at the drive terminals</li><li>• Check the motor phase to phase resistance at the motor terminals</li><li>• Ensure the stator resistance of the motor falls within the range of the drive model</li><li>• Select fixed boost mode (Pr <b>05.014</b> = Fd) and verify the output current waveforms with an oscilloscope</li><li>• Replace the motor</li></ul>																	
Slot 1 Different	Option module in option slot 1 has changed																	
204	<p>The <i>Slot 1 Different</i> trip indicates that the option module in option slot 1 on the drive is a different type to that installed when parameters were last saved on the drive. The reason for the trip can be identified by the sub-trip number.</p> <table><tr><th>Sub-trip</th><th>Reason</th></tr><tr><td>1</td><td>No module was installed previously</td></tr><tr><td>2</td><td>A module with the same identifier is installed, but the set-up menu for this option slot has been changed, and so default parameters have been loaded for this menu.</td></tr><tr><td>3</td><td>A module with the same identifier is installed, but the applications menu for this option slot has been changed, and so default parameters have been loaded for this menu.</td></tr><tr><td>4</td><td>A module with the same identifier is installed, but the set-up and applications menu for this option slot have been changed, and so default parameters have been loaded for these menus.</td></tr><tr><td>&gt;99</td><td>Shows the identifier of the module previously installed.</td></tr></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Turn off the power, ensure the correct option module is installed in the option slot and re-apply the power.</li><li>• Confirm that the currently installed option module is correct, ensure option module parameters are set correctly and perform a user save in Pr <b>mm.000</b>.</li></ul>		Sub-trip	Reason	1	No module was installed previously	2	A module with the same identifier is installed, but the set-up menu for this option slot has been changed, and so default parameters have been loaded for this menu.	3	A module with the same identifier is installed, but the applications menu for this option slot has been changed, and so default parameters have been loaded for this menu.	4	A module with the same identifier is installed, but the set-up and applications menu for this option slot have been changed, and so default parameters have been loaded for these menus.	>99	Shows the identifier of the module previously installed.				
Sub-trip	Reason																	
1	No module was installed previously																	
2	A module with the same identifier is installed, but the set-up menu for this option slot has been changed, and so default parameters have been loaded for this menu.																	
3	A module with the same identifier is installed, but the applications menu for this option slot has been changed, and so default parameters have been loaded for this menu.																	
4	A module with the same identifier is installed, but the set-up and applications menu for this option slot have been changed, and so default parameters have been loaded for these menus.																	
>99	Shows the identifier of the module previously installed.																	
Slot 1 Error	Option module in option slot 1 has detected a fault																	
202	<p>The <i>Slot 1 Error</i> trip indicates that the option module in option slot 1 on the drive has detected an error. The reason for the error can be identified by the sub-trip number.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• See relevant <i>option module User Guide</i> for details of the trip</li></ul>																	
Slot 1 HF	Option module 1 hardware fault																	
200	<p>The <i>Slot 1 HF</i> trip indicates that the option module in option slot 1 on the drive has indicated a hardware fault. The possible causes of the trip can be identified by the sub-trip number.</p> <table><tr><th>Sub-trip</th><th>Reason</th></tr><tr><td>1</td><td>The module category cannot be identified</td></tr><tr><td>2</td><td>All the required customized menu table information has not been supplied or the tables supplied are corrupt</td></tr><tr><td>3</td><td>There is insufficient memory available to allocate the comms buffers for this module</td></tr><tr><td>4</td><td>The module has not indicated that it is running correctly during drive power-up</td></tr><tr><td>5</td><td>Module has been removed after power-up or it has stopped working</td></tr><tr><td>6</td><td>The module has not indicated that it has stopped accessing drive parameters during a drive mode change</td></tr><tr><td>7</td><td>The module has failed to acknowledge that a request has been made to reset the drive processor</td></tr></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Ensure the option module is installed correctly</li><li>• Replace the option module</li><li>• Replace the drive</li></ul>		Sub-trip	Reason	1	The module category cannot be identified	2	All the required customized menu table information has not been supplied or the tables supplied are corrupt	3	There is insufficient memory available to allocate the comms buffers for this module	4	The module has not indicated that it is running correctly during drive power-up	5	Module has been removed after power-up or it has stopped working	6	The module has not indicated that it has stopped accessing drive parameters during a drive mode change	7	The module has failed to acknowledge that a request has been made to reset the drive processor
Sub-trip	Reason																	
1	The module category cannot be identified																	
2	All the required customized menu table information has not been supplied or the tables supplied are corrupt																	
3	There is insufficient memory available to allocate the comms buffers for this module																	
4	The module has not indicated that it is running correctly during drive power-up																	
5	Module has been removed after power-up or it has stopped working																	
6	The module has not indicated that it has stopped accessing drive parameters during a drive mode change																	
7	The module has failed to acknowledge that a request has been made to reset the drive processor																	
Slot 1 Not Fitted	Option module in option slot 1 has been removed																	
203	<p>The <i>Slot 1 Not Fitted</i> trip indicates that the option module in option slot 1 on the drive has been removed since the last power up.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>• Ensure the option module is installed correctly.</li><li>• Re-install the option module.</li><li>• To confirm that the removed option module is no longer required perform a save function in Pr <b>mm.000</b>.</li></ul>																	

Slot 1 Watchdog	Option module watchdog function service error																															
201	<p>The <i>Slot 1 Watchdog</i> trip indicates that the option module installed in Slot 1 has started the option watchdog function and then failed to service the watchdog correctly.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Replace the option module</li></ul>																															
Soft Start	Soft start relay failed to close, soft start monitor failed																															
226	<p>The <i>Soft Start</i> trip indicates that the soft start relay in the drive failed to close or the soft start monitoring circuit has failed. The cause of the trip can be identified by the sub-trip number.</p> <table><thead><tr><th>Sub-trip</th><th>Reason</th></tr></thead><tbody><tr><td>1</td><td>Soft-start failure</td></tr><tr><td>2</td><td>DC bus capacitor failure on 110 V drive (size 2 only)</td></tr></tbody></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Hardware fault – Contact the supplier of the drive</li></ul>			Sub-trip	Reason	1	Soft-start failure	2	DC bus capacitor failure on 110 V drive (size 2 only)																							
Sub-trip	Reason																															
1	Soft-start failure																															
2	DC bus capacitor failure on 110 V drive (size 2 only)																															
STO Error	No Safe Torque Off board fitted																															
234	STO board not fitted																															
Stored HF	Hardware trip has occurred during last power down																															
221	<p>The <i>Stored HF</i> trip indicates that a hardware trip (HF01 –HF19) has occurred and the drive has been power cycled. The sub-trip number identifies the HF trip i.e. stored HF19.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Enter 1299 in Pr <b>mm.000</b> and press reset to clear the trip</li></ul>																															
Sub-array RAM	RAM allocation error																															
227	<p>The <i>Sub-array RAM</i> trip indicates that an option module derivative image has requested more parameter RAM than is allowed. The RAM allocation is checked in order of resulting sub-trip numbers, and so the failure with the highest sub-trip number is given. The sub-trip is calculated as (parameter size) + (parameter type) + sub-array number.</p> <table><thead><tr><th>Parameter size</th><th>Value</th></tr></thead><tbody><tr><td>1 bit</td><td>1</td></tr><tr><td>8 bit</td><td>2</td></tr><tr><td>16 bit</td><td>3</td></tr><tr><td>32 bit</td><td>4</td></tr><tr><td>64 bit</td><td>5</td></tr></tbody></table> <table><thead><tr><th>Parameter type</th><th>Value</th></tr></thead><tbody><tr><td>Volatile</td><td>0</td></tr><tr><td>User save</td><td>1</td></tr><tr><td>Power-down save</td><td>2</td></tr></tbody></table> <table><thead><tr><th>Sub-array</th><th>Menus</th><th>Value</th></tr></thead><tbody><tr><td>Derivative image</td><td>29</td><td>2</td></tr><tr><td>Option slot 1 set-up</td><td>15</td><td>4</td></tr></tbody></table>			Parameter size	Value	1 bit	1	8 bit	2	16 bit	3	32 bit	4	64 bit	5	Parameter type	Value	Volatile	0	User save	1	Power-down save	2	Sub-array	Menus	Value	Derivative image	29	2	Option slot 1 set-up	15	4
Parameter size	Value																															
1 bit	1																															
8 bit	2																															
16 bit	3																															
32 bit	4																															
64 bit	5																															
Parameter type	Value																															
Volatile	0																															
User save	1																															
Power-down save	2																															
Sub-array	Menus	Value																														
Derivative image	29	2																														
Option slot 1 set-up	15	4																														
Temp Feedback	Internal thermistor has failed																															
218	<p>The <i>Temp Feedback</i> trip indicates that an internal thermistor has failed. The thermistor location can be identified by the sub-trip number.</p> <table><thead><tr><th>Source</th><th>xx</th><th>y</th><th>zz</th></tr></thead><tbody><tr><td>Power system</td><td>01</td><td>0</td><td>Thermistor location defined by zz</td></tr></tbody></table> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Hardware fault – Contact the supplier of the drive</li></ul>			Source	xx	y	zz	Power system	01	0	Thermistor location defined by zz																					
Source	xx	y	zz																													
Power system	01	0	Thermistor location defined by zz																													
Th Brake Res	Brake resistor over temperature																															
10	<p>The <i>Th Brake Res</i> trip is initiated if the hardware based braking resistor thermal monitoring is connected and the resistor overheats. If the braking resistor is not used, then this trip must be disabled with bit 3 of Action <i>On Trip Detection</i> (10.037) to prevent this trip.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Check brake resistor wiring</li><li>Check braking resistor value is greater than or equal to the minimum resistance value</li><li>Check braking resistor insulation</li></ul>																															
Th Short Circuit	Motor thermistor short circuit																															
25	<p>The <i>Th Short Circuit</i> trip indicates that the motor thermistor connected to terminal 14 (digital input 5) on the control connections, is short circuit or low impedance (&lt;50 <math>\wedge</math>).</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"><li>Check thermistor continuity</li><li>Replace motor / motor thermistor</li></ul>																															

Safety information	Product information	Mechanical installation	Electrical installation	Getting started	Basic parameters	Running the motor	Optimization	NV Media Card Operation	Onboard PLC	Advanced parameters	Technical data	Diagnostics	UL listing information
<b>Thermistor</b>		<b>Motor thermistor over-temperature</b>											
24		<p>The <i>Thermistor</i> trip indicates that the motor thermistor connected to terminal 14 (digital input 5) on the control connections has indicated a motor over temperature.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check motor temperature</li> <li>Check thermistor continuity</li> </ul>											
<b>User 24V</b>		<b>User 24 V supply is not present on Adaptor Interface terminals (1, 2)</b>											
91		<p>A <i>User 24V</i> trip is initiated if the <i>User Supply Select</i> (Pr <b>06.072</b>), is set to 1 and no user 24 V supply is present on the user 24 V input on the Adaptor Interface.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Ensure the user 24 V supply is present on the user terminals on the Adaptor Interface.</li> </ul>											
<b>User OI ac</b>		<b>User OI ac</b>											
8		<p>A <i>User OI ac</i> trip is initiated if the output current of the drive exceeds the trip level set by User Over Current Trip Level (Pr <b>04.041</b>).</p>											
<b>User Prog Trip</b>		<b>Trip generated by an onboard user program</b>											
96		<p>This trip can be initiated from within an onboard user program using a function call which defines the sub-trip number.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Check the user program</li> </ul>											

User Program

On board user program error

249

An error has been detected in the onboard user program image. The sub-trip indicated the reason for the trip.

Sub-trip	Reason	Comments
1	Divide by zero.	
2	Undefined trip.	
3	Attempted fast parameter access set-up with non-existent parameter.	
4	Attempted access to non-existent parameter.	
5	Attempted write to read-only parameter.	
6	Attempted an over-range write.	
7	Attempted read from write-only parameter.	
30	The image has failed because either its CRC is incorrect, or there are less than 6 bytes in the image or the image header version is less than 5.	Occurs when the drive powers-up or the image is programmed. The image tasks will not run.
31	The image requires more RAM for heap and stack than can be provided by the drive.	As 30.
32	The image requires an OS function call that is higher than the maximum allowed.	As 30.
33	The ID code within the image is not valid.	As 30.
34	The user program image has been changed for an image with a different user program number.	As 30.
40	The timed task has not completed in time and has been suspended.	Onboard User Program: Enable (11.047) is reset to zero when the trip is initiated.
41	Undefined function called, i.e. a function in the host system vector table that has not been assigned.	As 40.
52	Customizable menu table CRC check failed.	As 30.
53	Customizable menu table changed.	An error has been detected in the onboard user program image. The sub-trip indicated the reason for the trip.
80	*Image is not compatible with the control board	Initiated from within the image code.
81	*Image is not compatible with the control board serial number	
100	Image has detected and prevented attempted pointer access outside of the IEC task's heap area.	
101	Image has detected and prevented misaligned pointer usage.	
102	Image has detected an array bounds violation and prevented its access.	
103	Image has attempted to convert a data type to or from an unknown data type, has failed and has shut itself down.	
104	Image has attempted to use an unknown user service function.	
200	User program has invoked a "divide" service with a denominator of zero. (Note that this is raised by the downloaded image and has therefore been given a distinct error code despite being the same fundamental problem as sub-trip 1.)	

The following table shows the differences when compared to the derivative product image.

Sub-trip	Difference
40, 41	Onboard User Program: Enable (11.047) is reset to zero when the trip is initiated.
51	Not applicable as core menu Customization not allowed.
6x	Not applicable as option module restrictions not allowed.
7x	Not applicable as option module restrictions not allowed.
100	Image has detected and prevented attempted pointer access outside of the IEC task's heap area.
101	Image has detected and prevented misaligned pointer usage.
102	Image has detected an array bounds violation and prevented its access.
103	Image has attempted to convert a data type to or from an unknown data type, has failed and has shut itself down.
104	Image has attempted to use an unknown user service function.
200	User program has invoked a "divide" service with a denominator of zero. (Note that this is raised by the downloaded image and has therefore been given a distinct error code despite being the same fundamental problem as sub-trip 1)

User Save	User Save error / not completed
36	<p>The <i>User Save</i> trip indicates that an error has been detected in the user save parameters saved in non-volatile memory. For example, following a user save command, If the power to the drive was removed when the user parameters were being saved.</p> <p><b>Recommended actions:</b></p> <ul style="list-style-type: none"> <li>Perform a user save in Pr <b>mm.000</b> to ensure that the trip doesn't occur the next time the drive is powered up.</li> <li>Ensure that the drive has enough time to complete the save before removing the power to the drive.</li> </ul>
Watchdog	Control word watchdog has timed out
30	<p>The <i>Watchdog</i> trip indicates that the control word has been enabled and has timed out</p> <p><b>Recommended actions:</b></p>

Table 13-3 Serial communications look up table

No	Trip	No	Trip	No	Trip
1	Reserved	90	LF Power Comms	200	Slot 1 HF
2	Over Volts	91	User 24V	201	Slot 1 Watchdog
3	OI ac	92	OI Snubber	202	Slot 1 Error
4	OI Brake	93	Power Comms	203	Slot 1 Not Fitted
5	PSU	94 - 95	Reserved	204	Slot 1 Different
6	External Trip	96	User Prog Trip	205 - 214	Reserved
7	Over Speed	97	Data Changing	215	Option Disable
8	User OI ac	98	Out Phase Loss	216 - 217	Reserved
9	Reserved	99	Reserved	218	Temp Feedback
10	Th Brake Res	100	Reset	219	OHt Control
11	Reserved	101	OHt Brake	220	Power Data
12	Reserved	102	OHt Rectifier	221	Stored HF
13	Autotune	103 - 108	Reserved	222	Reserved
14 - 17	Reserved	109	OI dc	223 - 224	Reserved
18	Autotune Stopped	110 - 111	Reserved	225	Current Offset
19	Brake R Too Hot	112 - 167	t112 - t167	226	Soft Start
20	Motor Too Hot	168 - 172	Reserved	227	Sub-array RAM
21	OHt Inverter	173	Fan Fail	228	Output phase s/c
22	OHt Power	174	Card Slot	229	Reserved
23	Reserved	175	Card Product	230	Reserved
24	Thermistor	176	Reserved	231	I cal. range
25	Th Short Circuit	177	Card Boot	232	Drive config
26	I/O Overload	178	Card Busy	233	Reserved
27	OHt dc bus	179	Card Data Exists	234	STO Error
28	An Input 1 Loss	180	Card Option	235	Power Board HF
29	An Input 2 Loss	181	Card Read Only	236	No power board
30	Watchdog	182	Card Error	237	FW incompatible
31	EEPROM Fail	183	Card No Data	238 - 245	Reserved
32	Phase Loss	184	Card Full	246	Derivative ID
33	Resistance	185	Card Access	247	File changed
34	Keypad Mode	186	Card Rating	248	Derivative Image
35	Control Word	187	Card Drive Mode	249	User Program
36	User Save	188	Card Compare	250	Hot Rect/Brake
37	Power Down Save	189	An Input 1 OI	252 - 254	Reserved
38	Reserved	190	An Input 2 OI	255	Reset logs
39	Reserved	191 - 198	Reserved		
40 - 89	t040 - t089	199	Destination		

The trips can be grouped into the following categories. It should be noted that a trip can only occur when the drive is not tripped or is already tripped but with a trip with a lower priority number.

**Table 13-4 Trip categories**

Priority	Category	Trips	Comments
1	Internal faults	HF01, HF02, HF03, HF04, HF05, HF06, HF07, HF08, HF09, HF10, HF11, HF12, HF13, HF14, HF15, HF16, HF17, HF 18, HF 19	These indicate internal problems and cannot be reset. All drive features are inactive after any of these trips occur.
1	Stored HF trip	{Stored HF}	This trip cannot be cleared unless 1299 is entered into <i>Parameter (mm.000)</i> and a reset is initiated.
2	Non-resettable trips	Trip numbers 218 to 247, {Slot 1 HF}	These trips cannot be reset.
3	Volatile memory failure	{EEPROM Fail}	This can only be reset if Parameter <b>mm.000</b> is set to 1233 or 1244, or if <i>Load Defaults</i> (11.043) is set to a non-zero value.
4	NV Media Card trips	Trip numbers 174, 175 and 177 to 188	These trips are priority 5 during power-up.
4	Internal 24V	{PSU}	
5	Trips with extended reset times	{OI.ac}, {OI.Brake}, {OI.dc} and {Fan Fail}	These trips cannot be reset until 10 s after the trip was initiated.
5	Phase loss and d.c. link power circuit protection	{Phase Loss} and {Oht dc bus}	The drive will attempt to stop the motor before tripping if a {Phase Loss}. 000 trip occurs unless this feature has been disabled (see <i>Action On Trip Detection</i> (10.037)). The drive will always attempt to stop the motor before tripping if an {Oht dc bus} occurs.
5	Standard trips	All other trips	

## 13.5 Internal / Hardware trips

Trips {HF01} to {HF19} are internal faults that do not have trip numbers. If one of these trips occurs, the main drive processor has detected an irrecoverable error. All drive functions are stopped and the trip message will be displayed on the drive keypad. If a non permanent trip occurs this may be reset by power cycling the drive. On power up after it has been power cycled, the drive will trip on Stored HF. Enter 1299 in **mm.000** to clear the Stored HF trip.

## 13.6 Alarm indications

In any mode, an alarm is an indication given on the display by alternating the alarm string with the drive status string display. If an action is not taken to eliminate any alarm except "Auto Tune and Limit Switch" the drive may eventually trip. Alarms are not displayed when a parameter is being edited.

**Table 13-5 Alarm indications**

Alarm string	Description
<b>Brake Resistor</b>	Brake resistor overload. <i>Braking Resistor Thermal Accumulator</i> (10.039) in the drive has reached 75.0 % of the value at which the drive will trip.
<b>Motor Overload</b>	<i>Motor Protection Accumulator</i> (4.019) in the drive has reached 75.0 % of the value at which the drive will trip and the load on the drive is >100 %.
<b>Drive Overload</b>	Drive over temperature. <i>Percentage of Drive Thermal Trip Level</i> (07.036) in the drive is greater than 90 %.
<b>Auto Tune</b>	The autotune procedure has been initialized and an autotune in progress.
<b>Limit Switch</b>	Limit switch active. Indicates that a limit switch is active and that is causing the motor to be stopped.
<b>Option Slot 1</b>	Option slot alarm
<b>Low AC</b>	Low voltage mode. See <i>Low AC Alarm</i> (10.107).
<b>Current limit</b>	Current limit active. See <i>Current Limit Active</i> (10.009).

## 13.7 Status indications

Table 13-6 Status indications

Upper row string	Description	Drive output stage
<b>Inhibit</b>	The drive is inhibited and cannot be run. The SAFE TORQUE OFF signals are not applied to the SAFE TORQUE OFF terminals or Pr <b>06.015</b> is set to 0. The other conditions that can prevent the drive from enabling are shown as bits in <i>Enable Conditions</i> (06.010).	Disabled
<b>Ready</b>	The drive is ready to run. The drive enable is active, but the drive inverter is not active because the final drive run is not active.	Disabled
<b>Stop</b>	The drive is stopped / holding zero frequency.	Enabled
<b>Run</b>	The drive is active and running.	Enabled
<b>Supply Loss</b>	Supply loss condition has been detected.	Enabled
<b>Deceleration</b>	The motor is being decelerated to zero frequency because the final drive run has been deactivated.	Enabled
<b>dc Injection</b>	The drive is applying dc injection braking.	Enabled
<b>Trip</b>	The drive has tripped and no longer controlling the motor. The trip code appears in the lower display.	Disabled
<b>Under Voltage</b>	The drive is in the under-voltage state either in low voltage or high voltage mode.	Disabled

Table 13-7 Option module and other status indications at power-up

First row string	Second row string	Status
<b>Waiting For</b>	<b>Power System</b>	Waiting for power stage
The drive is waiting for the processor in the power stage to respond after power-up.		
<b>Waiting For</b>	<b>Option</b>	Waiting for an option module
The drive is waiting for the option module to respond after power-up		
<b>Uploading From</b>	<b>Option</b>	Loading parameter database
At power-up it may be necessary to update the parameter database held in the drive because an option module has changed. This may involve data transfer between the drive and option module. During this period 'Uploading From Option' is displayed.		

## 13.8 Displaying the trip history

The drive retains a log of the last ten trips that have occurred. *Trip 0* (10.020) to *Trip 9* (10.029) store the most recent 10 trips that have occurred where *Trip 0* (10.020) is the most recent and *Trip 9* (10.029) is the oldest. When a new trip occurs it is written to *Trip 0* (10.020) and all the other trips move down the log, with oldest being lost. The date and time when each trip occurs are also stored in the date and time log, i.e. *Trip 0 Date* (10.041) to *Trip 9 Time* (10.060). The date and time are taken from *Date* (06.016) and *Time* (06.017). Some trips have sub-trip numbers which give more detail about the reason for the trip. If a trip has a sub-trip number its value is stored in the sub-trip log, i.e. *Trip 0 Sub-trip Number* (10.070) to *Trip 9 Sub-trip Number* (10.079). If the trip does not have a sub-trip number then zero is stored in the sub-trip log.

If any parameter between Pr **10.020** and Pr **10.029** inclusive is read by serial communication, then the trip number in Table 13-2 is the value transmitted.

### NOTE

The trip logs can be reset by writing a value of 255 in Pr **10.038**.

## 13.9 Behavior of the drive when tripped

If the drive trips, the output of the drive is disabled so the load coasts to a stop. If any trip occurs, the following read only parameters are frozen until the trip is cleared. This is to help diagnose the cause of the trip.

Parameter	Description
<b>01.001</b>	Frequency reference
<b>01.002</b>	Pre-skip filter reference
<b>01.003</b>	Pre-ramp reference
<b>02.001</b>	Post-ramp reference
<b>03.001</b>	Final demand ref
<b>03.002</b>	Estimated frequency
<b>03.003</b>	Frequency error
<b>03.004</b>	Frequency controller output
<b>04.001</b>	Current magnitude
<b>04.002</b>	Active current
<b>04.017</b>	Reactive current
<b>05.001</b>	Output frequency
<b>05.002</b>	Output voltage
<b>05.003</b>	Power
<b>05.005</b>	DC bus voltage
<b>07.001</b>	Analog input 1
<b>07.002</b>	Analog input 2
<b>07.037</b>	Temperature nearest to trip level

If the parameters are not required to be frozen then this can be disabled by setting bit 4 of Pr **10.037**.



## **Excerpts from PowerFlex 520 series drive manual**

Chapter 2 Start-Up

Chapter 3 Programming

**\*\*Refer to the USB accompanying this manual for the PowerFlex 520 User Guide in its entirety.**

## Start Up

This chapter describes how to start up the PowerFlex 520-series drive. To simplify drive setup, the most commonly programmed parameters are organized in a single Basic Program Group.

For information on...	See page...
<a href="#">Prepare for Drive Start-Up</a>	<a href="#">59</a>
<a href="#">Display and Control Keys</a>	<a href="#">62</a>
<a href="#">Viewing and Editing Parameters</a>	<a href="#">63</a>
<a href="#">Drive Programming Tools</a>	<a href="#">64</a>
<a href="#">Smart Start-Up with Basic Program Group Parameters</a>	<a href="#">65</a>
<a href="#">LCD Display with QuickView Technology</a>	<a href="#">67</a>
<a href="#">Using the USB Port</a>	<a href="#">67</a>

**IMPORTANT** Read the *General Precautions* section before proceeding.



**ATTENTION:** Power must be applied to the drive to perform the following start-up procedures. Some of the voltages present are at incoming line potential. To avoid electric shock hazard or damage to equipment, only qualified service personnel should perform the following procedure. Thoroughly read and understand the procedure before beginning. If an event does not occur while performing this procedure, **Do Not Proceed. Remove All Power** including user supplied control voltages. User supplied voltages may exist even when main AC power is not applied to the drive. Correct the malfunction before continuing.

### Prepare for Drive Start-Up

### Drive Startup Task List

1. Disconnect and lock out power to the machine.
2. Verify that AC line power at the disconnect device is within the rated value of the drive.
3. If replacing a drive, verify the current drive's catalog number. Verify all options installed on the drive.
4. Verify that any digital control power is 24 volts.
5. Inspect grounding, wiring, connections, and environmental compatibility.

6. Verify that the Sink (SNK)/Source (SRC) jumper is set to match your control wiring scheme. See the [PowerFlex 523 Control I/O Wiring Block Diagram on page 38](#) and [PowerFlex 525 Control I/O Wiring Block Diagram on page 42](#) for location.

---

**IMPORTANT** The default control scheme is Source (SRC). The Stop terminal is jumpered to allow starting from the keypad or comms. If the control scheme is changed to Sink (SNK), the jumper must be removed from I/O Terminals 01 and 11 and installed between I/O Terminals 01 and 04.

---

7. Wire I/O as required for the application.
8. Wire the power input and output terminals.
9. Confirm that all inputs are connected to the correct terminals and are secure.
10. Collect and record motor nameplate and encoder or feedback device information. Verify motor connections.
  - Is the motor uncoupled?
  - What direction will the motor need to turn for the application?
11. Verify the input voltage to the drive. Verify if the drive is on a grounded system. Ensure the MOV jumpers are in the correct position. See [AC Supply Source Considerations on page 19](#) for more information.
12. Apply power and reset the drive and communication adapters to factory default settings. To reset the drive, see parameter [P053](#) [Reset to Defaults]. To reset the communication adapters, see the user manual of the adapter for more information.
13. Configure the basic program parameters related to the motor. See [Smart Start-Up with Basic Program Group Parameters on page 65](#).
14. Complete the autotune procedure for the drive. See parameter [P040](#) [Autotune] for more information.
15. If you are replacing a drive and have a backup of the parameter settings obtained using the USB utility application, use the USB utility application to apply the backup to the new drive. See [Using the USB Port on page 67](#) for more information.

Otherwise, set the necessary parameters for your application using the LCD keypad interface, Connected Components Workbench, or RSLogix or Logix Designer if using an Add-on Profile through EtherNet/IP.

- Configure the communication parameters needed for the application (node number, IP address, Datalinks in and out, communication rate, speed reference, start source, and so on). Record these settings for your reference.
- Configure the other drive parameters needed for the drive analog and digital I/O to work correctly. Verify the operation. Record these settings for your reference.

**16.** Verify the drive and motor perform as specified.

- Verify that the Stop input is present or the drive will not start.

---

**IMPORTANT** If I/O Terminal 01 is used as a stop input, the jumper between I/O Terminals 01 and 11 must be removed.

---

- Verify the drive is receiving the speed reference from the correct place and that the reference is scaled correctly.
- Verify the drive is receiving start and stop commands correctly.
- Verify input currents are balanced.
- Verify motor currents are balanced.

**17.** Save a backup of the drive settings using the USB utility application. See [Using the USB Port on page 67](#) for more information.

## Start, Stop, Direction and Speed Control

Factory default parameter values allow the drive to be controlled from the keypad. No programming is required to start, stop, change direction and control speed directly from the keypad.

---

**IMPORTANT** To disable reverse operation, see A544 [Reverse Disable].

---


If a fault appears on power up, see [Fault Descriptions on page 159](#) for an explanation of the fault code.

## Variable Torque Fan/Pump Applications


For improved motor and drive performance, tune the motor in SVC mode using parameter P040 [Autotune]. If V/Hz mode is selected, use parameter A530 [Boost Select] to adjust the boost.

## Display and Control Keys

PowerFlex 523












PowerFlex 525



Menu	Parameter Group and Description
<b>b</b>	<b>Basic Display</b> Commonly viewed drive operating
<b>P</b>	<b>Basic Program</b> Commonly used programmable
<b>t</b>	<b>Terminal Blocks</b> Programmable terminal functions.
<b>C</b>	<b>Communications</b> Programmable communication
<b>L</b>	<b>Logic (PowerFlex 525 only)</b> Programmable logic functions.
<b>d</b>	<b>Advanced Display</b> Advanced drive operating conditions.
<b>A</b>	<b>Advanced Program</b> Remaining programmable functions.
<b>N</b>	<b>Network</b> Network functions that are shown only when a comm card is used.
<b>M</b>	<b>Modified</b> Functions from the other groups with values changed from default.
<b>f</b>	<b>Fault and Diagnostic</b> Consists of list of codes for specific
<b>G</b>	<b>AppView and CustomView</b> Functions from the other groups organized for specific applications.
























## Control and Navigation Keys









Display	Display State	Description
ENET (PowerFlex 525 only)	Off	Adapter is not connected to the network.
	Steady	Adapter is connected to the network and drive is controlled through Ethernet.
	Flashing	Adapter is connected to the network but drive is not controlled through Ethernet.
LINK (PowerFlex 525 only)	Off	Adapter is not connected to the network.
	Steady	Adapter is connected to the network but not
	Flashing	Adapter is connected to the network and
LED	LED State	Description
FAULT	Flashing	Indicates drive is faulted.
Key	Name	Description
 	Up Arrow	Scroll through user-selectable display parameters or groups. Increment values.
	Down	
	Escape	Back one step in programming menu. Cancel a change to a parameter value and exit Program Mode.
	Select	<b>Advance one step in programming menu. Select a</b>
	Enter	Advance one step in programming menu. Save a change to a parameter value.

Key	Name	Description
	Reverse	Used to reverse direction of the drive. Default is active. Controlled by parameters P046, P048 and P050 [Start Source x] and
	Start	Used to start the drive. Default is active. Controlled by parameters P046, P048 and
	Stop	Used to stop the drive or clear a fault. This key is <b>always active</b> .
	Potentiometer	Used to control speed of drive. Default is active. Controlled by parameters P047, P049 and P051

## Viewing and Editing Parameters

The following is an example of basic integral keypad and display functions. This example provides basic navigation instructions and illustrates how to program a parameter.

Step	Key(s)	Example Display
1. When power is applied, the last user-selected Basic Display Group parameter number is briefly displayed with flashing characters. The display then defaults to that parameter's current value. (Example shows the value of b001 [Output Freq] with the drive stopped.)		
2. Press Esc to display the Basic Display Group parameter number shown on power-up. The parameter number will flash.		
3. Press Esc to enter the parameter group list. The parameter group letter will flash.		
4. Press the Up Arrow or Down Arrow to scroll through the group list (b, P, t, C, L, d, A, f and Gx).	 or 	
5. Press Enter or Sel to enter a group. The right digit of the last viewed parameter in that group will flash.	 or 	
6. Press the Up Arrow or Down Arrow to scroll through the parameter list.	 or 	
7. Press Enter to view the value of the parameter. Or Press Esc to return to the	 or 	
	 or 	
	 or 	

Step	Key(s)	Example Display
10. If desired, press Sel to move from digit to digit or bit to bit. The digit or bit that you can change will flash.		
11. Press Esc to cancel a change and exit Program Mode. Or Press Enter to save a change and exit Program Mode. The digit will stop flashing and the word Program on the LCD display will turn off.	 or 	 or 
12. Press Esc to return to the		

## Drive Programming Tools

Some features in the PowerFlex 520-series drive are not supported by older configuration software tools. It is strongly recommended that customers using such tools migrate to RSLogix 5000 (version 17.0 or greater) or Logix Designer (version 21.0 or greater) with Add-On-Profile (AOP), or Connected Components Workbench (version 5.0 or greater) to enjoy a richer, full-featured configuration experience. For Automatic Device Configuration (ADC) support, RSLogix 5000 version 20.0 or greater is required.

Description	Catalog Number/Release Version
Connected Components Workbench <sup>(1)</sup>	Version 5.0 or greater
Logix Designer	Version 21.0 or greater
RSLogix 5000	Version 17.0 or greater
Built-in USB software tool	—
Serial Converter Module <sup>(2)</sup>	22-SCM-232
USB Converter Module <sup>(2)</sup>	1203-USB
Remote Panel Mount, LCD Display <sup>(2)</sup>	22-HIM-C2S
Remote Handheld, LCD Display <sup>(2)</sup>	22-HIM-A3

(1) Available as a free download at <http://ab.rockwellautomation.com/programmable-controllers/connected-components-workbench-software>.

(2) Does not support the new dynamic parameter groups (AppView, CustomView), and CopyCat functionality is limited to the linear parameter list.

## Language Support

Language	Keypad/LCD Display	RSLogix 5000/ Logix Designer	Connected Components Workbench
English	Y	Y	Y
French	Y	Y	Y
Spanish	Y	Y	Y
Italian	Y	Y	Y
German	Y	Y	Y
Japanese	—	Y	—
Portuguese	Y	Y	—
Chinese Simplified	—	Y	Y
Korean	—	Y	—

Language	Keypad/LCD Display	RSLogix 5000/ Logix Designer	Connected Components Workbench
Polish <sup>(1)</sup>	Y	–	–
Turkish <sup>(1)</sup>	Y	–	–
Czech <sup>(1)</sup>	Y	–	–

(1) Due to a limitation of the LCD Display, some of the characters for Polish, Turkish, and Czech will be modified.

## Smart Start-Up with Basic Program Group Parameters

The PowerFlex 520-series drive is designed so that start up is simple and efficient. The Basic Program Group contains the most commonly used parameters. See [Programming and Parameters on page 71](#) for detailed descriptions of the parameters listed here, as well as the full list of available parameters.





= Stop drive before changing this parameter.





PF 525 = Parameter is specific to PowerFlex 525 drives only.



No.	Parameter	Min/Max	Display/Options	Default
P030	[Language] Selects the language displayed. <b>Important:</b> The setting takes effect after the drive is power cycled.	1/15	1 = English 2 = Français 3 = Español 4 = Italiano 5 = Deutsch 6 = Reserved 7 = Português 8 = Reserved 9 = Reserved 10 = Reserved 11 = Reserved 12 = Polish 13 = Reserved 14 = Turkish 15 = Czech	1
P031	[Motor NP Volts] Sets the motor nameplate rated	10V (for 200V Drives), 20V (for 400V Drives), 25V (for 600V Drives)	1V	Based on Drive Rating
P032	[Motor NP] Sets the motor nameplate rated	15/500 Hz	1 Hz	60 Hz
P033	[Motor OL] Sets the motor nameplate overload	0.0/(Drive Rated)	0.1 A	Based on Drive Rating
P034	[Motor NP] Sets the motor nameplate FLA.	0.0/(Drive Rated)	0.1 A	Drive Rated Amps
P035	[Motor NP] Sets the number of poles in the	2/40	1	4
P036	[Motor NP] Sets the rated nameplate rpm of	0/24000 rpm	1 rpm	1750 rpm
P037	[Motor NP] Sets the motor nameplate power. Used in PM regulator.	0.00/Drive Rated	0.01 kW	Drive Rated Power
P038	[Voltage Class] Sets the voltage class of 600V drives. Only applicable to 600V drives.	2/3	2 = "480V" 3 = "600V"	3



 = Stop drive before changing this parameter.

 = Parameter is specific to PowerFlex 525 drives only.

No.	Parameter	Min/Max	Display/Options	Default
P039	[Torque Perf Mode]	0/4	0 = "V/Hz" 1 = "SVC" 2 = "Economize" 3 = "Vector" <sup>(1)</sup> 4 = "PM Control" <sup>(1)(2)(3)</sup>	1
	<p>Selects the motor control mode.</p> <p>(1) Setting is specific to PowerFlex 525 drives only.</p> <p>(2) Setting is available in PowerFlex 525 FRN 5.xxx and later.</p> <p>(3) When P039 [Torque Perf Mode] is set to 4 and</p> <p><a href="#">A535</a> [Motor Fdbk Type] is set to 0, 1, 2 or 3, the drive is in open loop PM motor control mode.</p> <p>When P039 [Torque Perf Mode] is set to 4 and</p> <p><a href="#">A535</a> [Motor Fdbk Type] is set to 4 or 5, the drive is in closed loop PM motor control mode.</p>			
P040	[Autotune]	0/2	0 = "Ready/Idle" 1 = "Static Tune" 2 = "Rotate Tune"	0
	Enables a static (not spinning) or dynamic (motor spinning)			
P041	[Accel Time 1]	0.00/600.00 s	0.01 s	10.00 s
	Sets the time for the drive to accel from 0 Hz to			
P042	[Decel Time 1]	0.00/600.00 s	0.01 s	10.00 s
	Sets the time for the drive to decel from [Maximum			
P043	[Minimum]	0.00/500.00 Hz	0.01 Hz	0.00 Hz
	Sets the lowest frequency the drive			
P044	[Maximum]	0.00/500.00 Hz	0.01 Hz	60.00 Hz
	Sets the highest frequency the drive			
P045	[Stop Mode]	0/11	0 = "Ramp, CF" <sup>(1)</sup> 1 = "Coast, CF" <sup>(1)</sup> 2 = "DC Brake, CF" <sup>(1)</sup> 3 = "DCBrkAuto, CF" <sup>(1)</sup> 4 = "Ramp" 5 = "Coast" 6 = "DC Brake" 7 = "DC BrakeAuto" 8 = "Ramp+EM B, CF" <sup>(1)</sup> 9 = "Ramp+EM Brk" 10 = "PointStp, CF" <sup>(1)</sup> 11 = "PointStop"	0
	<p>Stop command for normal stop.</p> <p><b>Important:</b> I/O Terminal 01 is always a stop input. The stopping mode is determined by the drive setting.</p> <p><b>Important:</b> The drive is shipped with a jumper installed between I/O Terminals 01 and 11. Remove this jumper when using I/O Terminal 01 as a stop or enable input.</p> <p>(1) Stop input also clears active fault.</p>			
P046, P048, P050	[Start Source]	1/5	1 = "Keypad" <sup>(1)</sup> 2 = "DigIn TrmBlk" <sup>(2)</sup> 3 = "Serial/DSI" 4 = "Network Opt" 5 = "Ethernet/IP" <sup>(3)</sup>	P046 = 1 P048 = 2 P050 = 3 (PowerFlex 523) 5 (PowerFlex 525)
	<p>Sets the default control scheme used to start the drive unless overridden by P048 [Start Source 2] or P050 [Start Source 3].</p> <p>(1) When active, the Reverse key is also active unless disabled by <a href="#">A544</a> [Reverse Disable].</p> <p>(2) If "DigIn TrmBlk" is selected, ensure that the digital</p>			

 = Stop drive before changing this parameter.  
 = Parameter is specific to PowerFlex 525 drives only.

No.	Parameter	Min/Max	Display/Options	Default
P047, P049, P051	[Speed] Sets the default speed command of the drive unless overridden by P049 [Speed Reference2] or P051 [Speed Reference3].  (1) Setting is specific to PowerFlex 525 drives only.	1/16	1 = "Drive Pot" 2 = "Keypad Freq" 3 = "Serial/DSI" 4 = "Network Opt" 5 = "0-10V Input" 6 = "4-20mA Input" 7 = "Preset Freq" 8 = "Anlg In Mult" <sup>(1)</sup> 9 = "MOP" 10 = "Pulse Input" 11 = "PID1 Output" 12 = "PID2 Output" <sup>(1)</sup> 13 = "Step Logic" <sup>(1)</sup> 14 = "Encoder" <sup>(1)</sup> 15 = "Ethernet/IP" <sup>(1)</sup> 16 = "Positioning" <sup>(1)</sup>	P047 = 1 P049 = 5 P051 = 3 (PowerFlex 523) 15 (PowerFlex 525)
P052	[Average kWh] Sets the average cost per kWh.	0.00/655.35	0.01	0.00
P053	[Reset To] Resets parameters to their factory defaults values. After a Reset command, the value of this parameter returns to zero.  (1) Power cycle of the drive, <b>NO</b> parameters are reset. (2) Setting is available in PowerFlex 525 FRN 5.xxx and later.	0/4	0 = "Ready/Idle" 1 = "Param Reset" 2 = "Factory Rset" 3 = "Power Reset" 4 = "Module Reset" <sup>(1)(2)(3)</sup>	0

## LCD Display with QuickView Technology

QuickView™ technology enables text to scroll across the LCD display of the PowerFlex 520-series drive. This allows you to easily configure parameters, troubleshoot faults and view diagnostic items without using a separate device. Use parameter [A556](#) [Text Scroll] to set the speed at which the text scrolls across the display. Select 0 "Off" to turn off text scrolling. See [Language Support on page 64](#) for the languages supported by the PowerFlex 520-series drive.

## Using the USB Port


The PowerFlex 520-series drive has a USB port that connects to a PC for the purpose of upgrading drive firmware or uploading/downloading a parameter configuration.

**IMPORTANT** To use the USB feature of the PowerFlex 520-series drive, Microsoft .Net Framework 2.0 and Windows XP or later is required.


## MainsFree Programming

The MainsFree™ programming feature allows you to quickly configure your PowerFlex 520-series drive without having to power up the control module or install additional software. Simply connect the control module to your PC with a USB Type B cable and you can download a parameter configuration to your drive. You can also easily upgrade your drive with the latest firmware.

## Connecting a PowerFlex 520-series drive to a PC




When connected, the drive appears on the PC and contains two files:

- **GUIDE.PDF**  
This file contains links to relevant product documentation and software downloads.
-  **PF52XUSB.EXE**  
This file is an application to flash upgrade firmware or upload/download a parameter configuration.

It is not possible to delete these files or add more to the drive.

Double-click on the PF52XUSB.EXE file to launch the USB utility application. The main menu is displayed. Follow the program instructions to upgrade the firmware or upload/download configuration data.



**IMPORTANT** Make sure your PC is powered by an AC power outlet or has a fully charged battery before starting any operation. This prevents the operation from terminating before completion due to insufficient power.

## **Limitation in Downloading .pf5 Configuration Files with the USB Utility Application**

Before downloading a .pf5 configuration file using the USB utility application, parameter C169 [MultiDrv Sel] in the destination drive must match the incoming configuration file. If it does not, set the parameter manually to match and then cycle drive power. Also, the drive type of the .pf5 file must match the drive.

This means you cannot apply a multi-drive configuration using the USB utility application to a drive in single mode (parameter C169 [MultiDrv Sel] set to 0 “Disabled”), or apply a single mode configuration to a drive in multi-drive mode.

**Notes:**

# Chapter 3

## Programming and Parameters

This chapter provides a complete listing and description of the PowerFlex 520-series drive parameters. Parameters are programmed (viewed/edited) using either the drive's built-in keypad, RSLogix 5000 version 17.0 or greater, Logix Designer version 21.0 or greater, or Connected Components Workbench version 5.0 or greater software. The Connected Components Workbench software can be used offline (through USB) to upload parameter configurations to the drive or online (through Ethernet connection).

Limited functionality is also available when using the Connected Components Workbench software online (through DSI and serial converter module), a legacy external HIM, or legacy software online (DriveTools SP™). When using these methods, the parameter list can only be displayed linearly, and there is no access to communications option card programming.

For information on...	See page...
<a href="#">About Parameters</a>	<a href="#">71</a>
<a href="#">Parameter Groups</a>	<a href="#">73</a>
<a href="#">Basic Display Group</a>	<a href="#">78</a>
<a href="#">Basic Program Group</a>	<a href="#">83</a>
<a href="#">Terminal Block Group</a>	<a href="#">89</a>
<a href="#">Communications Group</a>	<a href="#">101</a>
<a href="#">Logic Group</a>	<a href="#">107</a>
<a href="#">Advanced Display Group</a>	<a href="#">110</a>
<a href="#">Advanced Program Group</a>	<a href="#">115</a>
<a href="#">Network Parameter Group</a>	<a href="#">141</a>
<a href="#">Modified Parameter Group</a>	<a href="#">142</a>
<a href="#">Fault and Diagnostic Group</a>	<a href="#">142</a>
<a href="#">AppView Parameter Groups</a>	<a href="#">150</a>
<a href="#">CustomView Parameter Group</a>	<a href="#">151</a>
<a href="#">Parameter Cross Reference by Name</a>	<a href="#">152</a>

## About Parameters

To configure a drive to operate in a specific way, drive parameters may have to be set. Three types of parameters exist:

- **ENUM**

ENUM parameters allow a selection from 2 or more items. Each item is represented by a number.




- **Numeric Parameters**

These parameters have a single numerical value (0.1V).

- **Bit Parameters**

Bit parameters have five individual digits associated with features or conditions. If the digit is 0, the feature is off or the condition is false. If the digit is 1, the feature is on or the condition is true.

Some parameters are marked as follows.

-  = Stop drive before changing this parameter.
-  <sup>32</sup> = 32 bit parameter.
-  = Parameter is specific to PowerFlex 525 drives only.

### 32-bit Parameters

Parameters marked 32-bit will have two parameter numbers when using RS485 communications and programming software. For example, parameters b010 [Process Display] and b011 [Process Fract] are scaled and displayed as follows.

- P043 [Minimum Freq] = 0 Hz
- P044 [Maximum Freq] = 60 Hz
- A481 [Process Display Lo] = 0
- A482 [Process Display Hi] = 10

Using the formula,

Scaled Process Value (PV) =

$$\frac{([Process\ Disp\ Hi] - [Process\ Disp\ Lo]) \times ([Output\ Freq] - [Minimum\ Freq])}{[Maximum\ Freq] - [Minimum\ Freq]}$$

when the drive is running at 10 Hz, the Process Value will be 1.66.

On the drive LCD display, only parameter b010 [Process Display] is shown.



In Connected Components Workbench software, parameter b010 [Process Display] and b011 [Process Fract] are shown separately.

Parameters - PowerFlex 525_2* Port 0							
Parameters							
#	Name	Value	Units	Internal Value	Default	Min	Max
1	Output Freq	10.00	Hz	1000	0.00	0.00	500.00
2	Commanded Freq	10.00	Hz	1000	0.00	0.00	500.00
3	Output Current	0.04	A	4	0.00	0.00	9.60
4	Output Voltage	37.0	V	370	0.0	0.0	999.9
5	DC Bus Voltage	333	VDC	333	0	0	1200
6	Drive Status	00000000 00000011		3	00000000 0000...	0	31
7	Fault 1 Code	81		81	0	0	127
8	Fault 2 Code	4		4	0	0	127
9	Fault 3 Code	81		81	0	0	127
10	Process Display	1		1	0	0	9999
11	Process Fract	0.66		66	0.00	0.00	0.99


## Parameter Groups

For an alphabetical listing of parameters, see [Parameter Cross Reference by Name on page 152](#).

<b>Basic Display</b>		Output Voltage		b004	Control Source		b012	Elapsed Run Time		b019	Accum CO2 Sav		b026
	Output Freq Commanded Freq Output Current	b001 b002 b003	DC Bus Voltage	b005	Contrl In Status	b013	Average Power	b020	Drive Temp	b027			
			Drive Status	b006	Dig In Status	b014	Elapsed kWh	b021	Control Temp	b028			
			Fault 1 Code	b007	Output RPM	b015	Elapsed MWh	b022	Control SW Ver	b029			
			Fault 2 Code	b008	Output Speed	b016	Energy Saved	b023					
			Fault 3 Code	b009	Output Power	b017	Accum kWh Sav	b024					
			Process Display	b010	Power Saved	b018	Accum Cost Sav	b025					
<b>Basic Program</b>		Motor NP Hertz		P032	Voltage Class		P038	Maximum Freq		P044	Start Source 3		P050
	Language Motor NP Volts	P030 P031	Motor OL Current	P033	Torque Perf Mode	P039	Stop Mode	P045	Speed Reference3	P051			
			Motor NP FLA	P034	Autotune	P040	Start Source 1	P046	Average kWh Cost	P052			
			Motor NP Poles	P035	Accel Time 1	P041	Speed Reference1	P047	Reset To Defaults	P053			
			Motor NP RPM	P036	Decel Time 1	P042	Start Source 2	P048					
			Motor NP Power <sup>(1)</sup>	P037	Minimum Freq	P043	Speed Reference2	P049					
<b>Terminal Blocks</b>		DigIn TermBlk 07 <sup>(1)</sup>		t067	Relay 1 On Time		t079	Analog Out High <sup>(2)</sup>		t089	Anlg Loss Delay		t098
	DigIn TermBlk 02 DigIn TermBlk 03 2-Wire Mode DigIn TermBlk 05 DigIn TermBlk 06	t062 t063 t064 t065 t066	DigIn TermBlk 08 <sup>(1)</sup>	t068	Relay 1 Off Time	t080	Anlg Out Setpt <sup>(2)</sup>	t090	Analog In Filter	t099			
			Opto Out1 Sel <sup>(1)</sup>	t069	Relay Out2 Sel <sup>(1)</sup>	t081	Anlg In 0-10V Lo	t091	Sleep-Wake Sel	t100			
			Opto Out1 Level <sup>(1)</sup>	t070	Relay Out2 Level <sup>(1)</sup>	t082	Anlg In 0-10V Hi	t092	Sleep Level	t101			
			Opto Out2 Sel <sup>(1)</sup>	t072	Relay 2 On Time <sup>(1)</sup>	t084	10V Bipolar Enbl <sup>(1)</sup>	t093	Sleep Time	t102			
			Opto Out2 Level <sup>(1)</sup>	t073	Relay 2 Off Time <sup>(1)</sup>	t085	Anlg In V Loss	t094	Wake Level	t103			
			Opto Out Logic <sup>(1)</sup>	t075	EM Brk Off Delay	t086	Anlg In4-20mA Lo	t095	Wake Time	t104			
			Relay Out1 Sel	t076	EM Brk On Delay	t087	Anlg In4-20mA Hi	t096	Safety Open En <sup>(1)</sup>	t105			
			Relay Out1 Level	t077	Analog Out Sel <sup>(2)</sup>	t088	Anlg In mA Loss	t097	SafetyFlt RstCfg <sup>(1)(3)</sup>	t106			
<b>Communications</b>		EN Addr Sel <sup>(1)</sup>		C128	EN Gateway Cfg 3 <sup>(1)</sup>			EN Data In 1 <sup>(1)</sup>		C153	Opt Data In 4		C164
	Comm Write Mode Cmd Stat Select <sup>(1)</sup> RS485 Data Rate RS485 Node Addr Comm Loss Action Comm Loss Time RS485 Format	C121 C122 C123 C124 C125 C126 C127	EN IP Addr Cfg 1 <sup>(1)</sup>	C129		C139	EN Data In 2 <sup>(1)</sup>	C154	Opt Data Out 1	C165			
			EN IP Addr Cfg 2 <sup>(1)</sup>	C130	EN Gateway Cfg 4 <sup>(1)</sup>		EN Data In 3 <sup>(1)</sup>	C155	Opt Data Out 2	C166			
			EN IP Addr Cfg 3 <sup>(1)</sup>	C131		C140	EN Data In 4 <sup>(1)</sup>	C156	Opt Data Out 3	C167			
			EN IP Addr Cfg 4 <sup>(1)</sup>	C132	EN Rate Cfg <sup>(1)</sup>	C141	EN Data Out 1 <sup>(1)</sup>	C157	Opt Data Out 4	C168			
			EN Subnet Cfg 1 <sup>(1)</sup>	C133	EN Comm Flt Actn <sup>(1)</sup>		EN Data Out 2 <sup>(1)</sup>	C158	MultiDrv Sel	C169			
			EN Subnet Cfg 2 <sup>(1)</sup>	C134		C143	EN Data Out 3 <sup>(1)</sup>	C159	Drv 1 Addr	C171			
			EN Subnet Cfg 3 <sup>(1)</sup>	C135	EN Idle Flt Actn <sup>(1)</sup>	C144	EN Data Out 4 <sup>(1)</sup>	C160	Drv 2 Addr	C172			
			EN Subnet Cfg 4 <sup>(1)</sup>	C136	EN Flt Cfg Logic <sup>(1)</sup>	C145		C161	Drv 3 Addr	C173			
			EN Gateway Cfg 1 <sup>(1)</sup>	C137	EN Flt Cfg Ref <sup>(1)</sup>	C146	Opt Data In 1	C162	Drv 4 Addr	C174			
				C138	EN Flt Cfg DL 1 <sup>(1)</sup>	C147	Opt Data In 2	C163	DSI I/O Cfg	C175			
			EN Gateway Cfg 2 <sup>(1)</sup>		EN Flt Cfg DL 2 <sup>(1)</sup>	C148							
					EN Flt Cfg DL 3 <sup>(1)</sup>	C149							
					EN Flt Cfg DL 4 <sup>(1)</sup>	C150							
<b>Logic<sup>(1)</sup></b>		Stp Logic 2		L182	Stp Logic Time 0		L190	Stp Logic Time 6		L196	Step Units 4		L208
	Stp Logic 0 Stp Logic 1	L180 L181	Stp Logic 3	L183	Stp Logic Time 1	L191	Stp Logic Time 7	L197	Step Units 5	L210			
			Stp Logic 4	L184	Stp Logic Time 2	L192	Step Units 0	L200	Step Units 6	L212			
			Stp Logic 5	L185	Stp Logic Time 3	L193	Step Units 1	L202	Step Units 7	L214			
			Stp Logic 6	L186	Stp Logic Time 4	L194	Step Units 2	L204					
			Stp Logic 7	L187	Stp Logic Time 5	L195	Step Units 3	L206					
<b>Advanced Display</b>		Elapsed Time-min		d363	Speed Feedback		d376	PID2 Fdbk Displ <sup>(1)</sup>		d385	RdyBit Mode Act <sup>(2)(4)</sup>		
	Analog In 0-10V Analog In 4-20mA Elapsed Time-hr	d360 d361 d362	Counter Status	d364	Encoder Speed <sup>(2)</sup>	d378	PID2 Setpnt Disp <sup>(1)</sup>	d386		d392			
			Timer Status	d365	DC Bus Ripple	d380	Position Status <sup>(1)</sup>	d387	Drive Status 2 <sup>(2)(3)</sup>	d393			
			Drive Type	d367	Output Powr Fctr	d381	Units Traveled H <sup>(1)</sup>	d388	Dig Out Status <sup>(2)(3)</sup>	d394			
			Testpoint Data	d368	Torque Current	d382	Units Traveled L <sup>(1)</sup>	d389					
			Motor OL Level	d369	PID1 Fdbk Displ	d383	Fiber Status	d390					
			Slip Hz Meter	d375	PID1 Setpnt Disp	d384	Stp Logic Status <sup>(1)</sup>	d391					



Advanced Program																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
------------------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Fault and Diagnostic										
	Fault 4 Code	F604	Fault 5 Time-min	F625	Fault10 Current <sup>(1)</sup>	F650	EN Rate Act <sup>(1)</sup>	F685	Drv 1 Reference	F710
	Fault 5 Code	F605	Fault 6 Time-min <sup>(1)</sup>	F626	Fault 1 BusVolts	F651	DSI I/O Act	F686	Drv 1 Logic Sts	F711
	Fault 6 Code	F606	Fault 7 Time-min <sup>(1)</sup>	F627	Fault 2 BusVolts	F652	HW Addr 1 <sup>(1)</sup>	F687	Drv 1 Feedback	F712
	Fault 7 Code	F607	Fault 8 Time-min <sup>(1)</sup>	F628	Fault 3 BusVolts	F653	HW Addr 2 <sup>(1)</sup>	F688	Drv 2 Logic Cmd	F713
	Fault 8 Code	F608	Fault 9 Time-min <sup>(1)</sup>	F629	Fault 4 BusVolts	F654	HW Addr 3 <sup>(1)</sup>	F689	Drv 2 Reference	F714
	Fault 9 Code	F609	Fault10 Time-min <sup>(1)</sup>	F630	Fault 5 BusVolts	F655	HW Addr 4 <sup>(1)</sup>	F690	Drv 2 Logic Sts	F715
	Fault10 Code	F610	Fault 1 Freq	F631	Fault 6 BusVolts <sup>(1)</sup>	F656	HW Addr 5 <sup>(1)</sup>	F691	Drv 2 Feedback	F716
	Fault 1 Time-hr	F611	Fault 2 Freq	F632	Fault 7 BusVolts <sup>(1)</sup>	F657	HW Addr 6 <sup>(1)</sup>	F692	Drv 2 Logic Cmd	F717
	Fault 2 Time-hr	F612	Fault 3 Freq	F633	Fault 8 BusVolts <sup>(1)</sup>	F658	EN IP Addr Act 1 <sup>(1)</sup>	F693	Drv 3 Reference	F718
	Fault 3 Time-hr	F613	Fault 4 Freq	F634	Fault 9 BusVolts <sup>(1)</sup>	F659	EN IP Addr Act 2 <sup>(1)</sup>	F694	Drv 3 Logic Sts	F719
	Fault 4 Time-hr	F614	Fault 5 Freq	F635	Fault10 BusVolts <sup>(1)</sup>	F660	EN IP Addr Act 3 <sup>(1)</sup>	F695	Drv 3 Feedback	F720
	Fault 5 Time-hr	F615	Fault 6 Freq <sup>(1)</sup>	F636	Status @ Fault 1	F661	EN IP Addr Act 4 <sup>(1)</sup>	F696	Drv 3 Logic Cmd	F721
	Fault 6 Time-hr <sup>(1)</sup>	F616	Fault 7 Freq <sup>(1)</sup>	F637	Status @ Fault 2	F662	EN Subnet Act 1 <sup>(1)</sup>	F697	Drv 4 Reference	F722
	Fault 7 Time-hr <sup>(1)</sup>	F617	Fault 8 Freq <sup>(1)</sup>	F638	Status @ Fault 3	F663	EN Subnet Act 2 <sup>(1)</sup>	F698	Drv 4 Logic Cmd	F723
	Fault 8 Time-hr <sup>(1)</sup>	F618	Fault 9 Freq <sup>(1)</sup>	F639	Status @ Fault 4	F664	EN Subnet Act 3 <sup>(1)</sup>	F699	Drv 4 Feedback	F724
	Fault 9 Time-hr <sup>(1)</sup>	F619	Fault10 Freq <sup>(1)</sup>	F640	Status @ Fault 5	F665	EN Subnet Act 4 <sup>(1)</sup>	F700	EN Rx Overruns <sup>(1)</sup>	F725
	Fault10 Time-hr <sup>(1)</sup>	F620	Fault 1 Current	F641	Status @ Fault 6 <sup>(1)</sup>	F666	EN Gateway Act 1 <sup>(1)</sup>	F701	EN Rx Packets <sup>(1)</sup>	F726
	Fault 1 Time-min	F621	Fault 2 Current	F642	Status @ Fault 7 <sup>(1)</sup>	F667	EN Gateway Act 2 <sup>(1)</sup>	F702	EN Rx Errors <sup>(1)</sup>	F727
	Fault 2 Time-min	F622	Fault 3 Current	F643	Status @ Fault 8 <sup>(1)</sup>	F668	EN Gateway Act 3 <sup>(1)</sup>	F703	EN Tx Packets <sup>(1)</sup>	F728
	Fault 3 Time-min	F623	Fault 4 Current	F644	Status @ Fault 9 <sup>(1)</sup>	F669	EN Gateway Act 4 <sup>(1)</sup>	F704	EN Tx Errors <sup>(1)</sup>	F729
	Fault 4 Time-min	F624	Fault 5 Current	F645	Status @ Fault10 <sup>(1)</sup>	F670	EN Gateway Act 4 <sup>(1)</sup>	F705	EN Missed IO Pkt <sup>(1)</sup>	F730
			Fault 6 Current <sup>(1)</sup>	F646	Comm Sts - DSI	F681		F706	DSI Errors	F731
			Fault 7 Current <sup>(1)</sup>	F647	Comm Sts - Opt	F682		F707		
			Fault 8 Current <sup>(1)</sup>	F648	Com Sts-Emb Enet <sup>(1)</sup>	F683	Drv 0 Logic Cmd	F708		
			Fault 9 Current <sup>(1)</sup>	F649	EN Addr Src <sup>(1)</sup>	F684	Drv 0 Reference	F709		
							Drv 0 Logic Sts			
							Drv 0 Feedback			
							Drv 1 Logic Cmd			






(1) Parameter is specific to PowerFlex 525 drives only.




(2) Parameter is also available in PowerFlex 523 FRN 3.xxx and later. (3) Parameter is available in PowerFlex 525 FRN 5.xxx and later.

(4) Parameter is available in PowerFlex 525 FRN 3.xxx and later. (5) Parameter is available in PowerFlex 525 FRN 2.xxx and later.

## AppView Parameter Groups

PowerFlex 520-series drives include various AppView™ parameter groups that groups certain parameters together for quick and easy access based on different types of applications. See [AppView Parameter Groups on page 150](#) for more information.

<b>Conveyor</b>										
	Language Output Freq Commanded Freq	P030 b001 b002	Motor NP Volts	P031	Decel Time 1	P042	DigIn TermBlk 03	t063	Anlg In mA Loss	t097
			Motor NP Hertz	P032	Minimum Freq	P043	Opto Out1 Sel	t069	Slip Hz Meter	d375
			Motor OL Current	P033	Maximum Freq	P044	Relay Out1 Sel	t076	Preset Freq 0	A410
			Motor NP FLA	P034	Stop Mode	P045	Anlg In 0-10V Lo	t091	Jog Frequency	A431
			Motor NP Poles	P035	Start Source 1	P046	Anlg In 0-10V Hi	t092	Jog Accel/Decel	A432
			Autotune	P040	Speed Reference1	P047	Anlg In4-20mA Lo	t095	S Curve %	A439
			Accel Time 1	P041	DigIn TermBlk 02	t062	Anlg In4-20mA Hi	t096	Reverse Disable	A544
<b>Mixer</b>										
	Language Output Freq	P030 b001	Commanded Freq	b002	Motor NP Poles	P035	Stop Mode	P045	Anlg In4-20mA Lo	t095
			Output Current	b003	Autotune	P040	Start Source 1	P046	Anlg In4-20mA Hi	t096
			Motor NP Volts	P031	Accel Time 1	P041	Speed Reference1	P047	Anlg In mA Loss	t097
			Motor NP Hertz	P032	Decel Time 1	P042	Relay Out1 Sel	t076	Preset Freq 0	A410
			Motor OL Current	P033	Minimum Freq	P043	Anlg In 0-10V Lo	t091	Stall Fault Time	A492
			Motor NP FLA	P034	Maximum Freq	P044	Anlg In 0-10V Hi	t092		
<b>Compressor</b>										
	Language Output Freq Commanded Freq Motor NP Volts	P030 b001 b002 P031	Motor NP Hertz	P032	Maximum Freq	P044	Anlg In 0-10V Lo	t091	Start At PowerUp	A543
			Motor OL Current	P033	Stop Mode	P045	Anlg In 0-10V Hi	t092	Reverse Disable	A544
			Motor NP FLA	P034	Start Source 1	P046	Anlg In4-20mA Lo	t095	Power Loss Mode	A548
			Motor NP Poles	P035	Speed Reference1	P047	Anlg In4-20mA Hi	t096	Half Bus Enable	A549
			Autotune	P040	Relay Out1 Sel	t076	Anlg In mA Loss	t097		
			Accel Time 1	P041	Analog Out Sel	t088	Preset Freq 0	A410		
			Decel Time 1	P042	Analog Out High	t089	Auto Rstrt Tries	A541		
Minimum Freq	P043	Anlg Out Setpt	t090	Auto Rstrt Delay	A542					
<b>Centrifugal Pump</b>										
	Language Output Freq Commanded Freq Motor NP Volts Motor NP Hertz	P030 b001 b002 P031 P032	Motor OL Current	P033	Start Source 1	P046	Anlg In4-20mA Hi	t096	PID 1 Diff Rate	A463
			Motor NP FLA	P034	Speed Reference1	P047	Anlg In mA Loss	t097	PID 1 Setpoint	A464
			Motor NP Poles	P035	Relay Out1 Sel	t076	Preset Freq 0	A410	PID 1 Deadband	A465
			Autotune	P040	Analog Out Sel	t088	PID 1 Trim Hi	A456	PID 1 Preload	A466
			Accel Time 1	P041	Analog Out High	t089	PID 1 Trim Lo	A457	Auto Rstrt Tries	A541
			Decel Time 1	P042	Anlg Out Setpt	t090	PID 1 Ref Sel	A459	Auto Rstrt Delay	A542
			Minimum Freq	P043	Anlg In 0-10V Lo	t091	PID 1 Fdback Sel	A460	Start At PowerUp	A543
Maximum Freq	P044	Anlg In 0-10V Hi	t092	PID 1 Prop Gain	A461	Reverse Disable	A544			
Stop Mode	P045	Anlg In4-20mA Lo	t095	PID 1 Integ Time	A462					
<b>Blower/Fan</b>										
	Language Output Freq Commanded Freq Motor NP Volts Motor NP Hertz	P030 b001 b002 P031 P032	Motor OL Current	P033	Start Source 1	P046	Anlg In4-20mA Hi	t096	PID 1 Diff Rate	A463
			Motor NP FLA	P034	Speed Reference1	P047	Anlg In mA Loss	t097	PID 1 Setpoint	A464
			Motor NP Poles	P035	Relay Out1 Sel	t076	Preset Freq 0	A410	PID 1 Deadband	A465
			Autotune	P040	Analog Out Sel	t088	PID 1 Trim Hi	A456	PID 1 Preload	A466
			Accel Time 1	P041	Analog Out High	t089	PID 1 Trim Lo	A457	Auto Rstrt Tries	A541
			Decel Time 1	P042	Anlg Out Setpt	t090	PID 1 Ref Sel	A459	Auto Rstrt Delay	A542
			Minimum Freq	P043	Anlg In 0-10V Lo	t091	PID 1 Fdback Sel	A460	Start At PowerUp	A543
Maximum Freq	P044	Anlg In 0-10V Hi	t092	PID 1 Prop Gain	A461	Reverse Disable	A544			
Stop Mode	P045	Anlg In4-20mA Lo	t095	PID 1 Integ Time	A462	Flying Start En	A545			

<b>Extruder</b>										
	Language Output Freq Commanded Freq Output Current Motor NP Volts	P030 b001 b002 b003 P031	Motor NP Hertz	P032	Stop Mode	P045	Anlg In4-20mA Lo	t095	Encoder PPR	A536
			Motor OL Current	P033	Start Source 1	P046	Anlg In4-20mA Hi	t096	Pulse In Scale	A537
			Motor NP FLA	P034	Speed Reference1	P047	Anlg In mA Loss	t097	Ki Speed Loop	A538
			Motor NP Poles	P035	Relay Out1 Sel	t076	Slip Hz Meter	d375	Kp Speed Loop	A539
			Autotune	P040	Analog Out Sel	t088	Speed Feedback	d376	Power Loss Mode	A548
			Accel Time 1	P041	Analog Out High	t089	Encoder Speed	d378	Half Bus Enable	A549
			Decel Time 1	P042	Anlg Out Setpt	t090	Preset Freq 0	A410		
			Minimum Freq	P043	Anlg In 0-10V Lo	t091	Stall Fault Time	A492		
			Maximum Freq	P044	Anlg In 0-10V Hi	t092	Motor Fdbk Type	A535		
<b>Positioning<sup>(1)</sup></b>										
	Language Output Freq Commanded Freq Motor NP Volts Motor NP Hertz Motor OL Current Motor NP FLA Motor NP Poles Autotune Accel Time 1 Decel Time 1 Minimum Freq Maximum Freq	P030 b001 b002 P031 P032 P033 P034 P035 P040 P041 P042 P043 P044	Stop Mode	P045	Stp Logic 5	L185	Step Units 6	L212	Jog Accel/Decel	A432
			Start Source 1	P046	Stp Logic 6	L186	Step Units 7	L214	DB Threshold	A438
			Speed Reference1	P047	Stp Logic 7	L187	Slip Hz Meter	d375	S Curve %	A439
			DigIn TermBlk 02	t062	Stp Logic Time 0	L190	Speed Feedback	d376	Motor Fdbk Type	A535
			DigIn TermBlk 03	t063	Stp Logic Time 1	L191	Encoder Speed	d378	Encoder PPR	A536
			DigIn TermBlk 05	t065	Stp Logic Time 2	L192	Units Traveled H	d388	Pulse In Scale	A537
			DigIn TermBlk 06	t066	Stp Logic Time 3	L193	Units Traveled L	d389	Ki Speed Loop	A538
			Opto Out1 Sel	t069	Stp Logic Time 4	L194	Preset Freq 0	A410	Kp Speed Loop	A539
			Opto Out2 Sel	t072	Stp Logic Time 5	L195	Preset Freq 1	A411	Bus Reg Enable	A550
			Relay Out1 Sel	t076	Stp Logic Time 6	L196	Preset Freq 2	A412	Positioning Mode	A558
			EM Brk Off Delay	t086	Stp Logic Time 7	L197	Preset Freq 3	A413	Counts Per Unit	A559
			EM Brk On Delay	t087	Step Units 0	L200	Preset Freq 4	A414	Enh Control Word	A560
			Stp Logic 0	L180	Step Units 1	L202	Preset Freq 5	A415	Find Home Freq	A562
			Stp Logic 1	L181	Step Units 2	L204	Preset Freq 6	A416	Find Home Dir	A563
			Stp Logic 2	L182	Step Units 3	L206	Preset Freq 7	A417	Encoder Pos Tol	A564
			Stp Logic 3	L183	Step Units 4	L208	Preset Freq 8	A418	Pos Reg Filter	A565
			Stp Logic 4	L184	Step Units 5	L210	Jog Frequency	A431	Pos Reg Gain	A566
<b>Textile/Fiber</b>										
	Language Output Freq Commanded Freq Motor NP Volts Motor NP Hertz Motor OL Current	P030 b001 b002 P031 P032 P033	Motor NP FLA	P034	DigIn TermBlk 02	t062	Slip Hz Meter	d375	Max Traverse	A567
			Motor NP Poles	P035	DigIn TermBlk 03	t063	Fiber Status	d390	Traverse Inc	A568
			Autotune	P040	Opto Out1 Sel	t069	Preset Freq 0	A410	Traverse Dec	A569
			Accel Time 1	P041	Opto Out2 Sel	t072	Jog Frequency	A431	P Jump	A570
			Decel Time 1	P042	Relay Out1 Sel	t076	Jog Accel/Decel	A432	Sync Time	A571
			Minimum Freq	P043	Anlg In 0-10V Lo	t091	S Curve %	A439	Speed Ratio	A572
			Maximum Freq	P044	Anlg In 0-10V Hi	t092	Reverse Disable	A544		
			Stop Mode	P045	Anlg In4-20mA Lo	t095	Power Loss Mode	A548		
			Start Source 1	P046	Anlg In4-20mA Hi	t096	Half Bus Enable	A549		
Speed Reference1	P047	Anlg In mA Loss	t097	Bus Reg Enable	A550					



**KNIGHT**  
**GLOBAL**

KNIGHT GLOBAL

2705 Commerce Parkway

Auburn Hills, MI 48326

Phone 248-377-4950 | Fax 248-377-2135

For additional copies/literature contact: [salesorders@knightglobal.com](mailto:salesorders@knightglobal.com)

For service-related requests contact: [service@knightglobal.com](mailto:service@knightglobal.com)

[www.knightglobal.com](http://www.knightglobal.com)